

Personal Computer
MZ-700

OWNER'S MANUAL



SHARP

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

BLUE: Neutral
BROWN: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows,

The wire which is coloured **BLUE** must be connected to the terminal which is marked with the letter **N** or coloured black.

The wire which is coloured **BROWN** must be connected to the terminal which is marked with the letter **L** or coloured red.

This apparatus complies with requirements of EEC directive 76/889/EEC.

Das Gerät stimmt mit den Bedingungen der EG-Richtlinien 76/889/EWG überein.

Cet appareil répond aux spécifications de la directive CEE 76/889/CEE.

Dit apparaat voldoet aan de vereisten van EEG-reglementen 76/889/EEG.

Apparatet opfylder kravene i EF direktivet 76/889/EF.

Quest'apparecchio è stato prodotto in conformità alle direttive CEE 76/889/CEE.

Personal Computer
MX-7000

**Owner's
Manual**

Personal Computer
MZ-700

NOTICE

This manual has been written for the MZ-700 series personal computers and the BASIC interpreter which is provided with the MZ-700.

- (1) All system software for the MZ-700 series computers is supported in software packs (cassette tape, etc.) in file form. The contents of all system software and the material presented in this manual are subject to change without prior notice for the purpose of product improvement and other reasons, and care should be taken to confirm that the file version number of the system software used matches that specified in this manual.
- (2) All system software for the Sharp MZ-700 series personal computer has been developed by the Sharp Corporation, and all rights to such software are reserved. Reproduction of the system software or the contents of this book is prohibited.
- (3) This computer and the contents of this manual have been fully checked for completeness and correctness prior to shipment; however, if you should encounter any problems during operation or have any questions which cannot be resolved by reading this manual, please do not hesitate to contact your Sharp dealer for assistance.


Notwithstanding the foregoing, note that the Sharp Corporation and its representatives will not assume responsibility for any losses or damages incurred as a result of operation or use of this equipment.

Preface

Congratulations on your purchase of a Sharp MZ-700 series personal computer. Before using your computer, please read and make sure you understand the operating procedures which are described in this manual. The features and general operating procedures are described in Chapters 1 and 3, so please read those chapters first.

All software for the MZ-700 series computers is distributed on cassette tape.

The cassette tape included with the computer contains BASIC 1Z-013B, a high level BASIC interpreter which enables programming in the BASIC language and makes it possible to utilize the full capabilities of the MZ-700. The BASIC 1Z-013B interpreter and procedures for its use are fully described in this manual.



THIS FIGURE DRAWN USING THE COLOR PLOTTER-PRINTER

MZ-700 OWNER'S MANUAL

CONTENTS

Chapter 1 The world of MZ-700 Series Personal Computer

1. 1	Features of the MZ-700 Series	10
1. 2	Using this Manual	12
1. 3	An Introduction to the World of Computers	13

Chapter 2 BASIC

2. 1	Introduction to Programming in BASIC	16
2. 2	An Outline of BASIC	21
2. 3	Frequently Used BASIC Commands and Statements	28
2. 4	Built-in Function	71
2. 5	String Function	76
2. 6	Color display state ment	80
2. 7	Color Plotter-Printer Commands	82
2. 8	Machine Language Program Control Statements	91
2. 9	I/O Statements	95
2. 10	Other Statements	96
2. 11	Monitor Function	99

Chapter 3 Operating the MZ-700

3. 1	Appearance of the MZ-700 Series Personal Computers	104
3. 2	Connection to Display Unit	106
3. 3	Data Recorder	108
3. 4	Color Plotter-Printer	110
3. 5	Key Operation	114

Chapter 4 Hardware

4. 1	MZ-700 System Diagram	122
4. 2	Memory configuration	123
4. 3	Memory Mapped I/O (\$E000-\$E008)	130
4. 4	Signal System of Color V-RAM	133
4. 5	MZ-700 Circuit Diagrams	134

Chapter 5 Monitor Commands and Subroutines

5. 1	Monitor Commands	146
5. 2	Functions and Use of Monitor Commands	147
5. 3	Monitor Subroutines	151

INDEX

[BASIC COMMANDS] (is abbreviated format)

APPENDICES

		88
	A. 1 Code Tables	154
	A. 2 MZ-700 Series Computer Specifications	157
	A. 3 BASIC Error Message List	159
	A. 4 Z80A Instruction Set	160
	A. 5 Monitor Program Assembly List	164
	A. 6 Color Plotter-Printer Control Codes	198
	A. 7 Notes Concerning Operation	201
		78
		90
		68
		52
		80
		98
		34
		71
		61
		56
		57
		31
		56
		82
		32
		84
		71
		29
		71
		71
		47
		77
		83
		83
		83
		49
		48
		88

INDEX

[BASIC COMMANDS] () is abbreviated format

A		H	
ABS	71	HSET	(H.) 88
ASC	78		
ATN	71	I	
AUTO	(A.) 31	IF ERL	97
AXIS	(AX.) 89	IF ERN	96
		IF~GOSUB	(IF~GOS.) 53
B		IF~GOTO	(IF~G.) 53
BYE	(B.) 35	IF~THEN	(IF~TH.) 50
		INP	95
C		INPUT	(I.) 42
CHR\$	78	INPUT/T	(I./T) 68
CIRCLE	(CI.) 90	INT	71
CLOSE	(CLO.) 68		
CLR	59	J	
COLOR	(COL.) 80		
CONSOLE	(CONS.) 98	K	
CONT	(C.) 34	KEY LIST	(K. L.) 35
COS	71		
CURSOR	(CU.) 61	L	
		LEFT\$	77
D		LEN	76
DEF FN	56	LET	36
DEF KEY	57	LIMIT	(LIM.) 92
DELETE	(D.) 31	LINE	85
DIM	56	LIST	(L.) 32
		LIST/P	(L./P) 84
E		LN	71
END	(E.) 59	LOAD	(LO.) 28
EXP	71	LOG	71
F		M	
FOR~NEXT	(F.~N.) 47	MERGE	(ME.) 32
		MID\$	77
G		MODE GR	(M. GR) 83
GET	43	MODE TL	(M. TL) 83
GOSUB		MODE TN	(M. TN) 83
~RETURN	(GOS.~RET.) 49	MODE TS	(M. TS) 83
GOTO	(G.) 48	MOVE	87
GPRINT	(GP.) 88	MUSIC	(MU.) 65

N
NEW 32

O
ON ERROR
 GOTO (ON ERR. G.) 96
ON~GOSUB (ON~GOS.) 55
ON~GOTO (ON~G.) 54
OUT 95

P
PAGE 84
PAI 71
PCOLOR (PC.) 83
PEEK 93
PHOME (PH.) 87
PLOT OFF (PL. OFF) 98
PLOT ON (PL. ON) 98
POKE 92
PRINT (?) 37
PRINT USING (?USI.) 38
PRINT/P (?/P) 84
PRINT/T (?/T) 68
PRINT [α , β] (? [α , β]) 81

Q

R
RAD 71
READ~DATA (REA. ~DA.) 44
REM 58
RENUM (REN.) 33
RESET 63
RESTORE (RES.) 46
RESUME (RESU.) 97
RIGHT\$ 77
RLINE (RL.) 86
RMOVE (RM.) 87
RND 72
ROPEN (RO.) 68
RUN (R.) 34

S
SAVE (SA.) 29
SET 63
SGN 71
SIN 71
SIZE 97
SKIP 84
SPC 62
SQR 71
STOP (S.) 59
STR\$ 79

T
TAB 62
TAN 71
TEMPO (TEM.) 67
TEST (TE.) 84
TIS\$ 60

U
USR (U.) 93

V
VAL 79
VERIFY (V.) 30

W
WOPEN (W.) 68

X

Y

Z

THE WORLD OF MZ-700 SERIES PERSONAL COMPUTER

Chapter 1



1.1 Features of the MZ-700 Series

In the space of just a few decades, the computer has undergone a dramatic transformation, changing from an intricate, enormously expensive monster weighing several dozen tons into a compact, inexpensive device which can be used by almost anyone. Whereas access to computers used to be limited to a few privileged individuals with special training, the inexpensive, user-friendly machines now available make the world of computing open to people in all different walks of life. The Sharp MZ-700 series computers are representative of such machines.

People use words and expressions to convey meanings.

Computers of the Sharp MZ-700 series, however, convey meaning through an ordinary television set or special printer. Any TV set can be used, either color or black-and-white; or, you may invest in one of the special display screens available if you want greater resolution and sharpness; you will be surprised at the beauty which is provided by such displays.

A tape recorder can be connected to computers of the Sharp MZ-700 series to record programs, the instructions which control the operation of the computer. When printed records of such programs or of the results of computer processing are desired, they can be obtained on the MZ-700's compact, elegantly designed 4-color plotter-printer.



MZ-731

Note: In the remainder of this manual, the term “MZ-700” will be used to indicate any of the computers of the MZ-700 series (the MZ-711, MZ-721, and MZ-731).

1.2 Using this Manual

Before starting to study programming, why not try playing with the MZ-700 a bit? We're sure you want to do that anyway, rather than waiting until after you have read this book. First, read "Operating the MZ-700" in Chapter 3 (you need read only those parts which apply to the model which you are using). Connect the MZ-700 to a television, read the explanation of procedures for using the keyboard, and learn which characters are output when each key is pressed.


If you are using the MZ-700 for the first time, you may find it difficult to learn the language; however, they are encouraged to key in the examples as given. What BASIC is all about. You may skip the Control Statement programming in BASIC.

If you have used the MZ-700 before, you will find it almost exactly the same as the MZ-800. The major difference between the two is in the color statements (applicable to both the television screen and the color plotter-printer) which have been added.

however, you should find it easy to become familiar with these by reading sections 2.6 "Color display statement", and 2.7 "Color Plotter-printer Commands". Having done this, you will quickly be captivated by the power of expanded BASIC.

This manual also includes a discussion of "Operating the MZ-700" (Chapter 3), a reference section entitled "Hardware" (Chapter 4), a discussion of the "MZ-700 Commands and Subroutines" (Chapter 5), and appendices of other information.

Now go ahead and try playing with the MZ-700. You will find this manual helpful.



MZ-721



MZ-711

1.2 Using this Manual

Before starting to study programming, why not try playing with the MZ-700 a bit? We're sure you want to do that anyway, rather than waiting until after you have read this book. First, read "Operating the MZ-700" in Chapter 3 (you need read only those parts which apply to the model which you are using). Connect the MZ-700 to a television, read the explanation of procedures for using the keyboard, and learn which characters are output when each key is pressed.

If you are using the MZ-700 for the first time, read Chapters 1 and 2, in that order. At first, you may find it difficult to grasp the meanings of the various commands and statements of the BASIC programming language; however, even if you don't understand the explanations, be sure to key in the examples as they are encountered. As you do so, you will gradually develop a concept of what BASIC is all about.

You may skip over those portions of Chapter 2 which start with 2. 8 "Machine Language Program Control Statements"; however, these sections will prove useful when you have completely mastered programming in BASIC, or wish to become more familiar with the computer's internal operation.

If you have used the MZ-80K, you will find that the commands and statements of BASIC for the MZ-700 are used in the same manner as those of the SP-5025 family, so that the MZ-700 can be used in almost exactly the same manner as the MZ-80K. The major difference between the two is in the color statements (applicable to both the television screen and the color plotter-printer) which have been added; however, you should find it easy to become familiar with these by reading sections 2. 6 "Color display statement" and 2. 7 "Color Plotter-printer Commands." Having done this, you will quickly be captivated by the power of expanded BASIC.

This manual also includes a discussion of "Operating the MZ-700" (Chapter 3), a reference section entitled "Hardware" (Chapter 4), a discussion of the "Monitor Commands and Subroutines" (Chapter 5), and appendices of other information.

Now go ahead and learn everything you can about the MZ-700. We hope that you will find this manual helpful.

1.3 An Introduction to the World of Computers

1.3.1 What is BASIC?

People use language to communicate with each other, and specially designed languages are also used for communication with computers. BASIC is one such language.

Beginner's All-purpose Symbolic Instruction Code

Just as human beings use languages such as English, French, German, and Japanese for communication, there are also many different languages which are used for communication with computers. Among these are BASIC, FORTRAN, COBOL, and PASCAL. Of these, BASIC is the computer language whose structure is closest to that of the languages used by humans, and therefore is the easiest for humans to understand.

1.3.2 Loading BASIC into the MZ-700

The BASIC language must be loaded into the MZ-700 before it can be used to do any work. A cassette tape containing this language has been included in the case containing the MZ-700. Now let's teach the language to the computer; procedures for doing this are described below. (The explanation assumes that you are using an MZ-731; however, the procedures are basically the same for all computers of the MZ-700 series.)

- (1) Connect the display as described on page 106.
- (2) Turn on the power switch located on the back of the computer.
- (3) The following characters are displayed on the screen and a square, blinking pattern appears. This pattern is referred to as the cursor.

```
** MONITOR 1Z-013A **
```

```
**
```

```
  | Cursor
```

- (4) Set the cassette tape containing the BASIC language in the computer's data recorder.
- (5) Type in the word `L※1O※2A※1D` and press the `C※2R` key. After doing this, the message `⊥ PLAY` appears on the screen.
- (6) Press the data recorder's `PLAY` button; the cassette tape starts moving and loading of the BASIC language begins.
- (7) After loading has been completed, the message `READY` is displayed and the cursor starts to blink again.

Notes:

- ※1 `L※1O※2A※1D` . . . This is the instruction for loading programs or data from cassette tape.
- ※2 `C※2R` This is referred to as the carriage return key, and is mainly used to indicate completion of entry of an instruction.

```

** MONITOR 1Z-013A**
* LOAD
⊥ PLAY
LOADING BASIC
  BASIC INTERPRETER 1Z-013B VX.XX
  COPYRIGHT 1983 BY SHARP CORP
XXXXX BYTES
READY
⊠

```

This completes loading of the BASIC program. You can talk to the computer using BASIC, and the computer will respond.

1.3.3 Try Executing a Program

Loading BASIC into the computer doesn't cause it to do anything; first, it must be given instructions in BASIC as to what it is to do. Although we will not explain the instructions of BASIC until later, let's go ahead and try executing a BASIC program right now.

Remove the cassette tape from the recorder and turn it over so that the "B" side is up. A sample program is recorded on this side of the cassette tape. Using the following procedures, load this program into the computer and execute it.

- (1) After turning the tape over and reloading it into the recorder, press the REWIND button to rewind it. Next, type in `LOAD` and press the `CR` key; when the message `⊥ PLAY` is displayed, press the `PLAY` button on the data recorder. This begins loading of the sample program.
- (2) When loading is completed, the cassette tape stops, `READY` is displayed on the screen, and the cursor starts to blink again.
- (3) Now that the program has been loaded into the computer's memory, try executing it. This is done by typing in `RUN` and pressing the `CR` key.
- (4) Now let's take a peek at the program. Hold down the `SHIFT` key and press the `BREAK` key. This stops program execution and displays the words `BREAK` and `READY`, then the cursor starts to blink again.
- (5) Type in `LIST` and press the `CR` key. This lists the lines of the program on the screen one after another. (Output of the list can be temporarily stopped at any time by pressing the space bar.)
- (6) If you wish to resume program execution, type in `RUN` again and hit the `CR` key.
- (7) If you want to run a different program, set the cassette tape containing that program in the recorder, `LOAD` the program, then `RUN` it. The previous program is automatically erased from memory when the new one is loaded, so the computer contains only the BASIC language and the last program loaded.


Introduction to Programming in BASIC

BASIC

As you would on a pocket calculator. (This is called operating the MZ-700 in the "direct mode.") Key

computer doesn't do anything when it is presented with a problem in this form: an ordinary calculator are completely different in this respect, and instructions must which can be understood by the computer (i.e. in the form prescribed by the BASIC

correctly, the number "13" will be displayed and the screen will appear as shown



2.1 Introduction to Programming in BASIC

2.1.1 Direct Mode

Now that you have made some key entries on the MZ-700, you have reached the point where you are ready to start learning how to program. Before you start, however, try using the MZ-700 as you would an ordinary pocket calculator. (This is called operating the MZ-700 in the “direct mode”.) Key in the following, just as you would on a pocket calculator.

```
4+9=CR
```

As you can see, the computer doesn't do anything when it is presented with a problem in this form; your computer and an ordinary calculator are completely different in this respect, and instructions must be entered in a form which can be understood by the computer (i.e, in the form prescribed by the BASIC language). Now try typing in the following.

```
PRINT 4+9CR
```

If you have done this correctly, the number “13” will be displayed and the screen will appear as shown below.

```
READY  
PRINT 4+9  
13  
READY
```

PRINT is an instruction which tells the computer to display something on the screen. Here, the computer is instructed to display the sum of 4 + 9.

Now let's try doing a somewhat more complex calculation.

With BASIC for the MZ-700, the operators (symbols) for the basic arithmetic operations are as follows.

Addition:	+	
Subtraction:	-	
Multiplication:	*	(the asterisk)
Division:	/	(the slash)
Exponentiation:	↑	

When symbols such a “*”, “+”, and “↑” are mixed together in a single arithmetic expression, the order in which calculations indicated by the symbols are performed is referred to as their priority. Just as with ordinary algebra, operations can be included in parentheses, so operations within the innermost set of parentheses are performed first. Within a set of parentheses, exponentiation is performed first, followed by multiplication and division (which have equal priority, and therefore are performed as they are encountered in the expression, from left to right), and then by addition and subtraction.

For example, to obtain the answer to the expression $3 \times 6 \times (6 + 3 \times (9 - 2 \times (4 - 2) + 1))$, enter the following.

```
PRINT 3*6*(6+3*(9-2*(4-2)+1))CR
```

Now try using the computer to do a variety of other problems in arithmetic.

[EXERCISE]

[ANSWER]

1. $\frac{6+4}{6-4}$

PRINT (6+4)/(6-4)
5

2. $3 \times (5+9 \times (9-2)) - \frac{6}{4-2} + 5$

PRINT 3*(5+9*(9-2))-6/(4-2)+5
200

3. $(3+4) \times (5+6)$

PRINT (3+4)*(5+6)
77

4. $\frac{10+20}{6} \times (2+3)$

PRINT (10+20)/6*(2+3)
25

5. $\frac{10+20}{6 \times (2+3)}$

PRINT (10+20)/(6*(2+3))
1

After going through the exercises, try typing in `?5*8` and pressing the `CR` key; the answer "40" is displayed. The reason for this is that BASIC interprets the question mark in the same manner as the instruction PRINT. Remember this as a convenient, abbreviated form of the PRINT instruction.

Now try entering the following. (The quotation marks are entered by holding down `SHIFT` and pressing the `2` key.)

```
PRINT"4+9="CR
```

As you can see, the characters within quotation marks are displayed on the screen, but the answer is not. Now try entering the following.

```
PRINT"ABCDEFG"CR
```

This causes ABCDEFG to be displayed on the screen.

In other words, using the PRINT instruction together with quotation marks tells the MZ-700 to display characters on the screen exactly as they are specified between quotation marks. The characters within any set of quotation marks are referred to as a "character string" or "string".

Now go on to enter the following.

```
PRINT"4+9=":4+9CR
```

This causes the following to be displayed on the screen.

4+9= 13..... (The " " symbol indicates a space. Actually, nothing is displayed on the TV screen in the position indicated by this symbol.)

In other words, the instruction above tells the computer to display both the character string "4 + 9 =" and the result of the arithmetic expression "4 + 9 =". Now try entering the following.

```
PRINT"4+9=" .4+9CR
```

After typing in this entry, the following should be displayed on the screen.

4+9= 13

The reason the screen appears different this time is because the PRINT instruction displays items of information (character strings or the results of arithmetic expressions) differently depending on whether they are separated from each other by semicolons or commas.

Semicolon (;) Instructs the computer to display items immediately adjacent to each other.

Comma (,) Instructs the computer to display the item at the position which is 10 spaces (columns) from the beginning of the display line.

If you have the MZ-731 (or a separate plotter-printer), now try appending the characters `[/P]` to the end of the word PRINT.

```
PRINT[/P]"4+9=":4+9CR
```

This time nothing appears on the display screen, but the same result is printed out on the plotter-printer. In other words, the `[/P]` symbols switch output from the display to the plotter-printer.

This completes our explanation of procedures for using the MZ-700 as you would a pocket calculator.

Note: PRINT "5 + 8 ="; 5 + 8 displays 5 + 8 = 13, while PRINT " 5 - 8 ="; 5 - 8 displays 5 - 8 = -3.

The reason for this is that one space is always reserved for a symbol indicating whether the result is positive or negative, but the symbol is only displayed in that space when the result is negative.

2.1.2 Programming

Let's try making a simple program. However, first let's make sure that the area in the computer's memory which is used for storing programs is completely empty. Do this by typing in NEW and pressing the `[CR]` key. (This instruction will be explained in more detail later; see page 32.)


Type in the following program exactly as shown.

```
10 A=3CR ..... Assigns the value 3 to A.
20 B=6CR ..... Assigns the value 6 to B.
30 C=A+BCR ..... Assigns the result of A + B to C.
40 ? CCR ..... Displays the value assigned to C.
50 ENDCR ..... Instruction indicating the end of the program.
```

The numbers 10, 20, 30, and so forth at the left end of each line are referred to as program line numbers, or simply line numbers; these numbers indicate the order in which instructions are to be executed by the computer. Instructions on the lowest numbered line are executed first, followed by those on the next lowest numbered line, and so forth. Line numbers must be integers in the range from 1 to 65535.

The line numbers 1, 2, 3, and so forth could have been used in this program instead of 10, 20, 30. However, it is common practice to assign line numbers in increments of 10 to provide room for later insertion of other lines.

Now let's check whether the lines have been correctly entered. Type in LIST and press the `[CR]` key; this causes a list of the program lines to be displayed. Notice that the question mark entered at the beginning of line 40 has been converted to PRINT, the full form of the command for displaying data on the display screen.



Now let's try executing the program.

```
RUNCR
```

Enter RUN and press the `CR` key; the result is displayed on line 9 of the screen.

Now we will explain procedures for making changes in programs. First, let's change the instruction on line 20 from $B = 6$ to $B = 8$. Type in LIST 20 and press the `CR` key; this displays just line 20 of the program on the screen. Next, use the cursor control keys (the keys at the right side of the keyboard which are marked with arrows) to move the cursor to the number '6', then press the `8` key and the `CR` key in succession to make the change. **Note that the change is not completed until the `CR` key is pressed.**

Now type in LIST and press the `CR` key again to confirm that the change has been made.

Next, let's change line 30 of the program to $C = 30 * A + B$.

Using the cursor control keys, move the cursor so that it is positioned on top of the "A" in line 30, then press the `INST` key three times in succession. This moves "A + B" three spaces to the right.

```
C=  A+B
   ^
   |
   | Cursor position
```

Now type in `30X` and press the `CR` key to complete the insertion. LIST the program to confirm that the change has been made correctly.

Now change line 30 again so that it reads " $C = 30 * A$ " instead of " $C = 30 * A + B$ ". Do this by moving the cursor to the position immediately to the right of B and pressing the `DEL` key two times; this deletes "+B". Press the `CR` key to complete the change.

Now LIST the program and confirm that it appears as shown below.

```
10 A=3
20 B=8
30 C=30*A
40 PRINT C
50 END
```

To delete an entire line from a program, simply enter the line number of that line and press the `CR` key; delete line 20 in this manner, then LIST the program to confirm that the line has been deleted.

We could insert the instruction "?A" between lines 30 and 40, by typing in `35?A` and pressing the `CR` key. Try this, then LIST the program to confirm that the line has been added. Now delete line 35 by entering 35 and pressing the `CR` key.

The process of changing or inserting lines in a program in this manner is referred to as **editing**, and the program which results from this process is referred to as the **BASIC text**. Each line of the program can include a maximum of 255 characters, including the line number, but the maximum length is reduced by four characters if the question mark is used to represent the PRINT instruction.

At this point, the program contained in the computer's memory should be as follows.

```
10 A=3
30 C=30*A
40 PRINT C
50 END
```

Now we will use this program to explain the procedures for recording programs on cassette tape. Prepare a blank cassette tape (one on which nothing has been recorded) and set it in the data recorder,

then type in the following from the keyboard.

```
SAVE "CALCULATION" J
```

Here, "CALCULATION" is the name which is to be recorded on the cassette tape to identify the program. Any name may be assigned, but the name cannot be longer than 16 characters.

Note: The J symbol in the example above represents the CR key.

When the CR key is pressed, "⏏ RECORD. PLAY" is displayed on the screen. Pressing the RECORD button on the data recorder at this time records the program on cassette tape.

The name which is assigned to the program is referred to as its **file name**. Specification of a file name is not absolutely necessary, but from the point of view of file management it is a good idea to assign one. Of course, the file name is recorded on the tape together with the program.

When recording is completed, READY is displayed to indicate that the computer is finished. Now press the STOP button on the data recorder and rewind the tape.

The program is still present in the computer's memory after recording is completed, so type in NEW J to delete it (enter LIST J to confirm that the program has been deleted). Now let's try using the LOAD instruction to load the program back into memory from the cassette tape as described on page 14.

When a cassette tape contains many programs, that which is to be loaded can be identified by specifying the program's file name together with the LOAD instruction as follows.

```
LOAD "CALCULATION" J
```

Specifying the file name in this manner tells the computer to ignore all programs on the tape other than that with the specified name. If the file name is not specified (if only LOAD J is entered), the computer loads the first program encountered.

Note: When using cassette recorder other than the data recorder built into the MZ-731, and MZ-721 read the instructions on page 109 before attempting to record or load programs.

The LIST command shown above can be used in a variety of different ways. For example, during editing LIST 20 J can be used to display just line 20 of a program. The entire program can be listed by entering LIST J. Other uses of the instruction are as follows.

LIST -30 CR	Lists all lines of the program to line 30.
LIST 30- CR	Lists all lines from line 30 to the end of the program.
LIST 30-50 CR	Lists all lines from line 30 to line 50.
LIST 30 CR	Lists line 30.

When editing programs by listing individual lines with the LIST instruction, press the CLR key (the INST key) together with the SHIFT key when the screen becomes distractingly crowded. This clears the entire screen and moves the cursor to its upper left corner. (This does not affect the program in memory). Afterwards, enter LIST < line number > J again to list the line which is to be edited.

2.2 An Outline of BASIC

2.2.1 Constants

A constant is a number or string of characters which is written into a program, and which is used by that program as it is executed. Types of constants include numeric constants, string (character) constants, and system constants. These are explained below.

Numeric constants

A numeric constant is a number which has a maximum of 8 significant digits. The exponent of such constants must be in the range from 10^{-38} to 10^{38} (the maximum range is 1.548437E-38 to 1.7014118E+38).

(Examples:)

-123.4

0.789

3748.0

3.7E+12..... 3.7×10^{12}

7.65E-9..... 7.65×10^{-9} } E indicates the exponent.

14.8E9..... 14.8×10^9

Hexadecimal numbers: Numbers can be specified in hexadecimal format only for direct memory addressing with the LIMIT, POKE, PEEK, and USR instructions (see pages 92 and 93), and are represented as four digits preceded by a dollar sign (\$).

(Examples:)

LIMIT \$BFFF

USR (\$C000, X\$) X\$ represents a string variable.

String constants

String constants are letters and symbols between quotation marks which are included in programs to allow titles or messages to be output to the display screen or printer. The characters "4+9" appearing on page 17 are a character constant, and not a numeric constant. With BASIC, a string constant may consist of a maximum of 255 characters. (Not including quotation marks which cannot be included in a string constant.)

(Examples:)


" ABCDEFG "

" 12345678910 "

DATA ABCDEFG..... Quotation marks are not needed when string constants are specified in a DATA statement; however, they may be used if desired.

2.2.2 Variables

The word “variable” has a different meaning with BASIC than it does when used with regard to algebraic expressions. To put it in very simple terms, the variables of BASIC are “boxes” in memory for the storage of numbers and characters (character strings). The types of variables used in BASIC include numeric variables, string variables, and system variables.



Numeric variables

Only numeric data can be stored in numeric variables.

Names must be assigned to these variables in accordance with the following rules.

- i) A variable name may consist of any number of characters, but only the first two characters are actually used by the BASIC interpreter to identify the variable. Further, the first character of the variable name must be a letter (A to Z), either letters or numerals may be used for subsequent characters.
- ii) It is not possible to use the names of BASIC commands and statements as variable names.

Correct variable names: ABC, XY, ABCD, A12345
(ABC and ABCD are regarded as the same variable.)

Incorrect variable names: PRINT (PRINT is a BASIC statement)
C@ (Variable names may not include special characters.)

(Example:)

1 Ø A=5..... Stores 5 in variable A.

2 Ø PRINT A..... Displays the value stored in variable A.

String variables

String variables are variables which are used for storing character strings. Names assigned to string variables must conform to the same rules as those assigned to numeric variables; however a dollar sign (\$) is appended to the end of string variable names to differentiate them from other types of variables.

String variables may be used to store a maximum of 255 characters. Such variables are blank until string data is assigned to them.

The only operator which can be used in expressions including more than one string variable is the "+" sign.

(Example:)

- 1Ø A\$ = " ABCD " Substitutes the character string ABCD into string variable A\$.
- 2Ø B\$ = " XYZ " Substitutes the character string XYZ into string variable B\$.
- 3Ø C\$ = A\$ + B\$ Substitutes the sum of string variables A\$ and B\$ (ABCDXYZ) into string variable C\$.
- 4Ø PRINT C\$ Displays the contents of string variable C\$.

System Variables

System variables contain values which are automatically changed by the BASIC interpreter. The system variables are size (the variable which indicates the amount of BASIC free area) and TI\$ (a 6-digit variable which contains the value of the system's 24-hour clock).


(Examples:)

- 1Ø TI\$ = " 013500 " ... This statement assigns the value corresponding to 1:35:00 A.M. to system variable TI\$ and sets the system clock to that time.
- 2Ø PRINT TI\$ Executing this statement displays the current time of the system clock (24-hour time).

Display format:

132819 Indicates that the time is 13:28:19.

- PRINT SIZE J This displays the current amount of free space in the computer's memory (in other words, the amount of space which is available for additional program lines). The value indicated by this variable is reduced each time a program line is entered.



2.2.3 Arrays

Arrays can be thought of as shelves within the computer's memory which contain rows of boxes, each of which represents a variable. The boxes on these shelves are arranged in an orderly sequence, and are identified by means of numbers; these numbers are referred to as subscripts, because they are subscripted to the name which identifies the entire group of boxes.





Such shelves of boxes are set up simply by executing an instruction which declares that they exist; this is referred to as making an array declaration. The array declaration specifies the number of boxes which are to be included in each set of shelves (i.e., the size of the shelves) and the manner in which they are to be arranged.

The boxes in each unit of shelves may be arranged in sequences which have any number of dimensions. Thus, a one-dimensional array can be thought of as a single shelf which holds, one row of boxes; a two-dimensional array can be thought of as a stack of shelves, each of which holds one row of boxes; and so forth. These boxes, or variables, are referred to as the array's elements.

The number of subscripts used to identify each of the array elements of a corresponds to the number of dimensions in that array. For example, each of the elements in a one-dimensional array is identified by a single subscript which indicates the box's position in the row; each of the elements in a two dimensional array is identified by two subscripts, one which identifies the box's row, and one which indicates the box's position within that row; and so forth. The numbers which are used as the subscripts start with zero, and have a maximum value which is determined by the size of each of the array's dimensions (i.e., the number of boxes in each row, etc.).

The maximum size of an array is limited by the amount of free space which is available in the computer's memory (i.e., by the size of the program, the number of items of data which are to be stored in the array, and so forth). The syntax of BASIC places no restrictions on the number of dimensions which can be used for any array, but in practice the number of dimensions is limited by the amount of free memory space which is available for storage of array variables.

An array must be declared before values can be stored in any of its elements.



(Example 1)

```
10 DIM A(5)..... Declares 1-dimensional numeric array A with 6 elements.
20 DIM X$(8)..... Declares 1-dimensional string array X$ with 9 elements.

10 DIM A(5), X$(8)..... Performs the same function as lines 10 and 20 above.
```

(Example 2)

```
10 DIM B(5, 5)..... Declares 2-dimensional numeric array B with 6 x 6
elements.
20 DIM Y$(5, 8)..... Declares 2-dimensional string array Y$ with 6 x 9 elements.

10 DIM B(5, 5), Y$(5, 8), A(5), X$(8)..... Declares two numeric arrays
and two string arrays.
```

(Example 3)

```
10 DIM C(3, 3, 3)..... Declares 3-dimensional array C with 4 x 4 x 4 elements.
```

Note: Different names must be used for each array which is declared; for example, the instruction DIM A(5), A(6) is not a legal array declaration.

Try executing the program shown below and check the results which are obtained.

```
10 DIM A(2), B$(2)
20 A(0)=26
30 A(1)=9
40 A(2)=-100
50 B$(0)=" ABC "
60 B$(1)=" XYZ "
70 B$(2)=" MZ-700 "
80 PRINT A(1)
90 PRINT B$(2)
100 PRINT A(2)
110 PRINT B$(0)+B$(1)
120 PRINT A(0)
```

Note: Individual variables within an array, such as A(5) and X\$(8), are referred to as an array's elements. Numeric constants, numeric variables, and numeric arrays are collectively referred to as numeric expressions, and string constants, string variables, and string arrays are collectively referred to as string expressions.

2.2.4 BASIC Operations

In BASIC, arithmetic operations take a slightly different form than is the case with ordinary arithmetic. The various arithmetic operators used in BASIC are shown in the table below. The priority of these operators when they are used together within a single expression (the sequence in which the different arithmetic operations are performed) is as indicated by the numbers in the left column of the table; however, operators within parentheses always have the highest priority.

Arithmetic operations

	Operator	Operation	Format
1	↑	Exponentiation	$X \uparrow Y$ (Indicates X^Y ; i.e., X to the Yth power.)
2	-	Negation	$-X$
3	*, /	Multiplication, division	$X * Y$ (X times Y), X/Y ($\frac{X}{Y}$; i.e., X divided by Y)
4	+, -	Plus, minus	$X + Y$ (X plus Y), $X - Y$ (X minus Y)



(Example 1)

1 Ø $A=3*8/4$When a series of operators with the same priority are used in an arithmetic expression, calculations are carried out from left to right; thus, the result of the expression at left is 6.

(Example 2)

1 Ø $A=60-6*8+2$Result is 14.

2 Ø $B=(60-6)*8+2$Result is 434.

(Example 3)

1 Ø $A=2 \uparrow 3$ Assigns 2 to the 3rd power to A; result is 8.

String operations

String operations are used to create new strings of character data by concatenating (linking) two or more shorter strings. The only operator which can be used in string operations is the “+” sign.

(Example)

PRINT "ABC"+"DEF" J → Displays the character string “ABCDEF”.

2.2.5 Initial settings

Initial settings made when BASIC 1Z-013B is started are as described below.

■ Keyboard

- 1) Operation mode: Normal (alphanumeric)
- 2) Definable function keys

F1 : "RUN" +CHR\$(13)	SHIFT + F1 : "CHR\$("
F2 : "LIST"	SHIFT + F2 : "DEF KEY ("
F3 : "AUTO"	SHIFT + F3 : "CONT "
F4 : "RENUM"	SHIFT + F4 : "SAVE "
F5 : "COLOR"	SHIFT + F5 : "LOAD "

Note A carriage return code is included in the definition of function key F1.

■ Built-in clock

The initial value set to system variable TIS is "000000".

■ Music function

- 1) Musical performance tempo: 4 (moderato, approximately medium speed)
- 2) Note duration: 5 (quarter note J)

■ Control keys and control characters

The control keys are keys which perform special functions when pressed together with the **CTRL** key. Functions of these keys and their corresponding ASCII codes are as shown in the table below.

[Control codes]

CTRL +	ASCII code (decimal)	Function
E	5	Selects the lowercase letter input mode for alphanumeric characters.
F	6	Selects the uppercase letter input mode for alphanumeric characters.
M	13	Carriage return (CR).
P	16	Same as the DEL key.
Q	17	Moves the cursor down one line (↓).
R	18	Moves the cursor up one line (↑).
S	19	Moves the cursor one column (character) to the right (→).
T	20	Moves the cursor one column (character) to the left (←).
U	21	Moves the cursor to the home position (HOME).
V	22	Clears the screen to the background color (CLR).
W	23	Places the computer in the graphic character input mode (GRAPH).
X	24	Inserts one space (INST).
Y	25	Places the computer in the alphanumeric input mode.

■ Other

The lower limit of the BASIC text area is set to address \$FEFF; this is the same as LIMIT MAX is executed).

For initial printer settings, see the discussion of the printer.

2.3 Frequently Used BASIC Commands and Statements

2.3.1 Program file input/output instructions

2.3.1.1 LOAD (abbreviated format: LO.)


Format	LOAD or LOAD "filename"
Function	This command loads the specified BASIC text file or a machine language file to be linked with a BASIC program from cassette tape.

(See pages 14 and 20.)

Only BASIC text files and machine language programs can be loaded with this command. When the file to be loaded is a BASIC text file, the current program is cleared from the BASIC text area when the new program is loaded.

Note	When loading a machine language routine to be linked with a BASIC program, the LIMIT statement must be executed to reserve a machine language program area in memory. Further, the applicable machine language program file is executed as soon as loading is completed if the loading address is inside that area. (In this case, the BASIC text is not erased.)
------	---



The LOAD command can be used within a program to load a machine language program file.



Note: The lower limit of the BASIC text area shifts according to the size the program text loaded.

2.3.1.2 SAVE (abbreviated format: SA.)

Format	SAVE or SAVE "filename"
Function	This command assigns a file name to the BASIC program in the computer's memory and saves it on cassette tape.



Note This command saves only the BASIC program text (i.e., the program text displayed by executing the LIST command); it does not save any machine language program in the machine language area.


The file name specified is recorded on tape together with the BASIC text file; specify any name desired using up to 16 characters. If no file name is specified, the program is recorded without a file name; however note that this can make file management difficult if more than one program is recorded on a single tape.

2.3.1.3 VERIFY (abbreviated format: V.)

Format
Function

VERIFY or VERIFY "filename"
 This command is used to confirm that programs have been properly recorded on tape by the SAVE command. This is done by playing the tape and comparing the program read with the program contained in memory. If both programs are the same, "OK" is displayed; if they are different, "READ error" is displayed. In the latter case, save the program again.

VERIFY



2.3.2 Text editing commands

2.3.2.1 AUTO (abbreviated format: A.)

Format	AUTO or AUTO Ls, n Ls Starting line number n Line number increment
Function	This command automatically generates program line numbers during entry of BASIC program statements.
Example	<p>(Example 1)</p> <pre>AUTO ↵ 10..... ↵ 20..... ↵ 30..... ↵</pre> <p>(Example 2)</p> <pre>AUTO 300, 5 ↵ 300..... ↵ 305..... ↵ 310..... ↵</pre> <p>Automatically generates program line numbers with an increment of 5, starting with line 300.</p> <p>(Example 3)</p> <pre>AUTO 100 ↵ 100..... ↵ 110..... ↵ 120..... ↵</pre> <p>Generates program line numbers with an increment of 10, starting with line 100.</p> <p>(Example 4)</p> <pre>AUTO, 20 ↵ 10..... ↵ 30..... ↵ 50..... ↵</pre> <p>Generates program line numbers with an increment of 20, starting with line 10.</p>

Note: The AUTO command is terminated by pressing SHIFT and BREAK.

2.3.2.2 DELETE (abbreviated format: D.)

Format	DELETE Ls-Le Deletes program lines from Ls to Le. DELETE -Le Deletes all program lines from the beginning of the program to line Le. DELETE Ls- Deletes all program lines from line Ls to the end of the program. DELETE Ls Deletes line Ls.
Example	<p>(Example 1)</p> <pre>DELETE 150-350 ↵ Deletes all program lines from 150 to 350.</pre> <p>(Example 2)</p> <pre>DELETE -100 ↵ Deletes all program lines up to line 100.</pre> <p>(Example 3)</p> <pre>DELETE 400- ↵ Deletes all program lines from 400 to the end of the program.</pre>

2.3.2.3 LIST (abbreviated format: L.)

Format	<pre>LIST LIST Ls-Le LIST Ls- LIST -Le</pre>	} Ls indicates the starting line number and Le indicates the ending line number.
--------	--	--

Function	This command lists all or part of the program lines contained in the BASIC text area on the display screen.
----------	---

```
LIST J ..... Lists the entire program.
LIST -30 J ..... Lists all lines of the program to line 30.
LIST 30-J ..... Lists all lines of the program from line 30 to the end.
LIST 30-50 J ..... Lists all lines of the program from line 30 to line 50.
LIST 30 J ..... Lists line 30 of the program.
```

Output of the program list to the display screen can be temporarily interrupted by pressing the space bar; listing is then resumed when the space bar is released. To terminate list output, press the **BREAK** key together with the **SHIFT** key.

2.3.2.4 LIST/P (abbreviated format: L/P)

Format	LIST/P <Ls-Le>
	Ls Starting line number
	Le Ending line number

Function	This command lists all or part of the program in the BASIC text area on the printer. The range of program lines to be listed is specified in the same manner as with the LIST command described above.
----------	--

Note: The angle brackets <...> in the above indicate that the enclosed item is optional.

2.3.2.5 MERGE (abbreviated format: ME.)

Format	MERGE or MERGE "filename"
--------	---

Function	The MERGE command is used to read a program from cassette tape. When a program is read using this command, it is appended to the program in memory. If "filename" is omitted, the computer reads the first file encountered on the cassette tape.
----------	---

If any line numbers in the program read are the same as those of the program in memory, corresponding lines of the program in memory are replaced with lines of the program read.

2.3.2.6 NEW

Format	NEW
--------	------------

Function	The NEW command erases the BASIC text area and clears all variables. Execute this command when you wish to clear the program in memory prior to entering another program. This command does not erase the machine language area reserved by the LIMIT statement.
----------	--

Since the BASIC text area is automatically cleared by the LOAD command, it is not necessary to execute this command before loading a BASIC program from cassette tape.

2.3.2.7 RENUM (abbreviated format: REN.)

Format	<pre> RENUM Ln New line number RENUM LnLo Old line number RENUM Ln, Lo, n n Increment </pre>
--------	--

Function	<p>This command renumbers the lines of a BASIC program. When this command is executed, line numbers referenced in branch statements such as GOTO, GOSUB, ON ~ GOTO, and ON ~ GOSUB are also reassigned.</p>
----------	---

RENUM Renumbers the lines of the current program in memory so that they start with 10 and are incremented in units of 10.

RENUM 100 Renumbers the lines of the current program in memory so that they start with 100 and incremented in units of 10.

RENUM 100, 50, 20 Renumbers lines of the current program in memory starting with line number 50; line number 50 is renumbered to 100, and subsequent line numbers are incremented in units of 20.

Example	<p>The example below shows the result of executing RENUM 100, 50, 20 for a sample program.</p>
---------	--

(Before renumbering)	}	(After renumbering)
50 A=1	→	100 A=1
60 A=A+1		120 A=A+1
70 PRINT A		140 PRINT A
100 GOTO 60		160 GOTO 120

Note	<p>When specifying the new and old line numbers, the new line number specified must be larger than the old line number. Note that an error will result if execution of this command results in generation of a line number which is greater than 65535.</p>
------	---

2.3.3 Control commands

2.3.3.1 RUN (abbreviated format: R.)

Format

RUN or RUN Ls

Ls Starting line number

Function

This command executes the current program in the BASIC text area.

If the program is to be executed starting with the first program line, just enter RUN and press the **CR** key. If execution is to begin with a line other than that the lowest line number, type in RUN Ls (where Ls is the line number at which execution is to start) and press the **CR** key.

When this command is executed, the BASIC interpreter clears all variables and arrays before passing control to the BASIC program.

2.3.3.2 CONT (abbreviated format: C.)

Format

CONT

Function

The CONT command is used to resume execution of a program which has been interrupted by pressing **SHIFT** + **BREAK** or by a STOP statement in the program. This command can also be used to continue execution of a program which has been interrupted by an END statement; however, in this case care must be taken to ensure that lines following the END statement are not the lines of a subroutine. Examples of situations in which the CONT command can and cannot be used are shown in the table below.

Program continuation possible	Program continuation not possible
<ul style="list-style-type: none"> • Program execution stopped by pressing SHIFT + BREAK. • Program execution stopped by a STOP command. • Program execution stopped by pressing SHIFT + BREAK while the program was a waiting input for an INPUT statement. 	<ul style="list-style-type: none"> • Before a RUN command has been executed. • "READY" displayed due to an error occurring during program execution. • Cassette tape operation interrupted by pressing SHIFT + BREAK. • Program execution stopped during execution of a MUSIC statement. • Program execution stopped and "READY" displayed after execution of an END statement.

2.3.3.3 BYE (abbreviated format: B.)


Format
Function

BYE

This command returns control of the computer from BASIC interpreter 1Z-013B to the monitor program in RAM. (The monitor commands are explained starting on page 99.)

... Numeric expression (consisting of one or more constants, variables, or array elements) or string expression (consisting of one or more constants, variables, or array elements)
 This statement assigns the value (numeric or string) specified by v to the variable or array element specified by v. As shown in the examples below, LET may be omitted.

Function



2.3.3.4 KEY LIST (abbreviated format: K. L.)

Format
Function

KEY LIST

This command displays a list of the character strings assigned to the definable functions keys.

```

KEY LIST
DEF KEY (1) = "RUN" + CHR$(13)
DEF KEY (2) = "LIST"
DEF KEY (3) = "AUTO"
DEF KEY (4) = "RENUM"
DEF KEY (5) = "COLOR"
DEF KEY (6) = "CHR$( "
DEF KEY (7) = "DEF KEY ( "
DEF KEY (8) = "CONT "
DEF KEY (9) = "SAVE "
DEF KEY (10) = "LOAD "
READY
    
```

Example

The following are examples of incorrect use of the LET statement:
 20 A=A+B...Invalid because different types of variables (string and numeric) are specified on either sides of the "=" sign.
 20 LOG(LK) = LK+1...Invalid because the left side of the statement is not a numeric variable or array element.

2.3.4 Assignment statement

LET

Format


LET $v = e$ or $v = e$

$v \dots$ Numeric variable or array element, or string variable or array element.

$e \dots$ Numeric expression (consisting of one or more constants, variables, or array elements) or string expression (consisting of one or more constants, variables, or array elements).

Function

This statement assigns the value (numeric or string) specified by e to the variable or array element specified by v . As shown in the examples below, LET may be omitted.



Example

```
10 A=10
20 B=20
30 A=A+B
40 PRINT A
50 END
```

```
10 LET A=10
20 LET B=20
30 LET A=A+B
40 PRINT A
50 END
```

RUN ↓

30

.....The two programs above produce exactly the same result.

The following are examples of incorrect use of the LET statement.

20 A\$=A+B.....Invalid because different types of variables (string and numeric) are specified on either sides of the “=” sign.

20 LOG (LK) =LK+1.....Invalid because the left side of the statement is not an numeric variable or array element.

2.3.5 Input/output statements

Input/output statements are the means by which data is submitted to the computer for processing, and by which the results of processing are output to the TV screen or printer.

2.3.5.1 PRINT

Format	$\left\{ \begin{array}{l} \text{PRINT} \\ ? \end{array} \right\} \left\{ \begin{array}{l} \text{variable} \\ \text{constant} \\ \text{expression} \end{array} \right\} \langle \{ ; \} \{ , \} \rangle \left\{ \begin{array}{l} \text{variable} \\ \text{constant} \\ \text{expression} \end{array} \right\} \dots \rangle$
--------	---

Function This statement outputs the values of variables, constants, character strings, or expressions to the display screen. Values are displayed starting at the cursor's current location on the screen. (To move the cursor down one line on the screen, execute the PRINT statement without specifying any variables, constants, or expressions.)

To simplify key input when entering this statement, a question mark (?) may be typed instead of the word PRINT.

Numeric data is displayed by this statement in one of two formats: real number format or exponential format.

Real number format

Numeric values in the range from 1×10^{-8} to 1×10^8 are displayed in real number format.

```

-1.9999
63598757
0.00000001 ..... 1 x 10-8
99999999
    
```

Exponential format







Numbers which cannot be displayed in real number format are displayed in exponential format.

```

-.31415E+9 ..... -0.31415 x 109
.513606E-20 ..... 0.513606 x 10-20
    
```

A plus (+) or minus (-) sign is always displayed ahead of the exponent (the number following "E") of a number displayed in exponential format.

Some special methods of using the PRINT statement are shown below.

- PRINT "  " Clears the entire screen and moves the cursor to the home position (the upper left corner of the screen).
- PRINT "  " Moves the cursor to the home position without clearing the screen.
- PRINT "  " Moves the cursor one column to the right.
- PRINT "  " Moves the cursor one column to the left.
- PRINT "  " Moves the cursor up one line.
- PRINT "  " Moves the cursor down one line.

PRINT "C↓↓↓↓↓A" Clears the screen, then displays the character "A" at the beginning of the sixth line from the top.

Note: The vertical bars |...| in the format description indicate that any one of the enclosed items may be selected.

To enter the special characters for cursor control, press the **GRAPH** key; this places BASIC in the graphic character input mode and changes the form of the cursor to "█". Next, enter the characters as follows.

- █..... Press the **CLR** key.
- █..... Press the **HOME** key.
- █..... Press the **←** key.
- █..... Press the **→** key.
- █..... Press the **↑** key.
- █..... Press the **↓** key.



After entering a special character, press the **ALPHA** key to return from the graphic character input mode to the alphanumeric input mode.

2. 3. 5. 2 PRINT USING (abbreviated format: ?USI.)

Format PRINT USING "format string"; variable < { ; } variable ... >

Function This statement displays data on the screen in a specific format. The format specification consists of a character or string of characters in quotation marks, and is specified immediately after the word USING as follows.

(1) Format specification strings for numeric values

(a) #

The number sign is used to specify the maximum number of digits to be displayed. If the number of digits in the number displayed is smaller than the number of # signs specified in "format string", numbers are right-justified in the field defined by that string.

(Example:)

10 A = 123

20 PRINT USING "####"; A

RUN ↵

 123

(b) .

A period may be included in a format string consisting of # signs to specify the position in which the decimal point is to be displayed. The number of # signs to the right of the decimal point specifies the number of decimal places to be displayed.

(Example:)

```
10 A = 12.345 : B = 6.789
20 PRINT USING "###.##" ; A
30 PRINT USING "###.##" ; B
RUN
```

12.34

6.79

(c) ,

Commas may also be included in "format string" to indicate positions in which commas are to be displayed. Numbers are right-justified in the same manner as when # signs are used alone.

(Example:)

```
10 A = 6345123 : B = 987324
20 PRINT USING "#,###,###" ; A
30 PRINT USING "#,###,###" ; B
RUN
```

6,345,123

987,324

(d) + and -

A plus (+) or minus (-) sign may be included at the end of "format string" to specify that the sign of the number is to be displayed in that position instead of a space. For instance, PRINT USING "#####+" will cause the sign to be displayed immediately after the number. (PRINT USING "#####-" causes a minus sign to be displayed following the number if the number is negative; if the number is positive, only a space is displayed in that position.) Further, a plus sign may be specified at the beginning of a format string to indicate that the number's sign is to be displayed in that position regardless of whether it is positive or negative.

(Examples)

```
PRINT USING "#####+" ; -13
```

13-

```
PRINT USING "+#####" ; 25
```

+25

(Note:)

Although a minus sign will be displayed if one is specified at the beginning of the format string, it will have no relationship to the sign of the number.

(e) **

Specifying a pair of asterisks at the beginning of the format string indicates that asterisks are to be displayed in the positions of leading zeros.

(Example:)

```
10 A = 1234
```

```
20 PRINT USING " **####" ; A
```

```
RUN J
```

```
**1234
```

(f) ££

Specifying a pair of pound signs at the beginning of the format string indicates that a pound sign is to be displayed in the position immediately to the left of the number.

(Example:)

```
10 A = 123
```

```
20 PRINT USING " ££####" ; A
```

```
RUN J
```

```
££123
```

(g) \$\$

Specifying a pair of dollar signs at the beginning of the format string indicates that a dollar sign is to be displayed in the position immediately to the left of the number.

(h) ↑↑↑↑

Four exponential operators may be included at the end of a format string to control display of numbers in exponential format.

(Example:)

```
10 A = 51123
```

```
20 PRINT USING "###.### ↑↑↑↑" ; A
```

```
RUN J
```

```
5.112E+04
```

In this case, the first number sign is reserved for display of the sign of the number.

(i) Extended list of operands

A list of variables may be specified following a single PRINT USING statement by separating them from each others with commas or semicolons. When this is done, the format specified in "format string" is used for display of all resulting values.

(Example:)

```
10 A = 5.3 : B = 6.9 : C = 7.123
```

```
20 PRINT USING "###.###" ; A, B, C
```

```
RUN J
```

```
5.300 6.900 7.123
```

(2) Format specification for string values

(a) !

When the values being displayed are character strings, specifying an exclamation mark in "format string" causes just the first character of the string specified to be displayed.

(Example:)

```
10 A$ = "CDE"  
20 PRINT USING "!" ; A$  
RUN  
C
```

(b) & _ _ _ _ &

Specifying "& _ _ _ _ &" in the format string causes the first 2 + n characters of specified string expressions to be displayed (where n is the number of spaces between the two ampersands). If fewer than 2 + n characters are specified in a string expression, characters displayed are left-justified in the field defined by "& _ _ _ _ &".

(Examples:)

```
10 A$ = "ABCDEFGH"  
20 PRINT USING "& _ _ _ _ &" ; A$  
RUN  
ABCDEF  
10 A$ = "XY"  
20 PRINT USING "& _ _ _ _ &" ; A$  
RUN  
XY
```

(3) String constant output function

When any character other than those described above is included in the format string of a PRINT USING statement, that character is displayed together with the value specified following the semicolon.

(Example:)

```
10 A = 123  
20 PRINT USING "DATA####" ; A  
RUN  
DATA_123
```

(4) Separation of USING

Usually, PRINT and USING are specified adjacent to each other; however, it is possible to use them separately within the same statement.

(Example:)

```
10 A = -12 : B = 14 : C = 12  
20 PRINT A;B;USING "####" ; C  
          Normal PRINT function    USING function  
RUN  
-12_14__12
```

2.3.5.3 INPUT (abbreviated format: I.)

Format	$\text{INPUT} \left\{ \begin{array}{l} \text{numeric variable} \\ \text{string variable} \\ \text{array element} \end{array} \right\} \dots \text{ or } \text{INPUT} \text{ "character string" ; } \left\{ \begin{array}{l} \text{numeric variable} \\ \text{string variable} \\ \text{array element} \end{array} \right\} \dots$
--------	---

INPUT A	INPUT "DATA A=" ; A
INPUT B\$	INPUT "YES OR NO " ; B\$
INPUT X(5)	INPUT "KEY IN " ; X (5)

Function	<p>INPUT is one of the statements which is used for entering values for assignment to variables during program execution. Program execution pauses when an INPUT statement is encountered to allow values to be typed in from the keyboard. After input has been completed, the values are substituted into specified variables by pressing the CR key, then program execution resumes.</p>
----------	--

(Example:)

```

10 INPUT A, B
20 C=A+B
30 PRINT C
40 END
    
```

When the program above is executed, a question mark is displayed and the cursor blinks to indicate that the computer is waiting for data input; enter any arbitrary number, then press the **CR** key. This assigns the value entered to variable A.

After doing this, the question mark will be displayed again. The reason for this is that two variables (A and B) are specified in the INPUT statement on line 10, but only one value has been entered (that which is substituted into variable A). Enter another arbitrary number and press the **CR** key again; this substitutes the second value entered into variable B and causes execution to go on to the next line of the program. In the example above, subsequent lines add the values of A and B, substitute the result into C, then display the contents of C.

Since the variables used in this example are numeric variables, the computer will display the message **ILLEGAL DATA ERROR** if an attempt is made to enter any characters other than numerics. The question mark is then redisplayed to prompt the user to reenter a legal value (a value whose type is the same as that of the variable or array element into which it is to be substituted). Be sure to enter data whose type matches that of the variable(s) specified in the INPUT statement.

During program execution, it may be difficult to remember what data is to be entered when the question mark is displayed; therefore, prompt strings are usually included in INPUT statements for display on the screen as a reminder. This is done as shown in the program example below.

```

10 INPUT "A=" ; A
20 INPUT "B=" ; B
30 PRINT "A+B=" ; A+B
40 PRINT "A-B=" ; A-B
50 PRINT "AxB=" ; AxB
60 PRINT "A/B=" ; A/B
70 END
    
```

Try running the program shown above. Inclusion of character strings in the PRINT and INPUT statements provides a clear indication of the program's operation. Practical computer programs consist of combinations of sequences similar to the one shown here. By combining commands, statements, and sequences in different manners, you will soon find that there are many different methods of achieving a desired result.

2.3.5.4 GET

Format

GET v

v Numeric variable or array element, or string variable or array element.

Function

When this statement is encountered during program execution, the BASIC interpreter checks whether any key on the keyboard is being pressed and, if so, assigns the corresponding value to the variable specified in v. Whereas the INPUT statement prompts for entry of data and waits until that data has been entered before resuming execution, the GET statement continues execution regardless of whether any key is being pressed.

Although data is substituted into variable v by the GET statement if any keys are pressed when the statement is executed, the variable will be left empty (0 for a numeric variable or null for a string variable) if no keys are pressed.

With numeric variables, this statement allows a single digit (from 0 to 9) to be entered; with string variables, it allows a single character to be entered.

This statement can be extremely useful when you want to enter data without pressing the **CR** key, as is often the case with game programs.

(Example:)

```
10 PRINT "NEXT GO? (Y OR N) "
```

```
20 GET A$
```

```
30 IF A$="Y" THEN 50
```

..... In the example above, execution jumps from line 30 to line 50 if the value of variable A\$ is "Y".

```
40 GOTO 20
```

..... Line 40 unconditionally transfers execution to line 20.

```
50 PRINT "PROGRAM END "
```

```
60 END
```

This program displays the prompt "NEXT GO? (Y OR N)" and waits for input. When the Y key is pressed, execution moves to line 50 and the program ends. Until that time, however, execution loops repeatedly between lines 20 and 40. Now delete lines 30 and 40 and try executing the program again. As you can see, execution is completed immediately regardless of whether any keys have been pressed.

Note: When GET statements are executed in succession, a routine should be included between them to ensure that each is completed before going on to the next. The reason for this is that key chatter (vibration of the contacts of the key switches) may result in two GET statements being executed simultaneously.

2.3.5.5 READ ~ DATA (abbreviated format: REA. ~ DA.)

Format	<pre> READ { numeric variable } < { numeric variable } > { string variable } , { string variable } , { array element } , { array element } DATA { numeric constant } < { numeric constant } > { string constant } , { string constant } , </pre>
--------	--

Function Like the INPUT and GET statements, the READ statement is used to submit data to the computer for processing. However, unlike the INPUT and GET statements, data is not entered from the keyboard, but is stored in the program itself in DATA statements. More specifically, the function of the READ statement is to read successive items of data into variables from a list of values which follows a DATA statement. When doing this, there must be a one-to-one correspondence between the variables of the READ statements and the data items specified in the DATA statements.

Example

```

(Example 1)
10 READ A, B, C, D
20 PRINT A;B;C;D
30 END
40 DATA 10, 100, 50, 60
RUN J
    
```

10 100 50 60 In this example, values specified in the DATA statement are read into variables A, B, C, and D by the READ statement, then the values of those variable are displayed.

```

(Example 2)
10 READ X$, A1, Z$
20 PRINT X$;A1;Z$
30 END
40 DATA A, 1, C
    
```

RUN J
A_1C As shown by the example below, string data included in DATA statements does not need to be enclosed in quotation marks.
The READ statement in this example picks successive data items from the list specified in the DATA statement, then substitutes each item into the corresponding variable in the list following the READ statement.

(Example 3)

```

10 DIM A (2)
20 READ A (0), A (1), A (2)
30 PRINT A (0); A (1); A (2)
40 END
50 DATA 3, 4, 5
RUN
3 4 5

```

The READ statement in this program substitutes the numeric values following the DATA statement into array elements A(0), A(1), and A(2), then the PRINT statement on line 30 displays the values of those array elements.

(Example 4)

```

10 READ A
20 READ B
30 DATA X

```

The example above is incorrect because (1) a numeric variable is specified by the READ statement on line 10, but the value specified following the DATA statement is a string value, and (2) there is no data which can be read by the READ statement on line 20.

This function creates random numbers (see page 12)

```

10 X=33*RN(1)
20 FOR A=1 TO 5
30 READ M$
40 PRINT TAB(0); M$
50 PRINT TAB(37);
60 NEXT A
70 Y=10*RN(1)
80 FOR A=1 TO Y
90 PRINT TAB(0);
100 PRINT TAB(37);
110 RESTORE:GOTO 10
120 DATA
130 DATA
140 DATA

```

Note: See page 63 for the TAB function and page 47 for the FOR...NEXT statement

2.3.5.6 RESTORE (abbreviated format: ... RES.)

Format
Function

RESTORE or RESTORE Ln

When READ statements are executed, a pointer managed by the BASIC interpreter is incremented to keep track of the next item of data to be read from DATA statements. The RESTORE statement resets this pointer to (1) the beginning of the first DATA statement in the program or (2) the beginning of the DATA statement on a specified line.

Example

```

10 DATA 1, 2, 3
20 DATA "AA", "BB"
30 READ X, Y
40 READ Z, V$
.....
100 RESTORE
110 READ A, B, C, D$, E$
.....
200 READ I, J
210 RESTORE
220 READ M, N
230 RESTORE 260
240 READ O, P
250 DATA 1, 2, 3, 4
260 DATA -1, -2, -3, -4
    
```

An error will result if the number specified in Ln is the number of non-existent line.

```

10 X=33*RND(1)
20 FOR A=1 TO 5
30 READ M$
40 PRINT TAB(0); "◆"; TAB(X); M$;
50 PRINT TAB(37); "◆"
60 NEXT A
70 Y=10*RND(1)
80 FOR A=1 TO Y
90 PRINT TAB(0); "◆";
100 PRINT TAB(37); "◆":NEXT
110 RESTORE:GOTO 10
120 DATA " ▲●▲", " ●●●●●●"
130 DATA " ●●●●", " ●●●●●●"
140 DATA " ▲▲▲"
    
```

← This function creates random numbers (see page 72).

Note: See page 62 for the TAB function and page 47 for the FOR ... NEXT statement.

2.3.6 Loop and branch instructions

2.3.6.1 FOR ~ NEXT (abbreviated format: F. ~ N.)

Format **FOR** cv = iv **TO** fv **<STEP** sv **>**

.....
NEXT <cv >

cv Control variable; a numeric variable or array element.

iv Initial value; a numeric expression.

fv Final value; a numeric expression.

sv Increment, or step value; a numeric expression (if omitted, 1 is assumed).


Function This statement repeats the instructions between FOR and NEXT a certain number of times.

```
10 A=0
20 FOR N=0 TO 10 STEP 2
30 A=A+1
40 PRINT "N=" ; N,
50 PRINT "A=" ; A
60 NEXT N
```

- (1) In the program above, 0 is assigned to N as the initial value.
- (2) Next, lines 20 through 50 are executed and the values of variables A and N displayed.
- (3) In line 60, the value of N is increased by 2, after which the BASIC interpreter checks to see whether N is greater than 10, the final value. If not, lines following line 20 are repeated.

When the value of N exceeds 10, execution leaves the loop and subsequent instructions (on lines following line 60) are executed. The program above repeats the loop 6 times.

If <STEP sv > is omitted from the statement specification, the value of N is increased by 1 each time the loop is repeated. In the case of the program above, omitting <STEP sv > in this manner would result in 11 repetitions of the loop.



FOR . . . NEXT loops may be nested within other FOR . . . NEXT loops. When doing this, inner loops must be completely included within outer ones. Further, separate control variables must be used for each loop.

Example

```

10 FOR X=1 TO 9
20 FOR Y=1 TO 9
30 PRINT X*Y;
40 NEXT Y
50 PRINT
60 NEXT X
70 END

```

Inner loop
Outer loop

```

FOR A=1 TO 3
FOR B=1 TO 5
FOR C=1 TO 7
.....
NEXT C
NEXT B
NEXT A

```

NEXT
C, B, A

When loops C, B, and A all end at the same point as in the example above, one NEXT statement may be used to indicate the end of all the loops.

Incorrect example:

```

FOR J=1 TO 10
FOR J=K TO K+5
NEXT J

```

```

FOR I=1 TO 10
FOR J=K TO K+5
NEXT I
NEXT J

```

× Different control variables must be used in each loop.

× Loops may not cross one another.

Note

The syntax of BASIC does not limit the number of levels to which loops may be nested; however, space is required to store return addresses for each level, so the number of levels is limited by the amount of available free space.

The CLR statement (see page 59) cannot be used within a FOR . . . NEXT loop.

2. 3. 6. 2 GOTO (abbreviated format: . . . G.)

Format

GOTO Ln
Ln Destination line number

Function

This statement unconditionally transfers program execution to the line number specified in Ln. If Ln is the number of a line which contains executable statements (statements other than REM or DATA statements), execution resumes with that line; otherwise, execution resumes with the first executable statement following line number Ln.

Example


```

10 N=1
20 PRINT N
30 N=N+1
40 GOTO 20
50 END

```

.....Transfers program execution to line 20.

Since execution of the program shown above will continue indefinitely, stop it by pressing the **SHIFT** and **BREAK** keys together (this may be done at any time to stop execution of a BASIC program). To resume execution, execute the **CONT** command.



Note

The line number specified in a GOTO statement may not be that of a line included within a FOR . . . NEXT loop.

2.3.6.3 GOSUB ~ RETURN (abbreviated format: GOS. ~ RET.)

Format

GOSUB Ln

⋮

RETURN

Ln . . . Destination line number

Function

The GOSUB statement unconditionally transfers program execution to a BASIC subroutine beginning at the line number specified in Ln; after execution of the subroutine has been completed, execution is returned to the statement following GOSUB when a RETURN statement is executed.

GOSUB ~ RETURN statements are frequently used when the same processing is required at several different points in a program. In such cases, a subroutine which performs this processing is included at some point in the program, and execution is branched to this subroutine at appropriate points by means of the GOSUB statement. After the required processing has been completed, execution is returned to the main routine by the RETURN statement.

Example

```

100 X=10
110 GOSUB 200
120 PRINT X
130 END
200 X=X*2
210 RETURN
  
```


Note

The syntax of BASIC imposes no limit on the extent to which subroutines can be nested (that is, on the number of levels of subroutine calls which can be made from other subroutines); however, in practice a limitation is imposed by the amount of free space in memory which is available for storing return addresses.

```

10 B=5
20 C=8
30 GOSUB 100
40 PRINT A
50 B=2
60 C=10
70 GOSUB 100
80 PRINT A
90 END
100 A=B+C
110 RETURN

```



2. 3. 6. 4 IF ~ THEN (abbreviated format: ... **IF ~ TH.**)

Format

IF e THEN Ln
IF e THEN statement


e: A relational expression or logical expression

Ln: Destination line number

Function

IF ... THEN statements are used to control branching of program execution according to the result of a logical or relational expression. When the result of such an expression is true, statements following THEN are executed. If a line number is specified following THEN, program execution jumps to that line of the program if the result of the expression is true.


If the result of the logical or relational expression is false, execution continues with the program line following that containing the IF ... THEN statement.



Example

```

IF.....THEN 100
IF.....THEN GOTO or IF.....GOTO
IF.....THEN PRINT or IF.....THEN ?
IF.....THEN A=5*7 assignment
IF.....THEN I=10:J=50
IF.....THEN INPUT
IF.....THEN READ
IF.....THEN GOSUB
IF.....THEN RETURN
IF.....THEN STOP
IF.....THEN END
    
```



Examples of logical and relational expressions

	Operator	Sample application	Explanation
Relational expressions	=	IF A=X THEN...	If the value of numeric variable A equals the value of X, execute the statements following THEN.
		IF A\$="XYZ" THEN...	If the contents of string variable A\$ equal "XYZ", execute the statements following THEN.
	>	IF A>X THEN...	If the value of variable A is greater than X, execute the statements following THEN.
	<	IF A<X THEN...	If the value of variable A is less than X, execute the statements following THEN.
	<> or >>	IF A<>X THEN...	If the value of variable A is not equal to X, execute the statements following THEN.
	>= or =>	IF A>=X THEN...	If the value of variable A is greater than or equal to X, execute the statements following THEN.
Logical expressions	*	IF(A>X)*(B>Y) THEN...	If the value of variable A is greater than X and the value of variable B is greater than Y, execute the statements following THEN.
	+	IF(A>X)+(B>Y) THEN...	If the value of variable A is greater than X or the value of variable B is greater than Y, execute the statements following THEN.

Note

Precautions on comparison of numeric values with BASIC 1Z-013B, numeric values are internally represented in binary floating point representation; since such values must be converted to other forms for processing or external display (such as in decimal format with the PRINT statement), a certain amount of conversion error can occur.

For example, when an arithmetic expression is evaluated whose mathematical result is an integer, an integer value may not be returned upon completion of the operation if values other than integers are handled while calculations are being made. Be especially sure to take this into consideration when evaluating relational expressions using “=”.

This need is illustrated by the sample program below, which returns FALSE after testing for equality between 1 and 1/100 * 100.

```

10 A=1/100*100
20 IF A=1 THEN PRINT "TRUE":GOTO 40
30 PRINT "FALSE"
40 PRINT "A=";A
50 END

RUN
FALSE
A=1

```

The fact that both “FALSE” and “ A = 1” are displayed as the result of this program shows that external representation of numbers may differ from the number’s internal representation.

Therefore, a better method of checking for equality in the program example above is as follows.

```

20 IF ABS(A-1) < .1E-8 THEN PRINT "TRUE":
GOTO 40

```

2.3.6.5 IF ~ GOTO (abbreviated format: IF ~ G.)

Format

IF e GOTO Lr

e: Relational expression or logical expression

Lr: Destination line number

Function

This statement sequence evaluates the condition defined by relational or logical expression e, then branches to the line number specified in Lr if the condition is satisfied. As with the IF . . . THEN sequence, IF ~ GOTO is used for conditional branching; when the specified condition is satisfied, program execution jumps to the line number specified in Lr. If the condition is not satisfied, execution continues with the next line of the program. (Any statements following IF ~ GOTO on the same program line will be ignored.)

Example

```
10 G=0:N=0
20 INPUT "GRADE=" ; X
30 IF X=999 GOTO 100
40 T=T+X:N=N+1
50 GOTO 20
100 PRINT "-----"
110 PRINT "TOTAL:" ; T
120 PRINT "NO. PEOPLE:" ; N
130 PRINT "AVERAGE:" ; T/N
140 END
```

2.3.6.6 IF ~ GOSUB (abbreviated format: IF ~ GOS.)

Format

IF e GOSUB Lr

e: Relational expression or logical expression

Lr: Destination line number

Function

This statement evaluates the condition defined by relational or logical expression e, then, if the condition is satisfied, branches to the subroutine beginning on the line number specified in Lr. Upon completion of the subroutine, execution returns to the first executable statement following the calling IF ~ GOSUB statement; therefore, if multiple statements are included on the line with the IF ~ GOSUB statement, execution returns to the first statement following IF ~ GOSUB.

Example

```
10 INPUT " X=" ; X
20 IF X<0 GOSUB 100:PRINT "X<0"
30 IF X=0 GOSUB 200:PRINT "X=0"
40 IF X>0 GOSUB 300:PRINT "X>0"
50 PRINT "-----"
60 GOTO 10
100 PRINT " * PROGRAM LINE 100 " :RETURN
200 PRINT " * PROGRAM LINE 200 " :RETURN
300 PRINT " * PROGRAM LINE 300 " :RETURN
```


2.3.6.7 ON~GOTO (abbreviated format: ON~G.)

Format

ON e GOTO Lr₁ <, Lr₂, Lr₃,, Lr_i >
 e . . . Numeric variable, array element, or expression
 Lr_i . List of destination line numbers

Function

This statement branches execution to one of the line numbers following GOTO, depending on the value of e.
 The value of e indicates which of the line numbers following GOTO is to be used for making the branch; in other words, if e is 1, execution branches to the first line number in the list; if e is 2, execution branches to the second line number in the list; and so forth. For example:



Example

```

10 INPUT "NUMBER " ; A
20 ON A GOTO 50, 60, 70
50 PRINT "XXX " : GOTO 10
60 PRINT "YYY " : GOTO 10
70 PRINT "ZZZ " : GOTO 10
    
```

```

RUN
NUMBER ? 1
XXX
NUMBER ? 2
YYY
NUMBER ? 3
    
```

If a decimal number such as 1.2 is specified, the decimal portion is truncated before evaluating the statement.

Note

When the value of e in an ON~GOTO statement is greater than the number of line numbers specified following GOTO, execution continues with the next line of the program.
 This also applies if the value of e is less than 1 or negative.
 Further, if the value of e is a non-integer, the decimal portion is truncated to obtain an integer value before the statement is evaluated.

2.3.6.8 ON~GOSUB (abbreviated format: ON~GOS.)

Format ON e GOSUB Lr₁ <, Lr₂, Lr₃, , Lri >
 e . . . Numeric variable, array element, or expression
 Lri . Destination line numbers

Function This statement branches execution to the subroutine beginning on one of the line numbers following GOSUB, depending on the value of e. Operation of this statement is basically the same as with the ON~GOTO statement, but all branches are made to subroutines. Upon return from the subroutine, execution resumes with the first executable statement following the ON~GOSUB statement which made the call.

Example Let's try using the ON~GOSUB statement in a scheduling program. The most important point to note in the following program is that, a subroutine call is made at line 180, even though line 180 itself is part of a subroutine (from line 170 to 190) which is called by line 90. Subroutines can be nested to many levels in this manner.

```

10 A$=" ENGL " : B$=" MATH " : C$=" FREN "
20 D$=" SCI " : E$=" MUS " : F$=" GYM "
30 G$=" HIST " : H$=" ART " : I$=" GEOG "
40 J$=" BUS " : K$=" H RM " : PRINT "■"
50 INPUT "WHAT DAY?"; X$
60 FOR Z=1 TO 7: Y$=MID$("SUNMONTUEWEDTHU
FRISAT", 1+3*(Z-1), 3) : IF Y$=X$ THEN X=Z
70 NEXT Z
80 FOR Y=0 TO 4: PRINT TAB(5+6*Y); Y+1;
90 NEXT Y: PRINT
100 ON X GOSUB 180, 120, 130, 140, 150, 160, 170
110 PRINT: GOTO 50
120 PRINT "MON " ; A$; B$; D$; G$; K$: RETURN
130 PRINT "TUE " ; B$; E$; H$; H$; D$: RETURN
140 PRINT "WED " ; C$; C$; I$; A$; F$: RETURN
150 PRINT "THU " ; B$; D$; F$; G$; E$: RETURN
160 PRINT "FRI " ; A$; D$; I$; C$; C$: RETURN
170 PRINT "SAT " ; B$; G$; D$; K$: RETURN
180 FOR Y=1 TO 6
190 ON Y GOSUB 120, 130, 140, 150, 160, 170
200 PRINT: NEXT Y
210 RETURN
  
```

2.3.7 Definition statements

2.3.7.1 DIM

Format

```
DIM a1 (i1) <, a2 (i2), ..... ai (im) >  
DIM b1 (i1, j1) <, b2 (i2, j2), ..... bi (in, jn) >  
ai ..... 1-dimensional array name (list)  
bi ..... 2-dimensional array name (table)  
im, in, jn ..... Dimensions
```

Function

This statement is used to declare (define) arrays with from one to four dimensions and to reserve space in memory for the number of dimensions declared (DIM: dimension). Up to two characters can be specified as the array name, and subscripts of any value may be specified to define the size of dimensions; however, the number of dimensions which can be used is limited in practice by the amount of free memory available.

Example

(Examples:)

```
10 DIM A (100)  
20 FOR J=0 TO 100  
30 READ A (J)  
40 NEXT J  
50 DATA 5, 30, 12, .....
```

(Examples:)

```
10 DIM A$ (1), B$ (1), C$ (1)  
20 FOR J=0 TO 1 : READ A$ (J), B$ (J)  
30 C$ (J) = A$ (J) + " " + B$ (J)  
40 PRINT A$ (J), B$ (J), C$ (J)  
50 NEXT J  
60 END  
70 DATA YOUNG, GIRL, WHITE, ROSE
```

Note

Execution of the DIM statement sets the values of all elements of declared arrays to 0 (for numeric arrays) or null (for string arrays). Therefore, this statement should be executed before values are assigned to arrays.

Different names must be used for each array which is declared; for example, the instruction DIM A(5), A(6) is not a legal array declaration.

All array declarations are nullified by execution of a CLR statement (see page 59) and a NEW statement (see page 32).

2.3.7.2 DEF FN

Format

```
DEF FN f (x) = e  
f ... Name assigned to the function being defined (one uppercase letter from A to Z)  
x ... Argument (variable name)  
e ... Numeric expression (constant, variable, array element, or function) or previously defined user function
```

Function

The DEF FN statement is used to define user function FN f (x). Such functions consist of combinations of functions which are intrinsic to BASIC.

Example

DEF FNA (X) =2*X↑2+3*X+1 Defines $2X^2 + 3X + 1$ as FNA (X).

DEF FNE (V) =1/2*M*V↑2 Defines $1/2MV^2$ as FNE (V).

1Ø DEF FNB (X) =TAN (X-PAI (1) /6)

2Ø DEF FND (X) =FNB (X)/ C+X Defines function FNB using the function defined on line 10.

(Incorrect definitions)

1Ø DEF FNK (X)=SIN (X/3+PAI(1)/4), FNL (X)=EXP(-X↑2/K)

..... Only one user function can be defined by a single DEF FN statement.

Find the kinetic energy of a mass of 5.5 when it is imparted with initial accelerations of 3.5, 3.5×2 , and 3.5×3 .

1Ø DEF FNE (V) =1/2*M*V↑2

2Ø M=5.5 : V=3.5

3Ø PRINT FNE (V) , FNE (V*2) , FNE (V*3)

4Ø END

Note

All user function definitions are cleared when the CLR statement and the NEW statement is executed.

2. 3. 7. 3 DEF KEY

Format

DEF KEY (k) = S\$

k Definable function key number (1 to 10)

S\$ Character string (up to 15 characters).

Function

Character strings can be assigned to any of the ten function keys to allow strings to be entered at any time just by pressing a single key. This statement is used to define such strings and assign them to the definable function keys. Function key numbers 1 to 5 are entered just by pressing the corresponding key at the top left corner of the keyboard; keys 6 to 10 are entered by pressing the **SHIFT** key together with the corresponding key. The function key number (1 to 10) is specified in k, and the string or command which is to be assigned to the key is specified exactly as it is to be entered in S\$. Execution of the DEF KEY statement cancels the previous definition of the definable function key.

No other statement can be specified after a DEF KEY statement on the same line.

(Example:)

1Ø DEF KEY (1) = " INPUT " Defines key **F1** as INPUT

2Ø DEF KEY (2) = " RUN " +CHR\$(13) ... Defines **F2** as RUN **J**

Note: CHR\$ (13) indicates the ASCII code for **CR**, and specifying it together with the string assigned to a definable function key has the same effect as pressing the **CR** key. (See the description of the CHR\$ function on page 78 and the ASCII code table on page 154.)

2.3.8 Remark statement and control commands

2.3.8.1 REM

Format**REM r**

r Programmer's remark

Function

REM is a non-executable statement which is specified in a program line to cause the BASIC interpreter to ignore the remainder of that line. Since REM statements are non-executable, they may be included at any point in the program without affecting the results of execution. REM statements are generally used to make a program easier to read, or to add explanatory notes to a program.

Multiple statement program lines

When more than one statement is included on a single program line, each statement must be separated from the one preceding it by a colon (:). Operation of the BASIC interpreter is generally the same in such cases as when the same statements are specified on different lines. For example, the two programs below produce exactly the same result.

```
10 A=5
20 B=8
30 C=A*B
40 PRINT C
```

→

```
10 A=5:B=8:C=A*B:PRINT C
```

Note: Also note that program operation may differ when multiple statement lines are used as shown below.

```
10 INPUT A
20 B=0
30 IF 99<A THEN B=1
40 PRINT B
50 END
```

This program displays 1 if the value entered at line 10 is greater than or equal to 100, and 0 if the value entered is less than 100.

```
10 INPUT A:B=0:IF 99<A THEN B=1:PRINT B
20 END
```

This program displays 1 if the value entered is greater than or equal to 100, but nothing at all if the value entered is less than 100. The reason for this is that statements following THEN on line 10 are not executed if the IF condition is not satisfied.

2.3.8.2 STOP (abbreviated format: S.)

Format
Function

STOP

Temporarily stops program execution, displays BREAK and READY, then waits for entry of executable commands in the direct mode.

The STOP statement is used to temporarily interrupt program execution, and may be inserted at as many points and locations in the program as required. Since execution of the program is only interrupted temporarily, the PRINT statement can be used in the direct mode to check the values stored in variables, after which execution can be resumed by entering CONT J .

Example

```
10 READ A, B
20 X=A*B
30 STOP
40 Y=A/B
50 PRINT X, Y
60 DATA 15, 5
70 END
RUN
BREAK IN 30
```

Note

Unlike the END statement, no files are closed by the STOP statement. (See page 68 concerning procedures for opening and closing of files.)

2.3.8.3 END (abbreviated format: E.)

Format
Function

END

The END statement terminates program execution and returns the BASIC interpreter to the command mode for input of direct mode commands. When this statement is executed, READY is displayed to indicate that the BASIC interpreter is ready. After the END statement has been executed, execution cannot be resumed by executing the CONT command even if there are executable statements on program lines following the END statement.

Note

All open files are closed when the END statement is executed. (See page 68 concerning procedures for opening and closing files.)

Differences between the STOP and END statements

	Screen display	Files	Resumption of execution
STOP	BREAK IN xxxx READY	Open files are not closed.	Can be resumed by executing CONT.
END	READY	Open files are closed	Cannot be resumed.

2.3.8.4 CLR

Format
Function

CLR

The CLR command clears all variables and cancels all array definitions. All numeric variables are cleared to 0, and null strings (" ") are placed in all string variables; arrays are eliminated entirely by nullifying all previously executed DIM statements. Therefore, DIM statements must be executed to redefine the dimensions of required arrays before they can be used again.

The CLR command also cancels all function definitions made with the DEF FN statement; therefore, it is also necessary to reexecute DEF FN statements to redefine such functions before they can be used again.

Note

CLR statements cannot be included in a FOR~NEXT loop or BASIC subroutine.

2.3.8.5 TIS

Format

TIS "hh mm ss"

Function

TIS is the name of the system string variable which contains the time of the computer's built-in clock.

This built-in variable is automatically incremented once each second, and the six character string contained in this variable indicates the hour, minute, and second, with two characters used for each. For example, if the string contained in TIS is "092035", the time is 9:20:35 A. M.

Variable TIS is automatically set to 00:00:00 when BASIC is loaded into the computer. To set the current time of day, use the string assignment statement. For example, the clock can be set to 7:00:00 P. M. by executing the following.

```
TIS = "190000"
```

The clock is set to 7:00:00 and then restarted automatically when the CR key is pressed.

The digits specified for the hour must be in the range from 00 to 23, and those specified for the minute and second must each be in the range from 00 to 59.

Example

The following program displays the current local time in various cities of the world.

```
10 PRINT "C"  
20 DIM C$(10), D(10), E(10), T$(10)  
30 FOR I=1 TO 10:READ C$(I), D(I):NEXT I  
40 PRINT"ENTER NEW YORK TIME (HOUR, MINUT  
E, SECOND) "  
50 INPUT B$:TIS=B$:PRINT "C"  
60 PRINT "H":TIS(1)=TIS  
70 FOR I=1 TO 10  
80 E(I)=VAL(LEFT$(TIS(1), 2))+D(I)  
90 IF E(I)=24 THEN E(I)=0  
100 IF E(I)<0 THEN E(I)=24+E(I)  
110 TIS(1)=STR$(E(I))+RIGHT$(TIS(1), 4)  
120 IF LEN(TIS(1))=5 THEN TIS(1)="0"+TIS(1)  
130 PRINT C$(I);TAB(15);LEFT$(TIS(1), 2);  
140 PRINT": ";MID$(TIS(1), 3, 2);": ";RIGHT$(  
TIS(1), 2);  
150 NEXT I:GOTO 60  
160 DATA NEW YORK, 0, MOSCOW, 8, RIO DE JANE  
IRO, 2  
170 DATA SYDNEY, 15, HONOLULU, -5, LONDON, 5,  
CAIRO, 7  
180 DATA TOKYO, 14, SAN FRANCISCO, -3, PARIS  
, 6
```

Note

The TI\$ variable cannot be specified in an INPUT statement. Further, after the time changes from 23:59:59 to 00:00:00, the time "00:00:01" is not displayed.

2.3.8.6 CURSOR (abbreviated format: CU.)

Format

CURSOR x, y
x ... X coordinate (0 to 39)
y ... Y coordinate (0 to 24)

Function

This command is used to move the cursor to a specified position on the TV (display) screen, and can be used together with the PRINT and INPUT statements to display characters in any desired location.

In the system of screen coordinates used, the columns of the screen are numbered from left to right, starting with 0 on the left side and ending with 39 on the right side; lines of the screen are numbered from top to bottom, with 0 indicating the top line of the screen and 24 indicating the bottom line. Thus, the cursor can be moved to any desired position in the range from (0, 0), which indicates the top left corner of the screen, to (39, 24) indicates the bottom right corner.

Example


The following program moves an asterisk (*) about on the screen as the cursor keys are pressed.

```
10 X=0:Y=0
15 PRINT " "
20 CURSOR X, Y:PRINT "*";
30 GET A$:IF A$=" " THEN 30
40 CURSOR X, Y:PRINT " ";
50 IF A$="↑" THEN Y=Y-1:REM "UP"
60 IF A$="↓" THEN Y=Y+1:REM "DOWN"
70 IF A$="←" THEN X=X-1:REM "LEFT"
80 IF A$="→" THEN X=X+1:REM "RIGHT"
90 IF X<0 THEN X=0
100 IF Y<0 THEN Y=0
110 IF X>38 THEN X=38
120 IF Y>24 THEN Y=24
150 GOTO 20
```

Note

If the value specified for either X or Y is other than an integer, it is converted to an integer by truncating the decimal portion before the cursor is moved.

Other methods of moving the cursor which are used together with the PRINT statement include the TAB and SPC functions. (See page 62 for a description of the SPC function.)



2. 3. 8. 7 TAB

Format

TAB (x)
x ... A numeric expression

Function

The TAB function is used together with the PRINT statement to move the cursor to the character position which is x + 1 positions from the left side of the screen. (This is referred to as space tabulation.)

Example

```
PRINT TAB (5) ; "XYZ" ; TAB (10) ; "ABC "
```

```
0 1 2 3 4 5 6 7 8 9 0 1 2
```

```
    _ _ _ _ _ XYZ _ _ ABC
```

← Not actually displayed.

Note

Tabulation can only be used to move the cursor to the right; therefore, **nothing happens** if this function is used together with the PRINT statement when the cursor is already to the right of the character position specified in (x).

(Example:)

```
PRINT TAB (5) ; "XYZ" ; TAB (5) ; "ABC "
```

```
0 1 2 3 4 5 6 7 8 9 0
```

```
    _ _ _ _ _ XYZ ABC
```

2. 3. 8. 8 SPC

Format

SPC (n)
n ... A numeric expression

Function

Use together with the PRINT statement, this function outputs a string of n spaces and thus moves the cursor n character positions to the right of its current position.

Example

(Example 1)

```
PRINT SPC (5) ; "ABC "
```

```
0 1 2 3 4 5 6 7
```

```
    _ _ _ _ _ ABC
```

(Example 2)

The following example illustrates the difference between the TAB and SPC functions.

```
10 ? TAB (2) ; "ABC" ; TAB (6) ; "DEF "
```

```
20 ? SPC (2) ; "ABC" ; SPC (6) ; "DEF "
```

```
0 1 2 3 4 5 6 7 8 9 0 1 2 3
```

```
_ _ ABC _ DEF _ _ _ _ _
```

```
_ _ ABC _ _ _ _ _ DEF
```


2.3.8.9 SET, RESET

These statements are used to turn dots on or off at a specified position on the screen.

Format	Function	Range of X, Y coordinates
SET X, Y, <C> X ... Numeric expression specifying the X coordinate. Y ... Numeric expression specifying the Y coordinate. C ... Color code (0 to 7).	Turns on the dots at the screen coordinates specified by X and Y. (SET)	$0 \leq X \leq 79$ $0 \leq Y \leq 49$
RESET X, Y X ... Numeric expression specifying the X coordinate. Y ... Numeric expression specifying the Y coordinate.	Turns off the dots at the screen coordinates specified by X and Y. (RESET)	$0 \leq X \leq 79$ $0 \leq Y \leq 49$

When a color code is specified, the color of the dots displayed by the SET statement is as follows.

- (0) Black
- (1) Blue
- (2) Red
- (3) Purple
- (4) Green
- (5) Light blue
- (6) Yellow
- (7) White


Since four dots are turned on simultaneously by the SET statement, changing the color of any one dot in that four dot group also causes the color of the other dots to change.

The SET and RESET statements can be used to produce a wide variety of interesting effects; some examples are introduced below.

1. Turning on one dot on the screen.

```

10 PRINT "■"
20 X=79:Y=49
30 SET X, Y, 2 ← Turns dots on.
40 RESET X, Y ← Turns dots off.
50 GOTO 30
  
```



2. Coloring the entire screen white.

```

10 PRINT "■"
20 FOR X=0 TO 79
30 FOR Y=0 TO 49
40 SET X, Y, 7
50 NEXT Y, X
60 GOTO 10
  
```

3. Drawing a rectangle around the edge of the screen.

```

10 PRINT "■"
20 FOR X=0 TO 79
30 SET X, 0
40 SET X, 49
50 NEXT X
60 FOR Y=0 TO 49
70 SET 0, Y
80 SET 79, Y
90 NEXT Y
100 GOTO 100
    
```

4. A program which simulates the ripples produced by throwing a pebble into a pond.

```

10 X=40:Y=25
20 DEF FNY (Z)=SQR (R*R-Z*Z)
30 PRINT "■":SET X, Y
40 R=R+5
50 FOR Z=0 TO R
60 T=FNY (Z)
70 SET X+Z, Y+T
80 SET X+Z, Y-T
90 SET X-Z, Y+T
100 SET X-Z, Y-T
110 NEXT Z
120 IF R<>25 THEN 40
130 GOTO 130
    
```

5. A program which simulates a ball bouncing off four walls.

```

10 PRINT "■"
20 FOR X=0 TO 79
30 SET X, 0:SET X, 49
40 NEXT X
50 FOR Y=0 TO 49
60 SET 0, Y:SET 79, Y
70 NEXT Y
80 X=79*RND (1) :Y=49*RND (1)
90 A=1:B=1
100 SET X, Y
110 IF X<2 GOSUB 200
120 IF X>78 GOSUB 200
130 IF Y<2 GOSUB 250
140 IF Y>48 GOSUB 250
150 RESET X, Y
160 X=X+A:Y=Y+B:GOTO 100
200 A=-A:MUSIC "A0": RETURN
250 B=-B:MUSIC "A0": RETURN
    
```

Note

As to JOY command, refer to the instruction manual of Joy Stick.

2.3.9 Music control statements

This section discusses the MUSIC and TEMPO statements which are used to control performance of music by the computer. As its name implies, the TEMPO statement specifies the speed with which music is performed. The notes (including half notes and upper and lower octaves) and duration of notes produced are controlled by the MUSIC statement.

Tempo:	Specified with TEMPO as a numeric variable or constant with a value from 1 (slow) to 7 (fast).				
Melody:	Specified with MUSIC as a string variable consisting of a collection of notes.				
Note specification:	<table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>octave</td> <td># (sharp)</td> <td>note name</td> <td>duration</td> </tr> </table>	octave	# (sharp)	note name	duration
octave	# (sharp)	note name	duration		

2.3.9.1 MUSIC (abbreviated format: MU.)

Format

MUSIC X\$
 X\$... String data
 Automatically performs music.

Discussion


This statement outputs the melody or sound effects specified by the character string or string variable of its argument to the speaker. The speed with which this melody is played is that which is specified with the TEMPO statement (see page 67).

The format for specification of each note is as follows:
 < octave specification > < # (sharp) > note name < duration >

The plus or minus signs are used to specify the octave. If neither is specified, the middle range is assumed.

The three ranges of sounds which can be output by the computer are as shown in the figure below. For example, the C notes ("do" on the 8-note C scale) indicated by the black dots below are differentiated from each other by the octave specification.

Low C -C
 Middle C C
 High C +C




Note specification

The symbols used to specify notes within each range are as follows:

CDEFGAB # R

The relationship between the 8-note scale (do, re, mi, fa, so, la, ti, do) and these symbols are as shown below. The sharp symbol (#) is used to specify half notes. Silent intervals are specified with "R".



Duration specification

The duration specification determines the length of the specified note. The durations from 1/32 to whole are specified as numbers from 0 to 9. (When R is specified, this determines the length of the silent interval.)

1/32 rest	1/16 rest	Dotted 1/16 rest	1/8 rest	Dotted 1/8 rest	1/4 rest	Dotted 1/4 rest	1/2 rest	Dotted 1/2 rest	Whole rest
1/32 note	1/16 note	Dotted 1/16 note	1/8 note	Dotted 1/8 note	1/4 note	Dotted 1/4 note	1/2 note	Dotted 1/2 note	Whole note
0	1	2	3	4	5	6	7	8	9

When successive notes have the same duration, the duration specification can be omitted for the second and following notes. If no duration is specified for the first note, 1/4 notes are assumed.

Sound volume

The volume of sound produced cannot be controlled by the program, but can be adjusted with the computer's external volume control.

Example

Let's try assigning a string to SR\$ to play the theme from the beginning of Beethoven's Serenade in D major (Opus 25).

```
SR$ = "+A3+#F1+A+B3A+D+#F1A+D3A+D
      + #F1A+D3+#F1A+D+E+#F+G+A3R"
```



2.3.9.2 TEMPO (abbreviated format: TEM.)

Format TEMPO x
x ... Numeric expression (1 to 7)

Function This statement sets the tempo with which music is played by the MUSIC statement. If this statement is not executed, TEMPO 4 is assumed for execution of MUSIC statements.

- 30 TEMPO 1 Slowest tempo (Lento, adagio)
- 30 TEMPO 4 Medium tempo (Moderato);
four times as fast as TEMPO 1.
- 30 TEMPO 7 Fastest tempo (Motto allegro, presto);
seven times as fast as TEMPO 1.

Example

```
10 REM Chopin's mazourka
20 MM$=" A3 " :M1$=" A5+#C3+D+E+#F+G+#F0+G+#
   F4+E3+D+#CB "
30 M2$=" A3+D2R0+D1+E2+D+#C3B+#C7+#C3 "
40 M3$=" A3+#C2R0+#C1+D2+#CB3A+D7+D3 "
50 TEMPO 3
60 MUSIC MM$, M1$, M2$, M1$, M3$, M1$, M2$, M1
   $, M3$
70 END
```



2.3.10 Data file input/output commands

Although the SAVE and LOAD commands can be used to write or read program text, other commands are used to record or read the various types of data which is handled by programs. These commands are described below.

	Format	Function
WOPEN (abbreviated W.)	WOPEN < file name >	Opens a data file on cassette tape prior to writing data to it. This command also assigns a name to the data file.
PRINT/T (abbreviated ?/T)	PRINT/T d_1 < , d_2 , d_3 , ... d_n > d_n Numeric data or string data	Writes data to cassette tape in the same format as it would be displayed by the PRINT statement.
ROPEN (abbreviated RO.)	ROPEN < file name >	Searches for the data file on cassette tape with the specified name and opens that file to prepare for reading data from it.
INPUT/T (abbreviated I./T)	INPUT/T v_1 < , v_2 , v_3 , ... v_n > v_n Numeric data or string data	Used to input data from a cassette file and pass it to the program (in a manner similar to that in which the INPUT statement is used to input data from the keyboard).
CLOSE (abbreviated CLO.)	CLOSE	Statement which closes cassette data files after writing or reading has been completed.

Unlike the LOAD and SAVE commands, no messages are displayed by execution of the WOPEN and ROPEN statements.

If display of a message is desired, use the PRINT statement to define one in the program.

Note: When an ordinary cassette recorder is used, it may not be possible to record data files even if no problems are encountered in storing or reading programs with the SAVE and LOAD commands.

(Example 1)

The following program writes the numbers from 1 to 99 on cassette tape.

```

10 WOPEN "DATA"
20 FOR X=1 TO 99
30 PRINT/T X
40 NEXT X
50 CLOSE
60 END

```

(Example 2)

The following program reads data from the data file prepared in Example 1 above. Before executing this program, be sure to rewind the cassette tape.

```

10 ROPEN "DATA"
20 FOR X=1 TO 99
30 INPUT/T A
40 PRINT A
50 NEXT X
60 CLOSE
70 END

```

(Example 3)

The following program creates a data file consisting of string data.

```
10 DIM N$(5)
20 N$(1) = "BACH"
30 N$(2) = "MOZART"
40 N$(3) = "BEETHOVEN"
50 N$(4) = "CHOPIN"
60 N$(5) = "BRAHMS"
70 WOPEN "GREAT MUSICIAN"
80 FOR J=1 TO 5
90 PRINT/T N$(J)
100 NEXT J
110 CLOSE
120 END
```

(Example 4)

The following program reads string data from the file created in Example 3. Before executing this program, be sure to rewind the cassette tape.

```
200 DIM M$(5)
210 ROPEN "GREAT MUSICIAN"
220 FOR K=1 TO 5
230 INPUT/T M$(K)
240 PRINT M$(K)
250 NEXT K
260 CLOSE
270 END
```

It is also possible to create data files which include both numeric and string data. However, since an error will occur if the type of data read does not match the type of variable specified in the INPUT/T statement, it is generally best to limit files to one type of data or the other.

Note: It is possible to omit the file name when opening a sequential file with the WOPEN statement. However, this is likely to result in errors if many files are included on the same tape; therefore, it is recommended that you make a habit of assigning file names to sequential data files.

The following program records student grades in English, French, science, and mathematics to a sequential data cassette file.

```

10 INPUT "ENTER NO. OF STUDENTS " ; N
20 DIM N$( N) , K ( N) , E ( N)
30 DIM R ( N) , S ( N)
40 A$ = " GRADE IS "
50 FOR X = 1 TO N
60 PRINT : PRINT " STUDENT NO. " ; X
70 INPUT " ENTER STUDENT NAME : " ; N$ ( X)
80 PRINT " ENG " ; A$ ; : INPUT K ( X)
90 PRINT " FREN " ; A$ ; : INPUT E ( X)
100 PRINT " SCI " ; A$ ; : INPUT R ( X)
110 PRINT " MATH " ; A$ ; : INPUT S ( X)
120 NEXT X
130 WOPEN " GRADES " ← Opens data file "GRADES" for output on cassette tape.
140 PRINT / T N ← Writes the number of students in the class to the file.
150 FOR X = 1 TO N
160 PRINT / T N$ ( X) , K ( X) , E ( X) , R ( X) , S ( X) ← Writes grades to the file.
170 NEXT X
180 CLOSE ← Closes the cassette file.
190 END

```

The following program reads the grade data written to the cassette file by the program shown above, then calculates displays the grade average for each student and class averages for each of the various subjects.

```

10 ROPEN " GRADES " ← Opens cassette file "GRADES" for input.
20 INPUT / T N ← Reads the number of people in the class.
30 DIM N$( N) , K ( N) , E ( N)
40 DIM R ( N) , S ( N)
50 FOR X = 1 TO N
60 INPUT / T N$ ( X) , K ( X) ← Reads student names and the grades for English.
70 INPUT / T E ( X) , R ( X) , S ( X) ← Reads the grades for French, science and mathematics.
80 NEXT X
90 CLOSE ← Closes the file.
100 PRINT TAB ( 10) ; " ENG " ;
110 PRINT TAB ( 15) ; " FREN " ;
120 PRINT TAB ( 20) ; " SCI " ;
130 PRINT TAB ( 25) ; " MATH "
140 FOR X = 1 TO N
150 PRINT N$ ( X) ; TAB ( 10) ; K ( X) ;
160 PRINT TAB ( 15) ; E ( X) ;
170 PRINT TAB ( 20) ; R ( X) ;
180 PRINT TAB ( 25) ; S ( X) ;
190 PRINT TAB ( 30) ; ( K ( X) + E ( X) + R ( X) + S ( X) ) / 4
200 K ( 0) = K ( 0) + K ( X) : E ( 0) = E ( 0) + E ( X)
210 R ( 0) = R ( 0) + R ( X) : S ( 0) = S ( 0) + S ( X)
220 NEXT X
230 PRINT TAB ( 10) ; K ( 0) / N ; TAB ( 15) ; E ( 0) / N ;
240 PRINT TAB ( 20) ; R ( 0) / N ; TAB ( 25) ; S ( 0) / N
250 END

```


2.4 Built-in Function


Function	BASIC symbol	Example	Description
Absolute value	ABS (X)	A = ABS (X)	Assigns the absolute value of variable X to variable A. Example: A = ABS (2.9) → A = 2.9 A = ABS (-5.5) → A = 5.5
Sign	SGN (X)	A = SGN (X)	Assigns the numeric sign of variable X to variable A. If the value of X is negative, -1 is assigned to A; if X is 0, 0 is assigned to A; and if X is positive, 1 is assigned to A. Example: 1 is assigned to variable A when A = SGN (0.4) is executed. $A = \begin{cases} 1 & (X > 0) \\ 0 & (X = 0) \\ -1 & (X < 0) \end{cases}$
Integer conversion	INT (X)	A = INT (X)	Assigns the greatest integer value to A which is less than or equal to the value of variable X. Examples: A = INT (3.87) → A = 3 A = INT (0.6) → A = 0 A = INT (-3.87) → A = -4
Trigonometric functions	SIN (X)	A = SIN (X) A=SIN(30*PAI(1)/180)	Assigns the sine of X (where X is in radians) to variable A. If the value of X is in degrees, it must be converted to radians before this function is used to obtain the sine. Since 1 degree equals $\pi/180$ radians, the value in radians is obtained by multiplying the number of degrees by PAI(1)/180. For example, $30^\circ = 30 * \text{PAI}(1)/180$ radians. The same applies to the COS, TAN, and ATN functions.
	COS (X)	A = COS (X) A=COS (200*PAI(1)/180)	Assigns the cosine of X (where X is in radians) to variable A.
	TAN (X)	A = TAN (X) A=TAN(Y*PAI(1)/180)	Assigns the tangent of X (where X is in radians) to variable A.
	ATN (X)	A = ATN (X) A=180/PAI(1)*ATN(X)	Assigns the arctangent in radians of X ($\tan^{-1} X$) to variable A. The value returned will be in the range from $-\pi/2$ to $\pi/2$.
Square root	SQR (X)	A = SQR (X)	Calculates the square root of X and assigns the result to variable A. X must be a positive number or 0.
Exponentiation	EXP (X)	A = EXP (X)	Calculates the value of e^x and assigns the result to variable A.
Common logarithm	LOG (X)	A = LOG (X)	Calculates the common logarithm of X ($\log_{10} X$) and assigns the result to variable A.
Natural logarithm	LN (X)	A = LN (X)	Calculates the natural logarithm of X ($\log_e X$) and assigns the result to variable A.
Ratio of circumference to diameter	PAI (X)	A = PAI (X)	Assigns the value to variable A which is X times the value of PI.
Radians	RAD (X)	A = RAD (X)	Converts the value of X (where X is in degrees) to radians and assigns the result to variable A.

Examples of use of the built-in functions

(Example 1)

Let's try solving the various elements of a triangle with a BASIC program.

Angle A of the triangle shown in the figure at right is 30° , angle B is a right angle, and side CA has a length of 12. The following program finds all angles of the triangle, the length of its sides, and its total area.



```

10 A=30 : B=90 : CA=12
20 AB=CA*COS (A*PI(1)/180)
30 BC=CA*SIN (A*PI(1)/180)
40 S=AB*BC/2
50 C=180-A-B
60 PRINT "AB=" ; AB, "BC=" ; BC, "CA=" ; CA
70 PRINT "AREAS=" ; S
80 PRINT "A=" ; A, "B=" ; B, "C=" ; C
90 END

```

(Example 2)

Now let's change line 50 of the program to use ATN, the function for finding the arctangent of a number, to find angle C from sides AB and BC.

```

10 A=30 : B=90 : CA=12
20 AB=CA*COS (A*PI(1)/180)
30 BC=CA*SIN (A*PI(1)/180)
40 S=AB*BC/2
50 C=ATN (AB/BC) *180/PI(1)
60 PRINT "AB=" ; AB, "BC=" ; BC, "CA=" ; CA
70 PRINT "AREAS=" ; S
80 PRINT "A=" ; A, "B=" ; B, "C=" ; C
90 END

```

RND function

Format

RND (X)

X .. Numeric expression

Function

The RND function returns a pseudo-random number in the range from 0.00000001 to 0.999999999.

When X is greater than 0, the random number returned is the one which follows that previously generated by the BASIC interpreter in a given pseudo-random number series.

When $X \leq 0$, the BASIC Interpreter's pseudo-random number generator is reinitialized to start a new series, and the pseudo-random number returned is the first one in that series. Reinitialization of the pseudo-random number series in this manner can be used to allow simulations based on random numbers to be reproduced.

The RND function is often used in game programs to produce unpredictable numbers, as in games of chance. Let's try using the RND function to investigate the percentage of times each of the six sides of a die comes up by simulating the action of throwing it a given number of times.

Since the sides of each die are numbered from 1 to 6, we must multiply the value returned by the RND function by 6.

$$0 < \text{RND}(1) < 1 \xrightarrow{\times 6} 0 < 6 * \text{RND}(1) < 6$$

Then we must use the INT function to convert the value obtained to an integer.

$$\text{INT}(6 * \text{RND}(1)) \rightarrow 0, 1, 2, 3, 4, 5$$

The result will be an integer between 0 and 5; now 1 is added to obtain the numbers which correspond to the number of dots on each of the 6 sides of a die.

$$\text{INT}(6 * \text{RND}(1)) + 1 \rightarrow 1, 2, 3, 4, 5, 6$$


This sequence is performed a specified number of times for each die thrown. Now let's incorporate the sequence into a program and check the results.

Example

```

10 PRINT "ENTER NO. OF
   TIMES DIE THROWN";
20 INPUT N
30 FOR J=1 TO N
40 R=INT(6*RND(1))+1
50 IF R=1 THEN N1=N1+1
60 IF R=2 THEN N2=N2+1
70 IF R=3 THEN N3=N3+1
80 IF R=4 THEN N4=N4+1
90 IF R=5 THEN N5=N5+1
100 IF R=6 THEN N6=N6+1
110 NEXT J
120 P1=N1/N:P2=N2/N:P3=N3/N
130 P4=N4/N:P5=N5/N:P6=N6/N
140 PRINT P1,P2,P3,P4,P5,P6
150 END

```



How about it? If the die is thrown enough times, the percentage of the time each number appears should be about the same. Mathematically speaking, each number should occur an average of once in six throws, or about 16.7% of the time. This mathematical ideal is approached more closely as the number of throws is increased.

Example

Now let's try using the RND function in a program which tests your ability to solve for the area of a triangle of random size. Here, the RND function is used to determine the length of each of the three sides of the triangle, then you compute the area of the triangle yourself and submit your answer to the computer for checking.

```

10 DIM A (3) , L$ (4)
20 FOR J=1 TO 4
30 READ L$ (J) : NEXT J
40 FOR J=1 TO 3
50 A (J) = INT (20 * RND (1) ) + 1
60 NEXT J
70 IF A (1) >= A (2) + A (3) GOTO 40
80 IF A (2) >= A (1) + A (3) GOTO 40
90 IF A (3) >= A (1) + A (2) GOTO 40
100 W = (A (1) + A (2) + A (3) ) / 2
110 T = W : FOR J=1 TO 3
120 T = T * (W - A (J) ) : NEXT J
130 SS = SQR (T) : S = INT (SS)
140 IF SS - S > 0.5 THEN S = S + 1
150 PRINT " C U L L U "
160 PRINT " SOLVE FOR THE AREA OF THE
FOLLOWING TRIANGLE "
170 PRINT " ROUND YOUR ANSWER TO THE
NEAREST WHOLE NUMBER "
180 PRINT
190 PRINT TAB (8) ; " A "
200 PRINT TAB (8) ; " □ □ " ; TAB (15) ; L$ (1)
; A (1)
210 PRINT TAB (7) ; " □ □ " ; TAB (15) ; L$ (2)
; A (2)
220 PRINT TAB (6) ; " □ □ " ; TAB (15) ; L$ (3)
; A (3)
230 PRINT TAB (5) ; " □ □ "
240 PRINT TAB (3) ; " B □ □ C "
250 PRINT TAB (4) ; " □ □ □ □ □ □ □ □ "
260 PRINT " U U U "
270 PRINT TAB (3) ; L$ (4) ;
280 INPUT Y
290 IF Y = S THEN PRINT " OK!! " : GOTO
40
300 IF Y < S THEN PRINT " TOO SMALL ! "
: GOTO 320
310 PRINT " TOO LARGE ! "
320 PRINT " ↑↑ " ;
330 PRINT TAB (24) ; SPC (25) : PRINT " ↑ " ;
340 GOTO 270
350 DATA LENGTH SIDE AB = , LENGTH SIDE BC =
360 DATA LENGTH SIDE CA = , AREAS OF TRIAN
GLE ABC IS

```

Note

Note that specifying a value for X which is less than or equal to 0 will always result in the same number for a given value of X. The reason for this is that specifying 0 or a negative number reinitializes the pseudo-random number generator to the beginning of the random number series.

LEN (X\$)

Format

X\$... String expression

Function

This function returns the number of characters included in the string expression represented by X\$. This value includes spaces which are not displayed on the screen and any control characters in the string, as well as letters, numbers, and symbols.

Example 1)

```
10 A$ = "ABCDEFG"
20 PRINT LEN(A$)
```

RUN

7

(Example 2) The following program uses the LEN function to draw squares on the screen.

```
10 ? : ? ENTER 30R MORE ASTERISKS
20 INPUT A$
30 FOR I=1 TO LEN(A$)-2
40 PRINT TAB(2); "X"; SPC(LEN(A$)-2); "X"
50 NEXT I
60 PRINT TAB(2); A$; GOTO 20
```

(Example 3) The LEN function can also be used to produce a "parade" of characters as shown below.

```
10 S$ = "SHARP BASIC"
20 FOR I=1 TO LEN(S$)
30 ? RIGHT$(S$, I)
40 NEXT I
50 END
RUN
```

SHARP BASIC
C
IC
BIC
.....
SHARP BASIC

(Example 4)

```
PRINT LEN(STR$(PI(1)))
B
```

PI(1), the function which returns the value of the ratio of the circumference of a circle to its diameter, contains the 8-digit constant 3.1415927 approximately the value of PI. When the length of the character string produced by converting this constant with the STR\$ function is evaluated with the LEN function, a total string length of 9 is returned.

2.5 String Function

2.5.1 LEN

Format

LEN (X\$)

X\$... String expression

Function

This function returns the number of characters included in the string expression represented by X\$. This value includes spaces which are not displayed on the screen and any control characters in the string, as well as letters, numerals, and symbols.

Example

(Example 1)

```
10 A$="ABCDEFGG"  
20 PRINT LEN(A$)
```

RUN

7

(Example 2) The following program uses the LEN function to draw squares on the screen.

```
10 ? " " : ? "ENTER 30R MORE ASTERISKS"  
20 INPUT A$  
30 FOR I=1 TO LEN(A$)-2  
40 PRINT TAB(2); "*" ; SPC(LEN(A$)-2); "*" ;  
50 NEXT I  
60 PRINT TAB(2); A$ : GOTO 20
```

(Example 3) The LEN function can also be used to produce a "parade" of characters as shown below.

```
10 S$="SHARP BASIC"  
20 FOR I=1 TO LEN(S$)  
30 ? RIGHT$(S$, I)  
40 NEXT I  
50 END
```

RUN

C

IC

SIC

.....

SHARP BASIC

(Example 4)

```
PRINT LEN(STR$(PAI(1)))
```


9

PAI (1), the function which returns the value of the ratio of the circumference of a circle to its diameter, contains the 8-digit constant 3.1415927 (approximately the value of PI). When the length of the character string produced by converting this constant with the STR\$ function is evaluated with the LEN function, a total string length of 9 is returned.

2.5.2 LEFT\$, MID\$, and RIGHT\$

The LEFT\$, MID\$, and RIGHT\$ functions are used to extract character strings from the left end, right end, or middle of a character expression.

Format X\$: String expression m and n: Numeric expressions	Function	Example (when A\$ = "ABCDEFGG")	Remarks
LEFT\$ (X\$, n)	Returns the character string consisting of the n characters making up the left of string expression X\$.	B\$= LEFT\$ (A\$, 2) B\$ ← AB CDEFG	$0 \leq n \leq 255$
MID\$ (X\$, m, n)	Returns the character string consisting of the n characters making up the n characters starting with the mth character in string expression X\$.	B\$=MID\$ (A\$, 3, 3) B\$ ← ABC DEFG	$1 \leq m \leq 255$ $0 \leq n \leq 255$
RIGHT\$ (X\$, n)	Returns the character string consisting of the n characters making up the right end of string expression X\$.	B\$ = RIGHT\$ (A\$, 2) B\$ ← ABCDEF FG	$0 \leq n \leq 255$



2.5.3 ASC and CHR\$

Format	Function	Example
ASC (x\$) x\$: String expression	Returns the ASCII code for the first character in string expression x\$.	<code>X=ASC (" A ")</code> Substitutes 65 (the ASCII code for the letter A) into variable X. <code>Y=ASC (" S HARP ")</code> Substitutes 83 (the ASCII code for S, the first letter in the string "SHARP") into variable X.
CHR\$ (x) x: Numeric expression	Returns the letter whose ASCII code corresponds to the value of numeric expression X. (No character is returned if the value specified for x is less than 33; therefore, <code>PRINT " "</code> or <code>PRINT SPC (1)</code> should be used to obtain spaces, rather than <code>CHR\$ (32)</code>).	<code>A\$=CHR\$ (65)</code> Assigns A, the letter corresponding to ASCII code 65, to string variable A\$. This function can be used to display characters which cannot be entered from the keyboard as follows. <code>PRINT CHR\$ (107) J</code> This displays the graphic character ☒.



Note: ASCII code is a standard code system which is frequently used with computers. This code uses 8 bit numbers to represent the letters of the alphabet, numerals, and symbols such as the dollar sign and question mark. The full code set is presented in the table on page 154.

2.5.4 VAL and STR\$

Format	Function	Example
STR\$(x) x: Numeric expression	Returns a string of ASCII characters representing the value of numeric expression X.	A\$=STR\$ (-12) Substitutes the character string "-12" into string variable A\$. B\$=STR\$ (70 * 33) Substitutes the character string " 2310 " into string variable B\$. C\$=STR\$ (1200000 * 5000) Substitutes the character string " 6E + 09 " into string variable C\$. Note: Positive numeric values are displayed with a leading space to indicate that the plus sign (+) has been omitted. However, this space is not included in the character string returned by the STR\$ function.
VAL(x\$) x\$: String expression	Converts an ASCII character representation of a numeric value into a numeric value. This is the complement of the STR\$ function.	A=VAL ("123") Converts the character string " 123 " into the number 123 and assigns it to numeric variable A.

The following sample program illustrates use of some of the functions discussed above to display numeric values in tabular format (with the decimal points aligned).

```

1. 23456
12. 3456
10
1
1234

```

If the values read from DATA statements were displayed using only the PRINT statement, the result would appear as shown below.

```



10 FOR X=1 TO 5
20 READ A
30 L=5-LEN(STR$(INT(A)))
40 PRINT TAB(L);A
50 NEXT:END
60 DATA 1. 23456, 12. 3456
70 DATA 123. 456, 1234. 56
80 DATA 12345. 6

```

```

1. 23456
12. 3456
123. 456
1234. 56
12345. 6

```



2.6 Color display statement

One of the greatest features of the MZ-700 is that it allows characters and graphics to be displayed using any of up to 8 colors.

2.6.1 COLOR (Abbreviated format: COL.)

Format

COLOR x, y, c <, b >

x X coordinate (0 to 39)

y Y coordinate (0 to 24)

c Character color specification (0 to 7).

b Background color specification (0 to 7).

Function

This statement is used to set the foreground and background colors for the character at a specific position on the screen. Any of up to 8 different colors can be specified for the character foreground (c) or background (b) as shown in the table below.

Color No.	Color
0	Black
1	Blue
2	Red
3	Purple
4	Green
5	Light blue
6	Yellow
7	White

Example

(1) Changing the background color of the entire screen

COLOR , , 2 (Changes the background color used for display of characters to red.)

(2) Changing the foreground color of the entire screen (the color used for display of all characters)

COLOR , , 3 (Changes the color used for display of all characters to purple.)

(3) Changing both the background and foreground colors for the entire screen

COLOR , , 1, 0 (Changes the color used for display of all characters to blue and changes the background used for display of characters to black.)

(4) Changing the background color at a specific screen location

COLOR 2, 2, , 4 (Changes the background color at coordinates 2, 2 to green.)

(5) Changing the foreground color at a specific screen location

COLOR 3, 2, 7 (Changes the foreground color at coordinates 3, 2 to white.)

(6) Changing both the foreground and background color at a specific screen location

COLOR 4, 2, 4, 2 (Changes the foreground color at coordinates 4, 2 to green and changes the background color at that location to red.)

2.6.2 Adding color specifications to the PRINT statement

Format

```

PRINT [f, b] { variable < { ; } { variable } { ; } ..... }
           ?      { constant } { constant } { ; }
           ?      { expression } { expression } { ; }

```

or

```

PRINT [f, b] USING "format string" ; variable < { ; } variable ....
           ?

```

f Foreground (character color) specification (a number from 0 to 7)

b Background color specification (a number from 0 to 7)

Function

Adding the color specifications to the PRINT and PRINT USING statements described on pages 37 and 38 makes it possible to display characters in a variety of colors. In the format above, f indicates the character foreground color, and b indicates the character background color. If only the foreground color is specified, the current background color is used for display of characters; this is done by specifying the foreground color, followed by a comma.

If only the background color is specified, the current foreground color is used for display of characters; in this case, a comma must precede the background color specification.

Example

(Example 1)

PRINT (6, 5) "ABCDE" Displays the letters "ABCDE" in yellow against a background of light blue.

PRINT (, 4) "FGHIJ" Displays the letters "FGHIJ" in yellow against a background of green.

PRINT (7,) "VWXYZ" Displays the letter "VWXYZ" in green against a background of white.

(Example 2) Let's try adding color to the automobile race program shown on page 46.

```

10 PRINT (, 1) "■"
20 Q=INT(5*RND(1))+2: X=33*RND(1)
30 FOR A=1 TO 5
40 READ M$
50 PRINT TAB(0); "◆"; TAB(X);
60 PRINT (Q, 1) M$;
70 PRINT (7, 1) TAB(37); "◆"
80 NEXT A
90 Y=10*RND(1)
100 FOR A=1 TO Y
110 PRINT TAB(0); "◆";
120 PRINT TAB(37); "◆": NEXT
130 RESTORE: GOTO 20
140 DATA " ■■■ ", " ■■■■ "
150 DATA " ■■■■ ", " ■■■■ "
160 DATA " ■■■ "

```

With ordinary PRINT statements (those without color specifications), the foreground and background colors used for character display are those which have been specified with the latest COLOR statement.

2.7 Color Plotter-Printer Commands

The color plotter-printer commands described below can be used with the MZ-731 or, when the MZ1P01 color-plotter printer is connected, with the MZ-711, or MZ-721. The color plotter-printer can be used in either of two modes: The text mode (for printout of program lists, results of calculations, or other character data), or the graphic mode (for drawing figures and graphs).

Further, any of four colors (black, blue, green, or red) can be used for printout of characters and graphics. This capability is particularly useful when using the printer in the graphic mode.

2.7.1 General information about the color plotter-printer

- (1) The color plotter-printer operates in either of two modes: The **text mode** (for printout of the results of calculations, program lists, and other character data) and the **graphic mode** (used for drawing figures and graphs). The printer will only operate in one mode at a time. (Graphic printer commands are ignored while the printer is in the text mode, and vice versa.)
- (2) Printer parameters are reset when the printer is switched from the graphics mode to the text mode. (In other words, the pens' X and Y coordinate settings are reinitialized.)
- (3) The printer runs on power supplied from the main unit of the MZ-700, and is not equipped with a separate power switch.
- (4) The following switches are used to control operation of the printer.
 - a. Feed switch Advances the paper.
 - b. Reset switch Resets (reinitializes) the printer.
 - c. Pen change switch Used when replacing the printer's pens.
- (5) There are four pen colors: Black, blue, green, and red.
- (6) When the printer is used in the text mode, any of three different sizes of characters can be printed. The largest size permits a maximum of 26 characters to be printed on one line, medium size permits a maximum of 40 characters to be printed on one line, and the smallest size allows up to 80 characters to be printed on one line.

Characters which can be printed when using the printer in the text mode are as shown below. No other letters, symbols, or graphic characters can be output while the printer is in this mode.

In most cases, hexadecimal ASCII codes will be printed in a different color if an attempt is made to print graphic characters with the PRINT/P statement or LIST/P command.

```
! "$%&'() *+,-./0123456789:;<=>?@ABCDEFGHIJ
KLMNOPQRSTUVWXYZ[\]^_`~ tgh bxd r p c q
s z w s u i ' ö k f v ü ß j n ù m * } ^ o | ã ö ä y < "
π □ → ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞
! "$%&'() *+,-./0123456789:;<=>?@A
BCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`~ tgh
bxd r p c q a z w s u i ' ö k f v ü ß j n ù m * } ^ o | ã ö ä y < "
π □ → ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞ ⊞
; < = >
```

2.7.2 Initial Printer Settings

The initial printer settings made when the BASIC interpreter 1Z-013B is started up are as follows.

- (1) Pen color: Black
- (2) Pen position: Left side of the carriage. (top line of 1 page.)
- (3) Mode: Text mode
- (4) Print size: 40 characters/line (standard size)
66 lines/page

2.7.3 Mode Specification Commands

These commands are used to place the printer in the text mode for printout of letters and numerics. This is the mode which is effective when the power is turned on; the initial character size is 40 characters/line.

- (1) **MODE TN** (abbreviated format: **M. TN**)
This command returns the printer to the text mode from the graphic mode and sets the character size to 40 characters/line.
- (2) **MODE TL** (abbreviated format: **M. TL**)
This command returns the printer to the text mode from the graphic mode and sets the character size to 26 characters/line.
- (3) **MODE TS** (abbreviated format: **M. TS**)
This command returns the printer to the **text mode** from the graphic mode and sets the character size to 80 characters/line.

*** CHARACTER MODE ***

80 character mode
ABCDEFGHIJKLMNOPQRSTUVWXYZ

40 character mode
ABCDEFGHIJKLMNOPQRSTUVWXYZ

26 character mode
ABCDEFGHIJKLMNOPQRSTUVWXYZ

- (4) **MODE GR** (abbreviated format: **M. GR**)
The **MODE GR** command is used to switch the printer from the text mode to the **graphics mode** for printout of charts and graphs. When switching to this mode, it is necessary for the BASIC program being executed to make a note of the character size being used immediately before the mode change is made. The reason for this is in order to return to the text mode when the **BREAK** key is pressed or a **STOP** command is encountered.

Note: Executing **MODE** command, every state returns to initial state excluding pen color and print size.

2.7.4 Pen color selection commands

PCOLOR n { n : 0 black
 n : 1 blue
 n : 2 green (abbreviated format: **PC.**)
 n : 3 red

This command specifies the color to be used for printout of characters or graphics. n is a number from 0 to 3, with 0 corresponding to black, 1 to blue, 2 to green, and 3 to red.

In text mode, executing **PCOLOR** in text mode every state is on initial state excluding pen color.

To keep current state execute **PRINT/P CHR\$(29)** next color.


This command can be entered in either the text mode or graphics mode.

2.7.5 Text mode commands

2.7.5.1 TEST (abbreviated format: TE.)

Format
Format

TEST
This command causes the printer to print squares in each of the four different colors to check the color specification, quantity of pen ink, and so forth. (Only usable in the text mode.)


0 1 2 3 Value of n in PCOLOR n
(Black) (Blue) (Green) (Red)

2.7.5.2 SKIP

Format
Function

SKIP n
n... A number in the range from -20 to 20
This command is used to feed the paper. Paper is fed n lines in the forward direction when the value for n is positive; if the value specified for n is negative, the paper is fed n lines in the reverse direction. Note that PRINTER MODE ERROR will occur if this command is executed while the printer is in the graphics mode.

2.7.5.3 PAGE

Format
Function

PAGE n
n... An integer in the range $1 \leq n \leq 72$
This command specifies the number of lines per page. (Executable only in the text mode.)

2.7.5.4 LIST/P (abbreviated format: L/P)

Format
Function

LIST/P or **LIST/P <LS-Le>**
Ls Starting line number
Le Ending line number
This command lists all or part of the program lines in memory on the printer. See the explanation of the LIST command on page 32 for an explanation of procedures for specifying the range of lines to be printed. Note that, when graphic characters are included in the program list, most of them will be printed in a different color as hexadecimal ASCII codes. See page 154 for the printer ASCII codes.
This command can only be executed in the text mode.

2.7.5.5 PRINT/P (abbreviated format: ?/P)

Format
Function


PRINT/P <I₁, d₁, I₂, d₂ I_n, d_n>
I_n Output list (numeric or string expressions)
d_n Delimiter
This command outputs the data in the output list to the printer. For details on using this command, see the description of the PRINT command on page 37. See pages 82 for printout of graphic characters.

2.7.5.6. PRINT/P USING (abbreviated format: ?/P USI.)

Except that output is directed to the printer, this is the same as the PRINT USING statement described on page 38.

2.7.6 Graphic mode statements

The graphic mode statements become effective after the **MODE GR** statement has been executed. When this statement is executed, the current pen location is set to the origin ($X = 0, Y = 0$). However, the origin can be set to any location. Be careful not to specify a location which is out of the print area, as this may damage the pen or cause other problems.



Note: See page 88 for the HSET statement.

2.7.6.1 LINE

Format

LINE $x_1, y_1 <, x_2, y_2, \dots, x_i, y_i >$ or

LINE %n, $x_1, y_1 <, x_2, y_2, \dots, x_i, y_i >$

n Integer from 1 to 16

x_i Number indicating the X coordinate ($x_i = -480$ to 480 ; the limit varies depending on the current pen location.)

y_i Number indicating the Y coordinate ($y_i = -999$ to 999)

Function

This statement draws a line from the current pen location to location (x_1, y_1) , then draws a line from (x_1, y_1) to (x_2, y_2) , and so on. n specifies the type of line drawn as shown below.

n = 1: solid line

n = 2 to 16: dotted line

If % is omitted, the previous value of n is assumed. The initial value of n is 1 (solid line).

Example

(Example 1) The following program draws a square with a side length of 240 units.

```

1Ø MODE GR          .....Switches to the graphic mode.
2Ø LINE 24Ø, Ø      .....Draws a line from the origin to the center
                       of paper.
3Ø LINE 24Ø, -24Ø
4Ø LINE Ø, -24Ø
5Ø LINE Ø, Ø        .....Draws a line to the origin.
6Ø MODE TN          .....Returns to the text mode.
  
```

(Example 2) The following program draws the same square as the example above.

```

1Ø MODE GR
2Ø LINE 24Ø, Ø, 24Ø, -24Ø, Ø, -24Ø, Ø, Ø
3Ø MODE TN
  
```

(Example 3) The following program draws a rectangle with a side length of 240 units.


```

10 MODE GR
20 SQ=INT(120*SQR(3))
30 LINE %2, 240, 0, 120, -SQ, 0, 0
40 MODE TN

```

The lines indicated with n are as follows.

*** LINE 1-16 ***



2.7.6.2 RLINE (abbreviated format: RL.)

Format

```

RLINE x1, y1 <, x2, y2, ... xi, yi ... >
RLINE %n, x1, y1, <, x2, y2, ..., xi, yi ... >
n ..... Integer from 1 to 16

```

xi Number indicating the X coordinate (-480 to 480)

yi Number indicating the Y coordinate (-999 to 999)

Function

This statement draws a line from the current pen location to the location indicated by **relative coordinates** x_1, y_1 , then draws a line from that point to the location indicated by relative coordinates x_2, y_2 , and so on. n is the same as for the LINE statement.

Example

This program draws the same rectangle as example 3 above.

```

10 MODE GR
20 SQ=INT(120*SQR(3))
30 RLINE %1, 240, 0, -120, -SQ, -120, SQ
40 MODE TN

```

Initial pen location




Figure drawn by LINE

Initial pen location




Figure drawn by RLINE

2.7.6.3 MOVE

Format

MOVE x, y

x Integer indicating the X coordinate (–480 to 480)

y Integer indicating the Y coordinate (–999 to 999)

Function

This statement **lifts the pen** and moves it to the specified location (x, y).

Example

The following program draws a cross with a side length of 480 units.

```
1Ø MODE GR
```

```
2Ø LINE 48Ø, Ø
```

```
3Ø MOVE 24Ø, 24Ø.....Lifts the pen at (480, 0) and moves it to  
240, 240).
```

```
4Ø LINE 24Ø, –24Ø
```

```
5Ø MODE TN
```

Be sure to advance the paper before executing this program.

2.7.6.4 RMOVE (abbreviated format: **RM**.)

Format

RMOVE x, y

x Integer indicating relative X coordinate (–480 to 480)

y Integer indicating relative Y coordinate (–999 to 999)

Function

This statement lifts the pen and moves it to the location indicated by **relative coordinates** (Δx , Δy)

Example

The following program draws the same cross as the example for the MOVE statement.

```
1Ø MODE GR
```

```
2Ø LINE 48Ø, Ø
```

```
3Ø RMOVE –24Ø, 24Ø.....Lifts the pen at (480, 0), then moves it  
–240 units in the X direction and 240  
units in the Y direction.
```

```
4Ø LINE 24Ø, –24Ø
```

```
5Ø MODE TN
```

Be sure to advance the paper before executing this program.

2.7.6.5 PHOME (abbreviated format: **PH**.)

Format

PHOME

Function

This statement returns the pen to the origin.

Example

The following example draws the same cross in red as the example for the MOVE statement.

```
1Ø MODE GR
```

```
2Ø LINE 48Ø, Ø :MOVE 24Ø, 24Ø
```

```
3Ø LINE 24Ø, –24Ø
```

```
4Ø PHOME .....Returns the pen to the origin.
```

```
5Ø PCOLOR 3
```

```
6Ø LINE Ø, 24Ø, 48Ø, 24Ø, 48Ø, –24Ø, Ø, –24Ø, Ø,  
Ø
```

```
7Ø MODE TN
```

2.7.6.6 HSET (abbreviated format: H.)

Format
Function

HSET
This statement sets the current pen location as the new origin. With this feature, the origin can be set to the location which is most appropriate for drawing figures. A MOVE statement is frequently executed before executing this command.

Example

```
1Ø MODE GR
2Ø MOVE 24Ø, -24Ø
3Ø HSET .....Sets the new origin.
4Ø FOR I=1 TO 36Ø STEP 3Ø
5Ø LINE 24Ø*COS (PAI(1)*I/18Ø),24Ø*SIN (PAI(1)*I/18Ø)
6Ø PHOME
7Ø NEXT
8Ø MODE TN
```

2.7.6.7 GPRINT (abbreviated format: GP.)

Format

GPRINT [n, @] , x\$
GPRINT x\$
n Integer indicating the character size (0 ~ 63)
@ Integer indicating the direction in which lines of characters are printed.
(@ = 0 ~ 3)
x\$ Character


Function

This statement prints the specified character using the specified size and direction. 80 characters can be printed on each line when n = 0; 40 characters can be printed on each line when n = 1; and 26 characters can be printed on each line when n = 2. When n and @ are omitted, the previous settings are assumed. Their initial values are n = 1 and @ = 0.

Example

```
1Ø MODE GR
2Ø GPRINT " A " .....Prints "A" in the graphic mode.
3Ø GPRINT (2, 2) , " A " .....Prints an upside down "A" in the 26
characters/line mode.
```

The following figures show various examples of printout.



2.7.6.8 **AXIS** (abbreviated format: **AX**.)

Format

AXIS x, p, r
 x Integer specifying the axis drawn (0 or 1)
 p Integer specifying the scale pitch (−999 to 999)
 r Integer specifying the number of repetitions (1 to 255)

Function


This statement draws the X-axis when x = 0 and the Y-axis when x = 1. The number of scale marks specified in r are drawn with a pitch of p.

Example

The following example draws the X and Y axes with scale marks from −240 to 240 at 10 unit intervals.

```

10 MODE GR ..... Switches the printer to the graphic
                           mode.
20 MOVE 240, 5
30 GPRINT [1, 0], "A"
40 MOVE 240, 0 ..... Lifts the pen and moves it to position
                           A (240, 0).
50 AXIS 0, -10, 48 ..... Draws the Y-axis from position A to
                           position B with scale marks included
                           at 10-unit interval.
60 MOVE 240, -500
70 GPRINT [1, 0], "B"
80 MOVE 0, -240 ..... Lifts the pen and moves it to position
                           C (0, -240).
90 GPRINT [1, 0], "C"
100 MOVE 0, -240
110 AXIS 1, 10, 48 ..... Draws the X-axis from position C to
                           position D with scale marks included
                           at 10-unit intervals.
120 MOVE 470, -240
130 GPRINT [1, 0], "D"
140 MODE TN
    
```



The coordinates can be used in the same manner as ordinary Cartesian coordinates after setting the point of intersection of the X and Y axes as the new origin. (X = −240 to 240, Y = −240 to 240)

2.7.6.9 CIRCLE (abbreviated format: CI.)

Format

CIRCLE x, y, r, s, e, d
 x, y Location of the center (-999 to 999)
 r Radius (0 to 999)
 s Starting angle (in degree)
 e Ending angle (in degree)
 d Step angle (in degree)

Function


This statement draws a circle or arc with a radius of r and a step of d at location (x, y), starting at angle S and ending at angle e. A complete circle is drawn when s = 0, e = 360 and d = 0.2.

Actually this statement draws a polygon; therefore, d must be as small as possible in order to draw a smooth figure.

s must be smaller than e. When d = 0, lines connecting the center and the starting point and the center and the ending point are drawn.

Example

```
10 MODE GR
20 LINE 480, 0, 480, -480, 0, -480, 0, 0
30 MOVE 240, -240
40 HSET
50 CIRCLE 0, 0, 240, 0, 360, 0.2
60 CIRCLE 240, 0, 240, 90, 270, 0.2
70 CIRCLE 0, 240, 240, 180, 360, 0.2
80 CIRCLE -240, 0, 240, 270, 450, 0.2
90 CIRCLE 0, -240, 240, 0, 180, 0.2
100 MODE TN
```



2.8 Machine Language Program Control Statements

Several machine language program control statements are supported by the MZ-700 BASIC interpreter. With these statements, machine language programs can be linked with a BASIC program.


Computer programming languages form a hierarchical structure as shown below. High level languages such as BASIC automatically performs work required when lower level languages such as assembly language are used. Although high level languages are convenient and easy to use, they cannot control the CPU directly.

The lowest level language (machine language) directly controls the CPU and provides high processing speed, but considerable skill is required for coding long programs.

Machine language program control statements enable sophisticated programming techniques which make it possible to utilize the advantages of both BASIC and machine language.

Machine language programs can be generated and loaded into the machine language program area (reserved with the BASIC LIMIT statement) using the monitor or assembler and loader. Such machine language programs can be called by BASIC programs with the `USR ()` function. Machine language programs can also be loaded into memory using a BASIC program which uses the `POKE` statement to write each step in machine code. The resultant machine language program can then be called by BASIC programs with the `USR ()` function.

The memory map at bottom right outlines the concept of data access with `POKE` and `PEEK`, and of calling machine language programs with `USR ()`.



2.8.1 LIMIT (Abbreviated format: LIM.)

Format


LIMIT ad
 ad Address; either a decimal number from 0 to 65279 or a 4-digit hexadecimal number from \$0000 to \$FEFF.

Function

This statement limits the memory area which can be used by the BASIC interpreter. ad indicates the upper limit of the BASIC area, and the area from the following address (ad + 1) to \$FEFF (65279) can be used for machine language programs or special data.

Example

LIMIT \$AFFF
 Limits the BASIC program area to \$AFFF.
 Note The area from \$FF00 to \$FFFF is used by the monitor as a work area, so it cannot be used as the user area. The LIMIT statement must be used at the beginning of a BASIC program.



Use LIMIT MAX to cancel the limit set by LIMIT ad.

2.8.2 POKE

Format

POKE ad, d
POKE@ ad, d
 ad Address: either a decimal number from 0 to 65535 or a hexadecimal number from \$0000 to \$FFFF.
 d Data to be written: a decimal number (0 to 255) or hexadecimal number (\$00 to \$FF)

Function

This statement writes data byte d to address ad. The POKE statement can write data to any memory location, regardless of the limit setting by the LIMIT statement. Therefore, careless use of this statement can destroy the monitor or BASIC interpreter. The POKE@ format is used to write data to an address in the user RAM area following 53248 (\$D000). (See page 125.)

Example

POKE \$D000, \$5F
POKE 53248, 95
 The two statements above perform the same function.
 Note A POKE statement specifying an address after \$D000 writes data into the video RAM area.

2.8.3 PEEK

Format PEEK (ad)
PEEK@ (ad)
ad Address in decimal or hexadecimal notation (0 to 65535 or \$0000 to \$FFFF)

Function This function returns the contents of the specified address as a decimal number from 0 to 255. Use the PEEK@ format to PEEK a user RAM area following 53248 (\$D000).

Example The following program displays data stored in the area from 40960 (\$A000) to 40975 (\$A00F).

```
10 FOR AD= 40960 TO 40975
20 ? PEEK (AD)
30 NEXT AD
```

2.8.4 USR (Abbreviated format: U.)

Format USR (ad)
USR (ad, x\$)
ad Address (decimal or 4-digit hexadecimal)
x\$ String data

Function This is a special function which transfers control to a machine language program which starts at the specified address. As with CALL ad, so control is returned to the statement following the USR function if the machine language program includes a return instruction (RET or RET_cc).
When x\$ is specified, the starting address of the memory area containing x\$ is loaded into the DE register, then the length of x\$ is loaded into the B register before the machine language program is called. This makes it possible for a BASIC program to pass string data to a machine language program.

2.8.5 Preparing machine language programs

A machine language program which fills the entire display screen with the characters supported by the MZ-700 is presented in this section as an example.

The following BASIC program loads such a machine program into memory and calls it.

```

10 LIMIT $BFFF .....Limits the BASIC area to $BFFF.
20 GOSUB 50
30 USR($C000) .....Calls the machine language program.
40 END
50 FOR I =49152 TO 49181
60 READ M .....Reads data for the machine language program from DATA
70 POKE I,M .....statements and writes it into the machine language area.
80 NEXT I
90 RETURN

100 DATA 197:REM      PUSH BC .....Beginning of data for the machine language program.
110 DATA 213:REM      PUSH DE
120 DATA 229:REM      PUSH HL
130 DATA 22,0:REM      LD D,0
140 DATA 33,0,208:REM  LD HL,D000H
150 DATA 1,232,3:REM   LD BC,1000
160 DATA 243:REM      DJNZ .....Switches the memory block to video RAM. (See page
170 DATA 211,227:REM  OUT (E3H),A .....155).
180 DATA 114:REM      STO:LD (HL),D
190 DATA 35:REM       INC HL .....Sets a display code to video RAM.
200 DATA 20:REM       INC D
210 DATA 11:REM       DEC BC
220 DATA 120:REM      LD A,B
230 DATA 177:REM      OR C
240 DATA 194,14,192:REM JP NZ,STO
250 DATA 211,225:REM  OUT (E1H),A .....Switches the memory block to RAM. (See page 127.)
260 DATA 251:REM      EI
270 DATA 225:REM      POP HL
280 DATA 209:REM      POP DE
290 DATA 193:REM      POP BC
300 DATA 201:REM      RET .....Returns to the BASIC program.

```

If the machine language program has been generated with the monitor and saved on cassette tape under the file name DISPLAYCODE, use the following program to call the machine language program.

```

110 LIMIT $BFFF
110 LOAD "DISPLAYCODE"
120 USR($C000)

```


2.9 I/O Statements

All external devices (including floppy disk drives) are connected to the MZ-700 through an optional interface board. The optional universal interface board makes it possible for the user to connect external devices such as an X-Y plotter, paper tape punch, and music synthesizer to the MZ-700.

A port address selection switch is provided on the universal interface card to allow any port address from 0 to 239 (00H to EFH) can be assigned to any devices. Addresses 240 to 255 are reserved for optional peripheral devices supplied by Sharp.

The INP and OUT statements allow the user to transfer data from/to external devices through the optional universal I/O card. The format of these statements is as follows.

INP #P, D Reads 8-bit data from port P, converts it into a decimal number and assigns it to variable D.

OUT #P, D Converts a decimal number in variable D to binary format and outputs it to port D.

These statements greatly extend the range of applications of the MZ-700 series computers.

2.10 Other Statements

2.10.1 ON ERROR GOTO (Abbreviated format: ON ERR. G.)

Format ON ERROR GOTO Lr
Lr . . . Destination line number (entry point of an error processing routine)

Function This statements causes execution to branch to line number Lr if an error occurs. The IF ERN and IF ERL statement can be used in a trap routine starting at that line to control subsequent processing according to the type of error and the line number in which it occurred. Including a RESUME statement at the end of the error processing routine makes it possible to return execution to the line at which the error occurred. Executing an ON ERROR GOTO statement cancels the error trap line number defined by the previous ON ERROR GOTO statement. The error trap line number definition is also cancelled by executing a CLR statement.

2.10.2 IF ERN

Format IF relational expression using ERN THEN Lr
IF relational expression using ERN THEN statement
IF relational expression using ERN GOTO Lr
Lr . . . Destination line number

Function This statement branches execution to the error processing (trap) routine starting at line Lr or executes the statement following THEN when the result of <relational expression using ERN> is true.

ERN is a special function which returns a number corresponding to the type of error occurring. See page 159 for the error numbers.

Example The following shows an error processing routine beginning on line 1000 which causes execution to branch to line 1200 if the error number is 5.

```
1000 ON ERROR GOTO 1000.....Declares the line number of the
                                error processing routine.
.....
1000 IF ERN=5 THEN 1200.....Branches to 1200 if a string
                                overflow error has occurred.
```

2.10.3 IF ERL

Format	IF relational expression using ERL THEN Lr IF relational expression using ERL THEN statement IF relational expression using ERL GOTO Lr Lr Destination line number
Function	This statement branches execution to the routine starting at line Lr or executes the statement following THEN when the result of <relational expression using ERL> is true. ERL is a special function which returns the line number at which an error occurred.
Example	The following statement causes execution to branch to line 1300 if an error has occurred on line 250. 1010 IF ERL = 250 THEN 1300 The following statement returns control to line 520 in the main routine if the error number is 43 and the error line number is other than 450. 1020 IF (ERN = 43) * (ERL < > 450) THEN RESUME 520

2.10.4 RESUME (Abbreviated format: RESU.)

Format	RESUME <NEXT> RESUME Lr Lr Line number or 0
Function	This statement returns control to the main routine from an error processing routine.
Discussion	The system holds the number of the line on which the error occurred in memory and returns program execution to that line or to another specified line after the error is corrected. The RESUME statement may be used in any of the following four forms:

- RESUME Returns to the error line.
- RESUME NEXT Returns to the line following the error line.
- RESUME Lr Returns to line Lr.
- RESUME Ø Returns to the beginning of the main routine.

If the RESUME is encountered when no error has occurred, error 21 (RESUME ERROR) occurs.

If the RESUME cannot be executed, error 20 (CAN'T RESUME ERROR) occurs.

2.10.5 SIZE

Format	PRINT SIZE
Function	This is a special function which returns the number of bytes in memory which can be used for storage of BASIC programs. For example, PRINT SIZE displays the number of free bytes of memory area.

2.10.6 PLOT ON (Abbreviated format: PL. ON)

Format
Function

PLOT ON
This statement makes it possible to use the color plotter-printer as a display unit. Thus, the MZ-700 can be used without an external display screen. This statement is effective only when the color plotter-printer is installed and the MODE TN statement has been previously executed.

Example
Note

PLOT ON
A period "." is printed to represent any characters which are not stored in the color plotter-printer's character generator (see page 156). The **INST**, **DEL** and "←" keys are disabled by executing this statement. **CTRL** + **G** can be used to change the pen.

2.10.7 PLOT OFF (Abbreviated format: PL. OFF)

Format
Function
Example

PLOT OFF
This statement cancels PLOT ON made of plotter-printer operation.
PLOT OFF

2.10.8 CONSOLE (Abbreviated format: CONS.)

Format

CONSOLE <Is, In< ,Cs, Cn >>


- Is : Starting line of the scroll area
- In : Number of lines within the scroll area
- Cs : Starting column of the scroll area
- Cn : Number of columns in the scroll area

Example

```
CONSOLE 0, 25, 0, 40
CONSOLE 5, 15
CONSOLE 0, 25, 5, 30
CONSOLE 0, 10, 0, 10
CONSOLE
```

Function

This statement specifies the size of the scroll area; i. e., the area which is cleared by PRINT "█".
The first example specifies the entire screen as the scroll area. The second specifies the area between lines 5 and 15 as the scroll area. The third specifies the area between columns 5 and 30 as the scroll area. The fourth specifies the 10 x 10 positions at the upper left corner of the screen as the scroll area.
This statement is useful for excluding the left and/or right edges of the image from the display area. When they are hidden behind the edges of the screen.
The last example does not specify the scroll area. When the scroll area is not specified, it is possible to scroll the screen up or down.
However, this makes it harder to perform screen editing because the values of Cn and In become smaller.



2.11 Monitor Function

The IOCS section of the BASIC Interpreter includes a monitor program to make it easy to enter machine language programs. This monitor program uses the area from FF00H to FFFFH as a stack area.

This monitor program includes the screen editor similar to that of BASIC which makes it possible to change the contents of any address within the 64K RAM area as described below.

2.11.1 Editing format

: address = data data data
: (colon) ... Indicates that the line following can be edited.
address ... Indicates the starting address of the memory area whose contents can be changed.
(4 hexadecimal digits)
= ... Separates data from the address.
data ... 2-digit hexadecimal number or a semicolon “;” plus the character which is written in the specified address. A blank is used to separate adjacent data items.

2.11.2 Printer switching command (P command)

Format * P

This command switches data output with the D or F command between the printer and display. If the printer is not connected to the computer, the message “ERR?” is displayed and the monitor stands by for input of another command. Check the printer connection or execute the P command again to switch the output device to the display.

2.11.3 Dump command (D command)

Format * D <start address < _ end address >>

This command dumps the contents of memory from the starting address to the end address. If the end address is omitted, the contents of the 128-byte block starting at the specified address are dumped. If both addresses are omitted, it dumps the contents of the 128-byte block following memory block previously dumped. The format in which data is dumped is as follows.

: HHHH=HH_HH_HH HH HH HH HH HH /ABCDE. G.
↑
Starting address 8 bytes (Hexadecimal code) 8 bytes (Characters)

The contents of any location can be changed by moving the cursor to the corresponding byte, entering the new data, and pressing the **CR** key.

Note Control codes are displayed as a period (.) in the character data field. Pressing the **BREAK** key stops dump output, and pressing the **SHIFT** and **BREAK** keys simultaneously returns the monitor to the command input mode.

2.11.4 Memory set command (M command)

Format * M [starting address]

This command is used to change the contents of memory. If the starting address is omitted, the address currently indicated by the program counter is assumed. Press the **SHIFT** and **BREAK** keys together to terminate this command.

When this command is entered, the starting address of the memory block and its contents are displayed in the editing format described previously and the cursor is moved to the data to be changed. Enter the new data and press the **CR** key; the following address and its contents are then displayed.

2.11.5 Fin command (F command)

Format * F [starting address] _ [end address] _ [data] _ [data] _

This command searches for the specified data string in the memory area from the starting address to the end address. When found, the address of the string and its contents are dumped to the screen. This command is terminated by simultaneously pressing the **SHIFT** and **BREAK** keys.

2.11.6 Subroutine call (G command)

Format * G [call address]

This command calls the subroutine starting at the specified address. The stack pointer is located at FFEEH.

2.11.7 Transfer command (T command)

Format * T [starting address] _ [end address] _ [destination address]

This address transfers the contents of memory between the starting address and the end address to the memory area starting at the destination address.

2.11.8 Save command (S command)

Format * S[starting address] _ [end address] _ [execution address] : [file name]

This command saves the contents of the memory between the starting address and the end address to cassette tape under the specified file name.

2.11.9 Load command (L command)

Format * L < load address > < : file name >

This command loads the specified file into memory, starting at the load address. If the load address is omitted, the execution address contained in the file is assumed as the load address. If the file name is omitted, the first file encountered on the tape is loaded. The message "ERR?" is displayed if a check sum error is detected or the BREAK key is pressed during execution, then the monitor returns to the command wait state input mode. The command input mode wait state is entered when execution is wait state is entered when execution is completed.

2.11.10 Verify command (V command)

Format * V < file name >

This command reads the specified file from cassette tape and compares it with the contents of memory. This makes it possible to confirm that a program has been properly recorded with the SAVE command. If any difference is found between data read from the tape and that contained in memory, the message "Err ?" is displayed.

2.11.11 Return command (R command)

Format * R

This command returns control to the system program which called the monitor program and restores the SP (stack pointer) and HL register to the values which they contained when the monitor program was called. Execution resumes with the command following BYE is executed.

This command cannot return control if the monitor has been called by a system program whose stack pointer is between FF00H to FFFFH, or if the stack pointer does not contain a return address. In such cases, use the G command to call the warm start entry point.

2.11.9 Load command (L command)

Format * L < load address > < : file name >

This command loads the specified file into memory, starting at the load address. If the load address is omitted, the execution address contained in the file is assumed as the load address. If the file name is omitted, the first file encountered on the tape is loaded. The message "ERR?" is displayed if a check sum error is detected or the BREAK key is pressed during execution, then the monitor returns to the command wait state input mode. The command input mode wait state is entered when execution is wait state is entered when execution is completed.

2.11.10 Verify command (V command)

Format * V < file name >

This command reads the specified file from cassette tape and compares it with the contents of memory. This makes it possible to confirm that a program has been properly recorded with the SAVE command. If any difference is found between data read from the tape and that contained in memory, the message "Err?" is displayed.

2.11.11 Return command (R command)

Format * R

This command returns control to the system program which called the monitor program and restores the SP (stack pointer) and HL register to the values which they contained when the monitor program was called. Execution resumes with the command following BYE is executed. This command cannot return control if the monitor has been called by a system program whose stack pointer is between F40H to FFFFH, or if the stack pointer does not contain a return address. In such cases, use the G command to call the warm start entry point.


Operating the MZ-700




3.1 Appearance of the MZ-700 Series Personal Computers

3.1.1 MZ-731

■ Front view




■ Rear view




3.1.2 MZ-721

■ Front view



3.1.3 MZ-711

■ Front view



3.2 Connection to Display Unit

Be sure to turn off both the computer and display unit before connecting them.

3.2.1 Connecting a TV set to the MZ-700

Disconnect the antenna feeder from the UHF antenna terminals of the TV set. Plug the connection cable provided into the RF signal output jack on the rear panel of the computer and connect the pin plugs on the cable's other end to the 75-ohm UHF antenna terminals on the TV set.



Back view of MZ-700



Back view of Home TV

Set the channel selection switch to the 36 ± 3 ch position, depending on which is not used in your area.

Note the following when using an ordinary TV set as a display unit.


- Adjust controls (fine tuning, color control, etc.) of the TV set to optimum conditions before connecting it to the computer.
- Note that color and quality of displayed images will be poorer with a TV set than when a special color monitor unit is used. Further, note that images may be painted with the wrong colors or may not be colored if the TV set is not properly adjusted.
- Part of the screen may be omitted if vertical and horizontal scanning frequencies of the TV set do not match those of the computer. This is not a problem with the computer; contact your TV dealer.
- Part of the screen may not be visible if the image is not centered.
- Be sure to remove the antenna feeder from the TV set before connecting it to the computer; otherwise, the signal from the computer will radiate from the TV antenna, possibly interfering with other TV sets.
- Be sure to connect the computer to the 75-ohm antenna terminals of the TV set. If the cable provided cannot be used, be sure to use a **75-ohm coaxial cable**.
- Characters may be hard to read with certain combinations of foreground and background colors. In such cases, switch the B/W-color switch to the B/W position to obtain higher contrast. The best combination of the foreground and background colors is white for the foreground and black or blue for the background.
- No audio signal is included in the RF signal fed to the TV set, so sound cannot be output from the speaker of the TV set.

3.2.2 Connecting the MZ-1D04 12-inch green display to the computer

Use the cable included with the MZ-1D04 green display to connect it to the computer. Plug the cable into the composite signal jack on the computer's rear panel, then set the B/W-COLOR switch to the B/W position.



Rear panel of the MZ-700 series computer



Rear panel of the MZ-1D04

3.2.3 Connecting the MZ-1D05 14-inch color display to the computer

Use the cable included with the MZ-1D05 color display to connect it to the computer. Plug the cable's DIN connector into the RGB signal output connector on the MZ-700.




Rear panel of the MZ-700 series computer



Rear panel of the MZ-1D05

Pin assignments of the RGB signal output connector of the MZ-700 are as shown below.




RGB signal output DIN connector (viewed from the rear side)

3.3 Data Recorder

■ Data recorder built into the MZ-731 and MZ-721

The built-in data recorder can be operated in the same manner as an ordinary cassette tape recorder.


RECORD	Press this key to record programs and data.
PLAY	Press this key to load programs and data.
REWIND	Press this key to rewind the tape.
FFWD	Press this key to fast-forward the tape.
STOP/EJECT	Press this key to stop the tape, to release other keys when the tape stops after loading or recording programs or data, or to eject the tape.



■ MZ-1T01


The MZ-1T01 data recorder unit can be installed in the MZ-711 (MZ-710). Installation procedures are as follows.

1. Turn off the computer's power switch and unplug the power cable from the AC outlet.
2. Remove the two screws located on the left side of the rear panel to remove the data recorder compartment cover.



3. Remove the joint connector cover.
4. Plug the connector of the MZ-1T01 onto the 9-pin connector located at the left rear of the recorder compartment of the MZ-711.
5. Position the data recorder in the recorder compartment and fasten it in place with the two screws. When doing this, be careful to avoid catching the connector cable between the data recorder and the computer, (otherwise, the screws cannot be tightened).

■ Ordinary cassette tape recorder




Using commercially available audio cables with 3.5 mm mini-plugs, connect the WRITE jack of the computer to the MIC jack of the cassette tape recorder and connect the computer's READ jack to the EXT SP or EAR jack of the cassette tape recorder.

Take note of the following when using an ordinary cassette tape recorder.


- (1) The message "⏏ RECORD. PLAY" does not appear when a SAVE command is entered. Be sure to press the RECORD key on the recorder before entering this command. Press the STOP key to stop the recorder after the message "READY" is displayed. Without depressing the STOP key, the recorder is not stopped.
- (2) The message "⏏ PLAY" does not appear when a LOAD command is entered. Be sure to start playing the tape after entering the command. The message "READY" is displayed when loading is completed.
- (3) The level and tone controls of the cassette tape recorder must be adjusted to appropriate levels. Some cassette recorders (e.g. those with the automatic level control) may not be usable. In such cases, please purchase the MZ-1T01.
- (4) The polarity of the head can make it impossible to load programs provided with the computer. Try switching the head polarity if programs cannot be loaded.
- (5) For any transfer or collation, use the tape recorder that was used for recording. If the tape recorder for transfer or collation is different from that used for recording, no transfer nor collation may be possible.
- (6) Data written using an ordinary cassette recorder may not be readable with the data recorder. Therefore, use of the MZ-1T01 is recommended.

3.4 Color Plotter-Printer



Reset switch Pen change switch Paper feed key


Plotter-printer (viewed from the top)



Paper inlet


Plotter-printer (viewed from the rear side)

■ Loading roll paper


1. Remove the printer cover.
 2. Cut the end of roll paper straight across and insert the end into the paper inlet. (Be careful to avoid folding or wrinkling the end of the paper when doing this.)
 3. Turn on MZ-731's power switch and press the  (paper feed) key to feed paper until the top of paper is 3 to 5 cm above the outlet.
 4. Insert the paper shaft into the roll and mount it to the paper holders.
 5. Set the printer cover so that the end of paper comes out through the paper cutter.
- To remove the roll from the printer for replacement, cut straight across the paper at the paper inlet and press the paper feed key.
- Roll paper for the MZ-700 series computers is available at any Sharp dealer. Do not use paper other than that specified.

The length of the paper is 23 to 25 meters, and the maximum roll diameter which can be loaded is 50 mm. Paper will not feed properly if a roll with a greater diameter is used, resulting in poor print quality.


Procedures for loading roll paper



(A) Insert paper into the paper inlet.



(B) Press the paper feed key to feed paper.



(C) Replace the printer cover.






Pen eject lever

- EA-850B (black; 4 pens)
- EA-850C (black, blue, green, red; 4 pens, 1 of each color)

■ Installing/replacing pens

1. Remove the printer cover and press the PEN CHANGE switch with a ball pen or the like; this causes the pen holder to move to the right side of the printer for pen replacement.
2. Depress the pen eject lever to eject the pen which is at the top of the holder. When doing this, rest your finger lightly on top of the pen while pushing the eject lever to prevent it from falling inside the printer.
3. Insert a new pen.
4. Press the PEN CHANGE switch again to bring another pen to the top of the holder.
5. Replace all four pens (black, blue, green and red) in the same manner. When finished, press the RESET switch to ready the printer for printing with the black pen.

Execute the BASIC TEST command to confirm that all colors are printed correctly.





- Replacements for the printer pens (ballpoint pens) can be purchased at the dealer where the printer was purchased.

- EA-850B (black; 4 pens)
- EA-850C (black, blue, green, red; 4 pens, 1 of each color)

■ MZ-1P01

Installation of the MZ-1P01 color plotter printer (for models other than the MZ-731)

1. Turn off the computer's power switch and unplug the power cable.
2. Remove the two screws located at the center of the rear panel to remove the printer compartment cover.
3. Confirm that the printer switch on the printed circuit board is set to the INT position.
4. Plug the printer connector into the matching connector on the printed circuit board, then position the printer in the printer compartment and fasten it in place with the two screws. When doing this, be careful to avoid catching the connector cable between the data recorder and the computer (otherwise, the screws cannot be tightened).



Connection of color plotter-printer to the MZ-700

■ Connecting an external printer (MZ-80P5(K))

The MZ-80P5(K) printer for the MZ-80K series computers can be connected to the MZ-700's external printer connector (see page 104) without any special interface card. Use an optional connection cable for making the connection.

When using an external printer, the printer switch on the printed circuit board must be set to the external printer position. Therefore, the color plotter-printer and the external printer cannot be used simultaneously.

Note that if a program including color plotter-printer control statements is run with an external printer, meaningless characters (control codes for the plotter-printer) will be printed.

3.5 Key Operation



3.5.1 Typewriter keyboard


Except for the special control keys, several characters are assigned to each key on the keyboard. The character entered when a key is pressed depends on the input mode selected by the special keys.

The input modes are as follows.

- (1) **Normal mode** This mode is automatically entered when the BASIC interpreter is loaded. In this mode, the ASCII character (uppercase or lowercase) shown on top of each key is entered when that key is pressed.
- (2) **Graphic mode** This mode is entered when the **GRAPH** key is pressed. In this mode, the graphic pattern shown on the left front of each key is entered when that key is pressed. The graphic pattern shown on the right front of each key is entered by pressing that key together with the shift key. Pressing the **ALPHA** key returns input to the normal mode.

Pressing the space bar enters a space regardless of the input mode.

For example characters entered by the C key in different input modes are as follows.



The special keys are explained below.

SHIFT

Pressing this key allows shift position characters to be entered.

For alphabetic keys, the shift position characters are lowercase letters; for keys other than alphabetic keys, the shift position characters are those shown on the upper side of the key tops. In the GRAPH mode, the graphic pattern shown on the right front of each key is entered.

C R

Pressing this key enters a CR (carriage return) code, terminating the line and moving the cursor to the beginning of the next line.

BREAK



Pressing this key enters a BREAK code. Pressing it together with the SHIFT key stops execution of a program or operation of the data recorder.


GRAPH

Pressing this key changes the input mode from normal to graphic for input of the graphic patterns shown on the left front of keys.

ALPHA


Pressing this key changes the input mode from graphic to normal.

The cursor symbol is  in the normal mode and  in the graphic mode.




(1) Normal mode (alphanumeric mode)

Character entered by each key in the normal mode are as indicated by the screened areas in the figure below.



When with the **SHIFT** key is pressed together with other keys, lowercase letters (or other symbols indicated by the screen areas in the figure below) are entered.



(2) Graphic mode

Pressing the **GRAPH** key places the computer in the graphic input mode. Characters entered by each key in the graphic mode are as indicated by the screened areas in the figure below. In this mode, pressing any of the cursor control keys, the INST/CLR key or the DEL/HOME key enters the symbols **↑**, **←**, **→**, **↓**, **⊙**, or **H**, respectively.



When with the **SHIFT** key is pressed together with other keys, symbols indicated by the screen areas in the figure below are entered.



The cursor symbol is **⊙** in the graphic mode. To return the mode to normal, press the **ALPHA** key.

3.5.2 Definable function keys



Definable function keys

The five blue keys marked F1 to F5 above the typewriter keyboard are referred to as definable function keys.

Certain character strings are automatically assigned to these keys as follows when the BASIC interpreter is activated.

F1: "RUN" + CHR\$ (13)

F2: "LIST"

F3: "AUTO"

F4: "RENUM"

F5: "COLOR"

SHIFT + F1: "CHR\$ ("

SHIFT + F2: "DEF KEY ("

SHIFT + F3: "CONT"

SHIFT + F4: "SAVE"

SHIFT + F5: "LOAD"


When one of these keys is pressed, the character string assigned to that key is entered; thus, statements which are frequently used can be entered just by pressing one key. The character string assigned to any of the definable function keys can be changed by the DEF KEY statement. (See page 57, DEF KEY statement.)

■ Definable function key label

Labels indicating the character strings assigned to definable function keys can be placed under the transparent cover located above these keys. The transparent sheet can easily be removed as shown below.



3.5.3 Cursor control keys and insert and delete keys



Cursor control keys and insert and delete keys

The cursor control keys are the four yellow keys at the right of the keyboard which are marked with arrows.

Pressing these keys moves the cursor one position in the direction indicated by the arrow. These keys are used when editing programs.

The

INST
CLR

 and

DEL
HOME

 key have the following functions.

INST
CLR

Inserts a space at the position of the cursor and shifts all following characters one position to the right. INST: insert.

DEL
HOME

Erases the character to the left of the cursor and shifts all following characters one position to the left. DEL: delete.

SHIFT	+	INST
		CLR


Clears the entire screen and returns the cursor to the screen's upper left corner. Pressing this key does not affect the program in memory. CLR: clear.

SHIFT	+	DEL
		HOME

Returns the cursor to the upper left corner of the screen (does not affect any characters displayed).

See pages 18 and 19.

3.5.3 Cursor control keys and insert and delete keys



Cursor control keys and insert and delete keys

The cursor control keys are the four yellow keys at the right of the keyboard which are marked with arrows. Pressing these keys moves the cursor one position in the direction indicated by the arrow. These keys are used when editing programs.

The CLR, DEL and HOME keys have the following functions:

Insterts a space at the position of the cursor and shifts all following characters one position to the right. INST: insert.	INST
Erases the character to the left of the cursor and shifts all following characters one position to the left. DEL: delete.	DEL
Clears the entire screen and returns the cursor to the screen's upper left corner. Pressing this key does not affect the program in memory. CLR: clear.	SHIFT + CLR
Returns the cursor to the upper left corner of the screen (does not affect any characters displayed).	SHIFT + HOME

See pages 18 and 19.


Hardware



Notice: The contents of this chapter are for reference only, and Sharp cannot assume responsibility for answering any questions about its contents.

4.1 MZ-700 System Diagram


The figure below shows the system configuration of the MZ-700 series computers.



Notice: The contents of this chapter are for reference only, and Sharp cannot assume responsibility for answering any questions about its contents.


4.2 Memory configuration

4.2.1 Memory map at power-on (80k mode)




- The memory map is as shown above immediately after the power has been turned on. (The contents of the V-RAM area from \$D000 to \$DFFF are not the same as those of MZ-80K.)
- The entry point of the monitor ROM is the same as that of the MZ-80K.

4.2.2 Memory map while loading system program (BASIC)




- When the monitor LOAD command is entered, the bootstrap loader is loaded into the system RAM area from ROM and control is transferred to that program.
- BOOT COMMAND : L

4.2.3 Memory map after the BASIC interpreter has been loaded (MZ-700 mode)




- The memory map is as shown above after the BASIC interpreter has been loaded.
- Bank switching is performed to access V-RAM or the KEY and TIMER PORT area.




4.2.4 Memory map after manual reset

The memory map is as shown below after the reset switch on the rear panel has been pressed.



After pressing the reset switch together with the **CTRL** key, the memory map is as shown below.



- When the reset switch is pressed together with the `CTRL` key, addresses \$0000 to \$0FFF and from \$D000 to \$FFFF are assigned to RAM.
- When the `#` command is entered after the reset switch has been pressed, the computer operates in the same manner as after the reset switch has been pressed together with the `CTRL` key.

4.2.5 Bank switching

- a) Memory blocks can be selected by outputting data to I/O ports as shown below.

SWITCHING

I/O PORT	\$0000~\$0FFF	\$D000~\$FFFF
\$ E0	SYSTEM AREA (D-RAM)	
\$ E1		SYSTEM AREA (D-RAM)
\$ E2	MONITOR (ROM)	
\$ E3		V-RAM, KEY, TIMER
\$ E4	MONITOR (ROM)	V-RAM, KEY, TIMER
\$ E5		Inhibit
\$ E6		Return to the front of condition, where being inhibited by \$ E5.

Note: Outputting data to I/O port \$E4 performs the same function as pressing the reset switch.

- b) Examples:

OUT (\$E0), A

Assigns addresses \$0000 to \$0FFF to RAM, but does not change execution address. The contents of variable A do not affect the result.


OUT (\$E4), A

Initializes memory to the state immediately after the power has been turned on.

Note: Since the program counter is not moved by the OUT statement, care must be taken when switching memory blocks if the program counter is located in the area from \$0000 to \$0FFF or from \$D000 to \$FFFF.

4.2.6 Memory map when V-RAM is accessed


i) V-RAM (Video RAM) memory map



ii) Correspondence between V-RAM address and location on the screen.

The MZ-700 has a 2K byte V-RAM area, but only 1K byte of that area can be displayed on the screen at one time. The area displayed can be changed by scrolling the screen.

a) Area displayed immediately after reset (or power-on):



b) Area displayed after the screen has been scrolled up one line from the end of V-RAM:


	1	2	3		39	40
1	D000 1041	D001 1042	D002 1043		D026 1079	D027 1080
2	D028 1081	D029 1082	D02A 1083		D04E 1119	D04F 1120
24	D398 1961	D399 1962	D39A 1963		D3BE 1999	D3BF 2000
25	D3C0 1	D3C1 2	D3C2 3		D3E6 39	D3E7 40

Note: The line consisting of bytes 1 to 40 is wrapped around to that consisting of bytes 1961 to 2000 as shown above.

iii) Scroll-up and scroll-down

a) The screen is scrolled up by pressing the and keys together, and is scrolled down by pressing the and keys together.

b) Scroll-up and scroll-down




- During scrolling, the area which is displayed on the screen moves through the 2K byte V-RAM area as shown above.
- The end of the V-RAM area is wrapped around to the beginning of V-RAM as shown above.
- The cursor does not move on the screen during scrolling.

4.3 Memory Mapped I/O (\$E000-\$E008)

Addresses \$E000 to \$E008 are assigned to the 8255 programmable peripheral interface, 8253 programmable interval timer and other I/O control ICs so that various I/O devices (including music functions using counter #0 of the 8253) can be accessed in the same manner as memory. The memory mapped I/O chart is shown below.


CPU memory address	Controller	Operation
\$E000 \$E001 \$E002 \$E003	8255	P _A : Output P _B : Input P _C : Input and output control by bit setting Mode control
\$E004 \$E005 \$E006 \$E007	8253	C ₀ : Mode 3 (square wave rate generator) C ₁ : Mode 2 (rate generator) C ₂ : Mode 0 (terminal counter) Mode control
\$E008	LS367, etc.	Tempo, joystick and HBLNK input



- During scrolling the area which is displayed on the screen moves through the 2K byte V-RAM area as shown above.
- The end of the V-RAM area is wrapped around to the beginning of V-RAM as shown above.
- The cursor does not move on the screen during scrolling.

4.3.1 Signal system of the 8255

The 8255 outputs keyboard scan signals, input key data, and controls the cassette tape deck and cursor blink timing.



Port	Terminal	I/O	Active state	Description of control	Name of signal
PA (\$E000)	PA ₀	OUT	H	Keyboard scan signals	
	PA ₁		H		
	PA ₂		H		
	PA ₃		H		
	PA ₇		L	Resets the cursor blink timer.	
PB (\$E001)	PB ₀	IN	L	Key scanning data input signals	
	PB ₁		L		
	PB ₂		L		
	PB ₃		L		
	PB ₄		L		
	PB ₅		L		
	PB ₆		L		
	PB ₇		L		
PC* (\$E002)	PC ₁	OUT	—	Cassette tape write data	WDATA
	PC ₂	OUT	L	Inhibits clock interrupts.	INTMSK
	PC ₃	OUT		Motor drive signal	M-ON
	PC ₄	IN	H	Indicates that the motor is on.	MOTOR
	PC ₅	IN	—	Cassette tape read data	RDATA
	PC ₆	IN	—	Cursor blink timer input signal	556 OUT
	PC ₇	IN	—	Vertical blanking signal	VBLK

* Each output data bit can be independently set or reset.


4.3.2 Signal system of the 8253

The 8253 includes three counters # 0, # 1 and # 2. Counter # 0 is used for sound generation, and counter # 1 and # 2 are used for the built-in clock.

Counter # 0 is used as a square wave rate generator (MODE 3) and counter # 1 is used as a rate generator (MODE 2). Counter # 2 is used for the interrupt on terminal count (MODE 0).

A 895 kHz pulse signal is applied to counter # 0, which divides the frequency to the specified value according to the note information. This divided signal is output to the sound generator.

Counter # 1 counts a 15.7 kHz pulse signal and outputs a pulse to OUT1 every 1 second. Counter # 2 counts the output signal from counter # 1 and outputs a high level pulse to OUT2 every 12 hours. Since OUT2 is connected to the interrupt terminal of the CPU, the CPU processes the interrupt every 12 hours.




* Each output data bit can be independently set or reset.


4.4 Signal System of Color V-RAM

Color information of the MZ-700 is controlled in character units; that is, a 1-byte color information table is assigned to each character displayed on the screen.

A color information table is shown in the figure below.




Color information tables are accessed as follows.





Characters displayed are stored at addresses \$D000 to \$D7FF of V-RAM, and color information tables are stored at addresses \$D800 to \$DFFF of V-RAM.

4.5 MZ-700 Circuit Diagrams

[CPU board circuit (1)]









[CPU board circuit (3)]


[5] Storage board (CPU)






[CPU board circuit (5)]

[CPU board circuit (5)]



Q1, Q2	2SC1675L	or	EQUIVALENT
Q3, Q5	2SC945	or	EQUIVALENT
Q4	2SA733	or	EQUIVALENT
D1~D6	ISS119	or	EQUIVALENT
D7, D8	ISS174	or	EQUIVALENT
IC 1	HD7404P	or	EQUIVALENT
IC 2	HD7486P	or	EQUIVALENT
IC 3	HD7474P	or	EQUIVALENT
IC 4	HD14066BP		
IC5, IC6	μPC1037H		



[Power unit]

[Copyright © 1995]

[CPU board terminal configuration]

[terminal configuration]

1. CPU board terminal configuration table

P-9

1	○	GND
2	○	C SYNC
3	○	C VIDEO
4	○	H SYNC
5	○	V SYNC
6	○	GND
7	○	+5V
8	○	G
9	○	B
10	○	R
11	○	COLR
12	○	GND

P-13

1	5 V
2	VBLK
3	JA 1
4	JA 2
5	GND

P-14

1	5 V
2	VBLK
3	JB 1
4	JB 2
5	GND

P-11

49	A15	NMI	50
47	A14	EXINT	48
45	A13	GND	46
43	A12	MREQ	44
41	A11	GND	42
39	A10	IORQ	40
37	A9	GND	38
35	A8	RD	36
33	A7	GND	34
31	A6	WR	32
29	A5	EXWAIT	30
27	A4	MI	28
25	A3	GND	26
23	A2	HALT	24
21	A1	EXRESET	22
19	A0	RESET	20
17	BUS \emptyset	GND	18
15	D7	GND	16
13	D6	GND	14
11	D5	GND	12
9	D4	GND	10
7	D3	GND	8
5	D2	GND	6
3	D1	GND	4
1	D0	GND	2

P-10

1	RDP	2	GND
3	RD1	4	GND
5	RD2	6	GND
7	RD3	8	GND
9	RD4	10	GND
11	RD5	12	GND
13	RD6	14	GND
15	RD7	16	GND
17	RD8	18	GND
19	IRT	20	GND
21	RDA	22	GND
23	STA	24	GND
25	FG	26	FG

P-5


1	+ 5 V
2	+ 5 V
3	GND
4	GND


P-1


1	ARDP
2	ARD1
3	ARD2
4	ARD3
5	ARD4
6	ARD5
7	ARD6
8	ARD7
9	ARD8
10	AIRT
11	GND
12	ARDA
13	GND
14	ASTA
15	ALPS

[Keyboard matrix circuit]

8255 outputs keyboard scan signals from port PA to the keyboard and reads key data from port PB. The figure below shows the key matrix.







[Color plotter-printer circuit]

Monitor Commands and Subroutines

... Loads cassette tape files into memory.
... Outputs the specified character string to the printer. (Print)
... Changes the contents of memory. (Memory correction)
... Transfers control to the specified address. (Jump)
... Saves the contents of the specified memory block to cassette tape. (Save)
... Compares the contents of cassette tape with the contents of memory.
... Transfers control to the RAM area.
... Makes the bell sound every time a key is pressed. Executing this command again stops the bell.




5.1 Monitor Commands

The monitor program starts immediately after the power is turned on and awaits input of a monitor command. The monitor commands are listed below. In this chapter, `CR` indicates that the carriage return key is to be pressed.

- L command Loads cassette tape files into memory.
- P command Outputs the specified character string to the printer. (Print)
- M command Changes the contents of memory. (Memory correction)
- J command Transfers control to the specified address. (Jump)
- S command Saves the contents of the specified memory block to cassette tape. (Save)
- V command Compares the contents of cassette tape with the contents of memory.
- # command Transfers control to the RAM area.
- B command Makes the bell sound every time a key is pressed. Executing this command again stops the bell.

■ Configuration of the monitor work area

The configuration of the monitor work area from \$1000 to \$11FF is shown below.



Note: The ROM monitor described in this chapter is not the same as the monitor function of the BASIC interpreter.

5.2 Functions and Use of Monitor Commands

This section describes the functions and use of the eight monitor commands.

- Commands are executed when the **CR** key is pressed. Characters must be entered in the correct order. If illegal characters (such as spaces) are included in a command string, the monitor rejects the command.
- All numeric data must be entered in hexadecimal form at, and all data is displayed in hexadecimal form at. Therefore, 1-byte data is represented with two hexadecimal digits and 2-byte data is represented with a four hexadecimal digits. For example, the decimal number 21 is displayed as 15 and the decimal number 10 must be typed in as 0A. The upper digit "0" cannot be omitted.
- If the number of characters typed as an operand exceeds the specified number, excess characters are discarded.
- Each command can access any location of memory. Therefore, the monitor program may be changed if the commands are used carelessly. **Since this can result in loss of control over the system, be careful to avoid changing the contents of the monitor program.**

5.2.1 L command

Format

L

Function

This command loads the first machine language file encountered on the cassette tape into memory. After the L command is entered, the display changes as follows.

```
*L↓
```

```
↓ PLAY
```

Press the **PLAY** key of the data recorder. When a machine language program is found, the message "LOADING program-name" is displayed. For example, the following message is displayed during loading of the BASIC interpreter.

```
LOADING BASIC
```

5.2.2 P command (P : Printer)

Function

This command is used as follows to control the plotter printer:

*PABC J

Prints the letters "ABC".

*P&T J

Prints the test pattern.

*P&S J

Sets the line width (character size) to 80 characters/line.

*P&L J

Sets the line width (character size) to 40 characters/line.

*P&G J

Switches the printer to the graphic mode.

*P&C J

Changes the pen color.

5.2.3 M command (M : Memory modification)

Format

M h h h h

h h h h starting address

Function

This command is used to change the contents of memory a byte at a time, starting at the specified address.

*MC000 J

C000 00 FF

C001 00 FF

C002 00 FF

C003 00 FF

C004 00 FF

*MC010 J

C010 00 88

C011 00 88

C012 00 88

C013 00 88

C014 00

[SHIFT] + [BREAK]

*

To terminate the M command, simultaneously press the [SHIFT] and [BREAK] keys.

5.2.6 V command (V : Verify)

Format

V

Function

Compares a machine language cassette file saved using the S command with the original program in memory.

*V ↵

↓ PLAY

OK

Press the PLAY key to read the cassette tape file when the prompt "↓ PLAY" is displayed. The message "OK" is displayed when the contents of the cassette file matches that of the original program; otherwise, the message "CHECK SUM ER." is displayed.

It is recommended that this command be executed immediately after recording a program with the S command.

5.2.7 # command

Format

#

Function

After pressing the RESET switch, executing this command produces the same effect as simultaneously pressing the RESET switch and the CTRL key.

*# ↵

5.2.8 B command (B : Bell)

Format

B

Function

*B ↵

Executing this command once causes the bell to ring each time a key is pressed. Executing it again disables the bell.

5.3 Monitor Subroutines


The following subroutines are provided for **Monitor 1Z-013A**. Each subroutine name symbolically represents the function of the corresponding subroutine. These subroutines can be called from user programs.

Registers saved are those whose contents are restored when control is returned to the calling program. The contents of other registers are changed by execution of the subroutine.

Name and entry point (hex.)	Function	Register saved
CALL LETNL (0006)	Moves the cursor to the beginning of the next line.	Other than AF
CALL PRINTS (000C)	Displays a space at the cursor position.	Other than AF
CALL PRINTS (0012)	Displays the character corresponding to the ASCII code stored in ACC at the cursor position. See Appendix A. 1 for the ASCII codes. No character is displayed when code 0D (carriage return) or 11 to 16 (the cursor control codes) is entered, but the corresponding function is performed (a carriage return for 0D and cursor movement for 11 to 16).	Other than AF
CALL MSG (0015)	Displays a message, starting at the position of the cursor. The starting address of the area in which the message is stored must be set in the DE register before calling this subroutine, and the message must end with a carriage return code (0D). The carriage return is not executed. The cursor is moved if any cursor control codes (11 to 16) are included in the message.	All registers
CALL BELL (003E)	Briefly sounds high A (about 880 Hz).	Other AF
CALL MELDY (0030)	Plays music according to music data stored in the memory area starting at the address indicated in the DE register. The music data must be in the same format as that for the MUSIC statement of the BASIC, and must end with 0D or C8. When play is completed, control is returned to the calling program with the C flag set to 0; when play is interrupted with the BREAK key, control is returned with the C flag set to 1.	Other than AF
CALL XTEMP (0041)	Sets the musical tempo according to the tempo data stored in the accumulator (ACC). ACC ← 01 Slowest speed ACC ← 04 Middle speed ACC ← 07 Highest speed Note that the data in the accumulator is not the ASCII code corresponding to 1 to 7 but the binary code.	All registers
CALL MSTA (0044)	Generates a continuous sound of the specified frequency. The frequency is given by the following equation. freq. = 895 kHz/nn'. Here, nn' is a 2-byte number stored in addresses 11A1 and 11A2 (n in 11A2 and n' in 11A1).	BC and DE

Name and entry point (hex.)	Function	Register saved	
CALL MSTP (0047)	Stops the sound generated with the CALL MSTA subroutine.	Other than AF	
CALL TIMST (0033)	Sets and starts the built-in clock. Registers must be set as follows before this routine is called. ACC ← 0 (AM), ACC ← 1 (PM) DE ← 4-digit hexadecimal number representing the time in seconds.	Other than AF	
CALL TIMRD (003B)	Reads the built-in clock and returns the time as follows. ACC ← 0 (AM), ACC ← 1 (PM) DE ← 4-digit hexadecimal number representing the time in seconds.	Other than AF and DE	
CALL BRKEY (001E)	Checks whether the <input type="checkbox"/> SHIFT and <input type="checkbox"/> BREAK keys are both being pressed. The Z flag is set when they are being pressed simultaneously; otherwise, it is reset.	Other than AF	
CALL GETL (0003)	Reads one line of data from the keyboard and stores it in the memory area starting at the address indicated in the DE register. This routine stops reading data when the RETURN key is pressed, then appends a carriage return code (0D) to the end of the data read. A maximum of 80 characters (including the carriage return code) can be entered in one line. Characters keyed in are echoed back to the display, and cursor control codes can be included in the line. When the <input type="checkbox"/> SHIFT and <input type="checkbox"/> BREAK keys are pressed simultaneously, BREAK code is stored in the address indicated in the DE register and a carriage return code is stored in the subsequent address.	All registers	
CALL GETKY (001B)	Reads a character code (ASCII) from the keyboard. If no key is pressed, control is returned to the calling program with 00 set in ACC. No provision is made to avoid data read errors due to key chatter, and characters entered are not echoed back to the display. When any of the special keys (such as <input type="checkbox"/> DEL or <input type="checkbox"/> CR) are pressed, this subroutine returns a code to ACC which is different from the corresponding ASCII code as shown below. Here, display codes are used to address characters stored in the cahracter generator, and are different from the ASCII codes.	Other than AF	
Special key read with GETKY	Special key	Code set in ACC	Display code
	DEL INST ALPHA BREAK CR <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> HOME <input type="checkbox"/> CLR	60 61 62 64 66 11 12 13 14 15 16	C7 C8 C9 CB CD C1 C2 C3 C4 C5 C6

APPENDICES



A.1 Code Tables

■ ASCII code table

MSD is an abbreviation for most significant digit, and represents the upper 4 bits of each code; LSD is an abbreviation for least significant digit, and represents the lower 4 bits of each code. Codes 11_H to 16_H are cursor control codes. For example, executing CALL PRNT (a monitor subroutine) with 15_H set in ACC returns the cursor to the home position. ("▣" is not displayed.)

MSD \ LSD		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
		0000	0001	0010	0011	0100	0101	0110	0111	1000	1001	1010	1011	1100	1101	1110	1111
0	0000		SP	0	@	P	☛	▣	}	—	q	n		▣	▣	▣	▣
1	0001	↓	!	1	A	Q	H	▣	▣	▣	a	▣	▣	▣	▣	♠	●
2	0010	↑	"	2	B	R	I	▣	▣	e	z	Ü	▣	▣	▣	▣	▣
3	0011	→	#	3	C	S	♣	▣	▣	`	w	m	▣	▣	▣	▣	♥
4	0100	←	\$	4	D	T	♣	▣	▣	~	s	▣	▣	▣	▣	▣	▣
5	0101	H	%	5	E	U	♣	▣	▣	▣	u	▣	▣	▣	▣	▣	▣
6	0110	Ⓒ	&	6	F	V	¥	▣	▣	t	i	▣	→	▣	▣	▣	⊗
7	0111	'	7	G	W	☺	▣	▣	g	▣	o	▣	▣	▣	▣	▣	○
8	1000	(8	H	X	☺	▣	▣	h	ö	l	▣	▣	▣	▣	▣	♣
9	1001)	9	I	Y	☹	▣	▣	▣	k	Ä	▣	▣	▣	▣	▣	▣
A	1010	*	:	J	Z	♣	▣	▣	▣	b	f	ö	▣	▣	▣	▣	♦
B	1011	+	;	K	[♣	°	^	x	v	ä	▣	▣	▣	▣	▣	£
C	1100	,	<	L	\	▣	▣	▣	d	▣	▣	▣	▣	▣	▣	▣	↓
D	1101	CR	—	=	M]	▣	▣	r	ü	y	▣	▣	▣	▣	▣	▣
E	1110	.	>	N	↑	▣	▣	▣	p	β	{	▣	▣	▣	▣	▣	▣
F	1111	/	?	O	←	▣	▣	▣	c	j	▣	▣	▣	▣	▣	▣	π

■ Display code table

The display codes are used to address character patterns stored in the character generator. These codes must be transferred to video-RAM to display characters.

Monitor subroutines PRNT (0012H) and MSG (0015H) convert ASCII codes into display codes and transfer them to the V-RAM location indicated for the cursor.

Codes C1H to C6H are for controlling the cursor.

MSD LSD		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
		0000	0001	0010	0011	0100	0101	0110	0111	1000	1001	1010	1011	1100	1101	1110	1111
0	0000	SP	P	O	□	}	↑	π	□		p	▤	▥	↓	▩	▮	SP
1	0001	A	Q	I	□	♠	<	!	□	a	q	▨	▩	↓	▩	▮	□
2	0010	B	R	2	□	▤	□	"	□	b	r	▨	▩	↑	▩	▮	□
3	0011	C	S	3	□	■	♥	#	□	c	s	▩	▩	→	▩	▮	□
4	0100	D	T	4	▬	♦]	\$	▬	d	t	'	▩	←	▩	▮	□
5	0101	E	U	5	▮	←	@	%	▮	e	u	~	▩	▩	▩	▮	□
6	0110	F	V	6	□	♣	▤	&	▨	f	v	▩	▩	☉	▩	▮	□
7	0111	G	W	7	□	●	>	'	▨	g	w	▩	▩	♣	▩	▮	□
8	1000	H	X	8	▬	○	↓	(▬	h	x	▩	▩	H	▩	▮	□
9	1001	I	Y	9	▮	?	▨)	▮	i	y	▩	▩	H	▩	▮	□
A	1010	J	Z	-	▬	○	→	+	▬	j	z	β	▩	♣	▩	▮	□
B	1011	K	&	=	▬	▩	▩	*	▬	k	ä	ü	▩	♣	°	Y	▩
C	1100	L	▨	;	□	▩	▩	▩	▬	l	▩	ö	{	♣	▩	▮	▩
D	1101	M	▨	▨	□	▤	▩	▩	▬	m	▩	Ü	▩	¥	▩	▮	▩
E	1110	N	▨	.	▬	▤	▩	▩	▬	n	▩	Ä	^	☉	▩	▮	▩
F	1111	O	▨	,	▬	:	▩	▩	▬	o	▩	Ö	▬	☺	▩	▩	▩

The character patterns on the former page are contained in the 2K bytes which make up the first half of CG-ROM. Character patterns for the second half of CG-ROM are shown on the latter page. However, character patterns in the second 2K bytes of the CG-ROM are not supported by BASIC, and cannot be entered directly from the keyboard. Although they can be displayed using the POKE statement as shown in the example below, they cannot be output to any printer (either the built-in printer or an external printer).

< Examples >

(1) The following program example displays character patterns from the second half of CG-ROM on the CRT screen.

```

10 COLOR, , 7, 0
20 PRINT " ";
30 FOR J=55296 TO 56296 → 55296 = $D800
40 POKE J, 240 → Specifies the second 2K-byte
50 NEXT J → half of CG-ROM. 240 = $F0
60 A=53248 : I=0 : H=0 → 53248 = $D000
70 POKE A, I
80 A=A+2
90 I=I+1 : IF I=256 THEN GOTO 120
100 H=H+1 : IF H=20 THEN A=A+40 : H=0
110 GOTO 70
120 GOTO 120

```

(2) The example below illustrates using machine language to display character patterns from the second half of CG-ROM on the CRT screen.

```

LD HL, D000H          DISP : XOR A
CALL DISP            LD B, 00H
LD HL, D208H         DISP2 : LD (HL), A
CALL DISP            INC HL
LD A, F1H            INC A
LD HL, DA08H         DEC B
LD DE, DA09H         JP NZ, DISP2
LD BC, 00FFH        RET
LD (HL), A
LD IR
END

```


■ MZ-700 Display code table (second 2K-byte half)

MSD LSD		0 0000	1 0001	2 0010	3 0011	4 0100	5 0101	6 0110	7 0111	8 1000	9 1001	A 1010	B 1011	C 1100	D 1101	E 1110	F 1111
0	0000																
1	0001																
2	0010																
3	0011																
4	0100																
5	0101																
6	0110																
7	0111																
8	1000																
9	1001																
A	1010																
B	1011																
C	1100																
D	1101																
E	1110																
F	1111																

■ ASCII code table for color plotter-printer

■ MS-700 display code table (second 2K-byte half)

Graphic characters other than those shown above cannot be printed, but the corresponding hexadecimal code is printed in a different pen color.

MSD LSD	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0			SP	Ø	@	P			}		q	n				
1		↓	∩	1	A	Q					a					
2		↑	"	2	B	R				e	Z	ü				
3		→	#	3	C	S				´	w	Ɔ				
4		←	\$	4	D	T				˘	s					
5		H	%	5	E	U					u					
6		◻	&	6	F	V				t	ı		→			
7			/	7	G	W				g	o			▬		
8			(8	H	X				h	ö	ı				
9)	9	I	Y					k	ä				
A			*	:	J	Ɔ				b	f	ö				
B			+	;	K	[◻	^	x	v	ä				Ɔ
C			9	<	L	\				d						↓
D			-	=	M]				Ɔ	ü	y				
E			◻	>	N	↑				p	Ɔ	{				
F			/	?	O	←				c	j		▬			π

A.2 MZ-700 Series Computer Specifications

A.2.1 MZ-700

CPU:	SHARP LH0080A (Z80A)
Clock:	3.5 MHz
Memory:	ROM 4K bytes (ROM) 2K bytes (character generator) RAM 64K bytes (program area) 4K bytes (video RAM)
Video output:	PAL system RGB signal Composite signal (B/W) RF signal (UHF 36 ± 3 CH, B/W)
Screen size:	40 characters x 25 lines 8 x 8 dot character matrix
Colors:	8 colors for characters 8 colors for background
Music function:	Built in (500 mW max. output)
Clock:	Built in (24 hour clock, no backup)
Keys:	69 keys ASCII standard Definable function keys, cursor control keys
Editing function:	Screen editor (cursor control, home, clear, insert, and delete)
Temperature:	Operating; 0 ~ 35°C Storage; -20 ~ 60°C
Humidity:	Operating; 85% or less Storage; 85% or less
Dimensions:	MZ-731; 400 (W) x 305 (D) x 102 (H) mm MZ-721; 440 (W) x 305 (D) x 86 (H) mm MZ-711; 440 (W) x 305 (D) x 86 (H) mm
Weight:	MZ-731; 4.6 kg MZ-721; 4.0 kg MZ-711; 3.6 kg
Accessories:	Cassette tape (BASIC (side A) Application programs (side B)) Owners manual, function labels, power cable, TV connection cable Attachments for the color plotter-printer are listed later.

A.2.2 CPU board specifications

CPU:	LH0080A (Z80A)	1
PPI:	8255	1
PIT:	8253	1
Memory controller		
(CRTC):	M60719	1
ROM:	Monitor 4K byte ROM	1
	Character generator 2K byte ROM	1
RAM:	64K bits D-RAM	8
	2K byte S-RAM	2
I/O bus:	Expansion I/O bus	1
	Printer I/O bus	2 (Cannot be used at the same time)
	Cassette READ/WRITE terminals	2
	Joystick terminal	2

A.2.3 Color plotter-printer specifications

Printing system:	4 selectable colors using ball point pens
Colors:	1. Black, 2. Blue, 3. Green, 4. Red
Printing speed:	Average 10 characters/second when printing with the smallest size characters.
Line width:	80 columns, 40 columns, or 26 columns (selected by software)
Number of characters:	115 (including ASCII characters)
Resolution:	0.2 mm
Accessories:	Roll paper (1), Ball pens (black, blue, green red) Paper holders (left and right) Roll shaft (1), Paper guide (1)

A.2.4 Data recorder specifications

Type:	IEC standard compact cassette mechanism
Recording/ playback system:	2 track, 1 channel monophonic
Rated speed:	4.8 cm/s \pm 3.5%
Type of control switches:	Piano type
Control switches:	PLAY, FF, REW, STOP/EJECT, and REC keys and counter reset button
Data transfer method:	Sharp PWM method
Data transfer rate:	1200 bps (typ.)
Tape:	Ordinary audio cassette tape

A.2.5 Power supply specifications

(Supplies power to the color plotter-printer and data recorder, as well as to the main unit.)

Input:	240/220 V \pm 10%, 50/60 Hz, 20 W
Output:	5 V

A.3 BASIC Error Message List

The BASIC interpreter displays an error message in one of the following formats when an error occurs during operation.

- | | |
|--|---------------------|
| 1. < error type > error | (Direct mode error) |
| 2. < error type > error in line number | (Run mode error) |

Error messages in format 1 are issued when an error is detected during execution of a direct command or entry of a program. Error messages in format 2 are issued when an error is detected during program execution.

Error messages which may be displayed are shown below.






SYNTAX









Error No.	Message displayed	Description
1	Syntax error	Syntax error
2	Over flow error	Numeric data used is out of the specified range, or an overflow occurred.
3	Illegal data error	Illegal constant or variable was used.
5	String length error	String length exceeded 255 characters.
6	Memory capacity error	Memory capacity is insufficient.
7	Array def. error	An attempt was made to redefine an array to a size greater than that defined previously.
8	Linelenh error	The length of a line was too long.
10	GOSUB nesting error	The number of levels of GOSUB nesting exceeded the limit determined by the usable memory space.
11	FOR~NEXT error	The number of levels of FOR~NEXT loops exceeded the limit determined by the usable memory area.
12	DEF FN nesting error	The number of levels of DEF FN nesting exceeded the limit.
13	NEXT error	NEXT was used without a corresponding FOR.
14	RETURN error	RETURN was used without a corresponding GOSUB.
15	Un def. function error	An undefined function was called.
16	Un def. line num. error	An unused line number was referenced.
17	Can't continue	CONT command cannot be executed.
18	Memory protection	An attempt was made to write data to the BASIC control area.
19	Instruction error	Direct mode commands and statements are mixed together.
20	Can't RESUME error	RESUME cannot be executed.
21	RESUME error	An attempt was made to execute RESUME when no error had occurred.
24	READ error	READ was used without a corresponding DATA statement.
43	Already open error	An OPEN statement was issued to a file which was already open.
63	Out of file error	Out of file during file read.
65	Printer is not ready	Printer is not connected.
68	Printer mode error	Color plotter-printer mode error.
70	Check sum error	Check sum error (during tape read).

A. 4 Z80A Instruction Set

A summary of the Z80A instructions are given below for reference.

Mnemonic	Symbolic operation	Op-code	Mnemonic	Symbolic operation	Op-code
8-bit load group			LD HL, (nn)	H←(nn+1) L←(nn)	00 101 010 ← n → ← n →
LD r, r'	r←r'	01 r r'	LD dd, (nn)	dd _H ←(nn+1) dd _L ←(nn)	11 101 101 ← n → ← n →
LD r, n	r←n	00 r 110 ← n →	LD IX, (nn)	IX _H ←(nn+1) IX _L ←(nn)	11 011 101 ← n → ← n →
LD r, (HL)	r←(HL)	01 r 110	LD IY, (nn)	IY _H ←(nn+1) IY _L ←(nn)	11 011 101 ← n → ← n →
LD r, (IX+d)	r←(IX+d)	11 011 101 01 r 110 ← d →	LD (nn), HL	(nn+1)←H (nn)←L	00 101 010 ← n → ← n →
LD r, (IY+d)	r←(IY+d)	11 111 101 01 r 110 ← d →	LD (nn), dd	(nn+1)←dd _H (nn)←dd _L	11 111 101 ← n → ← n →
LD (HL), r	(HL)←r	01 110 r	LD (nn), IX	(nn+1)←IX _H (nn)←IX _L	11 110 r ← d → ← n →
LD (IX+d), r	(IX+d)←r	11 011 101 01 110 r ← d →	LD (nn), IY	(nn+1)←IY _H (nn)←IY _L	11 011 101 ← d → ← n →
LD (IY+d), r	(IY+d)←r	11 111 101 01 110 r ← d →	LD SP, HL	SP←HL	00 110 r ← d → ← n →
LD (HL), n	(HL)←n	00 110 110 ← n →	LD SP, IX	SP←IX	11 110 110 ← n →
LD (IX+d), n	(IX+d)←n	11 011 101 00 110 110 ← d →	LD SP, IY	SP←IY	11 011 101 ← n →
LD (IY+d), n	(IY+d)←n	11 111 101 00 110 110 ← d →	PUSH qq	(SP-2)←qq _L (SP-1)←qq _H	11 111 101 ← d → ← n →
LD A, (BC)	A←(BC)	00 001 010	PUSH IX	(SP-2)←IX _L (SP-1)←IX _H	00 001 010 ← n →
LD A, (DE)	A←(DE)	00 011 010	PUSH IY	(SP-2)←IY _L (SP-1)←IY _H	00 011 010 ← n →
LD A, (nn)	A←(nn)	00 111 010 ← n →	POP qq	qq _H ←(SP+1) qq _L ←(SP)	00 111 010 ← n →
LD (BC), A	(BC)←A	00 000 010	POP IX	IX _H ←(SP+1) IX _L ←(SP)	00 000 010 ← n →
LD (DE), A	(DE)←A	00 010 010	POP IY	IY _H ←(SP+1) IY _L ←(SP)	00 010 010 ← n →
LD (nn), A	(nn)←A	00 110 010 ← n →			00 110 010 ← n →
LD A, I	A←I	11 101 101 01 010 111			11 101 101 ← n →
LD A, R	A←R	11 101 101 01 011 111			11 101 101 ← n →
LD I, A	I←A	11 101 101 01 000 111			11 101 101 ← n →
LD R, A	R←A	11 101 101 01 001 111			11 101 101 ← n →
16-bit load group			Exchange group and block transfer and search group		
LD dd, nn	dd←nn	00 dd0 001 ← n → ← n →	EX DE, HL	DE↔HL	11 101 011
LD IX, nn	IX←nn	11 011 101 00 100 001 ← n → ← n →	EX AF, AF'	AF↔AF'	00 001 000
LD IY, nn	IY←nn	11 111 101 00 100 001 ← n → ← n →	EXX	(BC)↔(BC') (DE)↔(DE') (HL)↔(HL')	11 011 001
			EX (SP), HL	H↔(SP+1) L↔(SP)	11 100 011
			EX (SP), IX	IX _H ↔(SP+1) IX _L ↔(SP)	11 011 101
			EX (SP), IY	IY _H ↔(SP+1) IY _L ↔(SP)	11 100 011 11 111 101 11 100 011

Mnemonic	Symbolic operation	Op-code	Mnemonic	Symbolic operation	Op-code
LDI	(DE)←(HL) DE←DE+1	11 101 101 10 100 000	DEC m	m←m-1	← d → 101
LDIR	HL←HL+1 BC←BC-1 (DE)←(HL) DE←DE+1 HL←HL+1 BC←BC-1 Repeat until BC=0	11 101 101 10 110 000	General purpose arithmetic and control group		
LDD	(DE)←(HL) DE←DE-1 HL←HL-1 BC←BC-1	11 101 101 10 101 000	DAA	Decimal adjustment upon contents of A after add or subtract	00 100 111
LDDR	(DE)←(HL) DE←DE-1 HL←HL-1 BC←BC-1 Repeat until BC=0	11 101 101 10 111 000	CPL	A← \overline{A}	00 101 111
CPI	A-(HL) HL←HL+1 BC←BC-1	11 101 101 10 100 001	NEG	A← $\overline{A}+1$	11 101 101 01 000 100
CPIR	A-(HL) HL←HL+1 BC←BC-1 Repeat until A=(HL) or BC=0	11 101 101 10 110 001	CCF	CY← \overline{CY}	00 111 111
CPD	A-(HL) HL←HL-1 BC←BC-1	11 101 101 10 101 001	SCF	CY←1	00 110 111
CPDR	A-(HL) HL←HL-1 BC←BC-1 Repeat until A=(HL) or BC=0	11 101 001 10 111 001	NOP	No operation, but PC is incremented.	00 000 000
8-bit arithmetic and logical group			HALT	CPU halted	01 110 110
ADD A, r	A←A+r	10 000 r	DI	IFF←0	11 110 011
AD A, n	A←A+n	11 000 110 ← n →	EI	IFF←1	11 111 011
ADD A, (HL)	A←A+(HL)	10 000 110	IM0	Set interrupt mode 0	11 101 101 01 000 110
ADD A, (IX+d)	A←A, (IX+d)	11 011 101 10 000 110 ← d →	IM1	Set interrupt mode 1	11 101 101 01 010 110
ADD A, (IY+d)	A←A+(IY+d)	11 111 101 10 000 110 ← d →	IM2	Set interrupt mode 2	11 101 101 01 011 110
ADC A, s	A←A+s+CY	001	16-bit arithmetic group		
SUB s	A←A-s	010	ADD HL, ss	HL←HL+ss	00 ss1 001
SBC A, s	A←A-s-CY	011	ADC HL, ss	HL←HL+ss+CY	11 101 101 01 ss1 010
AND s	A←A∧s	100	SBC HL, ss	HL←HL-ss-CY	11 101 101 01 ss0 010
OR s	A←A∨s	110	ADD IX, pp	IX←IX+pp	11 011 101 00 pp1 001
XOR s	A←A⊕s	101	ADD IY, rr	IY←IY+rr	11 111 101 00 rr1 001
CP s	A-s	111	INC ss	ss←ss+1	00 ss0 011
INC r	r←r+1	00 r 100	INC IX	IX←IX+1	11 011 101 00 100 011
INC (HL)	(HL)←(HL)+1	00 110 100	INC IY	IY←IY+1	11 111 101 00 100 011
INC (IX+d)	(IX+d) ←(IX+d)+1	11 011 101 00 110 100 ← d →	DEC ss	ss←ss-1	00 ss1 011
INC (IY+d)	(IY+d) ←(IY+d)+1	11 111 101 00 110 100 ← d →	DEC IX	IX←IX-1	11 011 101 00 101 011
			DEC IY	IY←IY-1	11 111 101 00 101 011
Rotate and shift group			Rotate and shift group		
			RLCA		00 000 111
			RLA		00 010 111
			RRCA		00 001 111
			RRA		00 011 111
			RLC r		11 001 011 00 000 r
			RLC (HL)		11 001 011 00 000 011 00 000 110

Mnemonic	Symbolic operation	Op-code	Mnemonic	Symbolic operation	Op-code
RLC (IX+d)		11 011 101 11 001 011 ← d → 00 000 110	Jump group		
RLC (IY+d)		11 111 011 11 001 011 ← d → 00 000 110	JP nn	PC←nn	11 000 011 ← n → ← n →
RL m		010	JP cc, nn	If condition cc is true, PC←-nn; otherwise, continue	11 cc 010 ← n → ← n →
RRC m		001	JR e	PC←PC+e	00 011 000 ← e-2 →
RR m		011	JR C, e	If C=0, continue. If C=1, PC←PC+e	00 111 000 ← e-2 →
SLA m		100	JR Z, e	If Z=0, continue. If C=1, PC←PC+e	00 101 000 ← e-2 →
SRA m		101	JR NC, e	If C=1, continue. If C=0, PC←PC+e	00 110 000 ← e-2 →
SRL m		111	JR NZ, e	If Z=1, continue. If Z=0, PC←PC+e	00 100 000 ← e-2 →
RLD		11 101 101 01 101 111	JP (HL)	PC←HL	11 101 001
RRD		11 101 101 01 100 111	JP (IX)	PC←IX	11 011 101
Bit set, reset and test group			JP (IY)	PC←IY	11 111 101
BIT b, r	Z←rb	11 001 011 01 b r	DJNZ e	B←B-1 If B=0, continue; otherwise, PC←PC+e	11 101 001 00 010 000 ← e-2 →
BIT b, (HL)	Z←(HL)b	11 011 011 01 b 110	Call and return group		
BIT b, (IX+d)	Z←(IX+d)b	11 011 101 11 001 011 ← d → 01 b 110	CALL nn	(SP-1)←PC _H (SP-2)←PC _L PC←nn	11 001 101 ← n → ← n →
BIT b, (IY+d)	Z←(IY+d)b	11 111 101 11 001 011 ← d → 01 b 110	CALL cc, nn	If condition cc is false, continue; otherwise same as CALL nn.	11 cc 100 ← n → ← n →
SET b, r	rb←1	11 001 011 11 b r	RET	PC _L ←(SP) PC _H ←(SP+1)	11 001 001
SET b, (HL)	(HL)b←1	11 001 011 11 b 110	RET cc	If condition cc is false, continue; otherwise same as RET.	11 cc 000
SET b, (IX+d)	(IX+d)b←1	11 001 101 11 001 011 ← d → 11 b 110	RETI	Return from interrupt	11 101 101
SET b, (IY+d)	(IY+d)b←1	11 111 101 11 001 011 ← d → 11 b 110	RETN	Return from NMI.	01 001 101 11 101 101
RES b, m	mb←0	11 001 011 ← d → 11 b 110 10	RST p	(SP-1)←PC _H (SP-2)←PC _L PC _H ←0 PC _L ←p	01 000 101 11 t 111

Mnemonic	Symbolic operation	Op-code	Mnemonic	Symbolic operation	Op-code
Input and output group					
IN A, (n)	A ← (n)	11 011 011	OUT (n), A	(n) ← A	11 010 011
		← n →			
IN r, (C)	r ← (C)	11 101 101	OUT (C), r	(C) ← r	11 101 101
		01 r 000			01 r 001
INI	(HL) ← (C)	11 101 101	OUTI	(C) ← (HL)	11 101 101
	B ← B - 1	10 100 010		B ← B - 1	10 100 011
	HL ← HL + 1			HL ← HL + 1	
INIR	(HL) ← (C)	11 101 101	OTIR	(C) ← (HL)	11 101 101
	B ← B - 1	10 110 010		B ← B - 1	10 110 011
	HL ← HL + 1			HL ← HL + 1	
	Repeat until B = 0		OUTD	Repeat until B = 0	
IND	(HL) ← (C)	11 101 101		(C) ← (HL)	11 101 101
	B ← B - 1	10 101 010		B ← B - 1	10 101 011
	HL ← HL - 1			HL ← HL - 1	
INDR	(HL) ← (C)	11 101 101	OTDR	(C) ← (HL)	11 101 101
	B ← B - 1	10 111 010		B ← B - 1	10 111 011
	HL ← HL - 1			HL ← HL - 1	
	Repeat until B = 0			Repeat until B = 0	

(Note) The meanings of symbols used in the above table are as follows.

r, r'	Register	dd, ss	Register pair	qq	Register pair	pp	Register pair
000	B	00	BC	00	BC	00	BC
001	C	01	DE	01	DE	01	DE
010	D	10	HL	10	HL	10	IX
011	E	11	SP	11	AF	11	SP
100	H						
101	L						
111	A						

rr	Register pair	b	Bit set	cc	Condition	t	p
00	BC	000	0	000	NZ non zero	000	00H
01	DE	001	1	001	Z zero	001	08H
10	IX	010	2	010	NC non carry	010	10H
11	SP	011	3	011	C carry	011	18H
		100	4	100	PO parity odd	100	20H
		101	5	101	PE parity even	101	28H
		110	6	110	P sign positive	110	30H
		111	7	111	M sign negative	111	38H

∧ : AND operation	101	5
∨ : OR operation	110	6
⊕ : Exclusive OR operation	111	7

s : r, n, (HL), (IX + d), (IY + d)

CY: Carry flip-flop

(register pair)H: Upper 8 bits of register pair

m : r, (HL), (IX + d), (IY + d)

m_b : Bit b or location m

(register pair)L: Lower 8 bits of register pair

For op-codes ADC, SUB, SBC, AND, OR, XOR and CP, the bits in replace in the ADD set.

For op-code DEC, replaces in the INC set.

Similar operations apply to op-codes of the rotate and shift group and bit set, reset and test group.

A.5 Monitor Program Assembly List

An assembly listing of the MONITOR 1Z-013A is provided on the following pages.

This assembly list was produced with the Z80 assembler contained in the floppy DOS. The meanings of symbols in the list are as follows.

Relative address	Assembler message		Mnemonic (op-code)		Comment
	Relocatable object code	Label	Operand		
20	02A7	13	INC	DE	
21	02A8	13	INC	DE	
22	02A9	13	INC	DE	
23	02AA	C9	RET		
24	02AB				
25	02AB				
26	02AB				
27	02AB				
28	02AB				
29	02AB				
30	02AB				
31	02AB				
32	02AB	2AA111	LD	HL, (RATIO)	
33	02AE	7C	LD	A, H	
34	02AF	B7	OR	A	
35	02B0	280C	JR	Z, MLDSP	
36	02B2	D5	PUSH	DE	
37	02B3	EB	EX	DE, HL	
38	02B4	2104E0	LD	HL, CONTO	
39	02B7	73	LD	(HL), E	
40	02B8	72	LD	(HL), D	
41	02B9	3E01	LD	A, 1	
42	02BB	D1	POP	DE	
43	02BC	1806	JR	MLDS1	
44	02BE				
45	02BE				
46	02BE	3E36	LD	A, 36H	; MODE SET (8253 C0)
47	02C0	3207E0	LD	(CONTF), A	; E007H
48	02C3	AF	XOR	A	
49	02C4	3208E0	LD	(SUNDB), A	; E00BH
50	02C7	C9	RET		; TEHRO RESET

Since the starting address of Monitor 1Z-013A is set to \$0000, relocatable addresses and object codes in the assembly list can be assumed as absolute addresses and object code, respectively.

This assembly list is provided for reference, only and the Sharp Corporation can assume no responsibility for answering any question about it.

Note that this monitor differs from the monitor program included in the BASIC interpreter.

```

01 0000      ;
02 0000      ;
03 0000      ;   MONITOR PROGRAM 1Z-013A
04 0000      ;
05 0000      ;   (MZ-700) FOR PAL
06 0000      ;
07 0000      ;   REV. 83.4.7
08 0000      ;
09 0000      ;
10 0000      ;
11 0000 C34A00   MONIT: ENT
12 0003      ;   JP   START      ; MONITOR ON
13 0003 C3E607   GETL:  ENT
14 0006      ;   JP   ?GETL     ; GET LINE (END 'CR')
15 0006 C30E09   LETNL: ENT
16 0009      ;   JP   ?LTNL     ; NEW LINE
17 0009 C31809   NL:      ENT
18 000C      ;   JP   ?NL       ;
19 000C C32009   PRNTS: ENT
20 000F      ;   JP   ?PRTS    ; PRINT SPACE
21 000F C32409   PRNTT: ENT
22 0012      ;   JP   ?PRTT    ; PRINT TAB
23 0012 C33509   PRNT:  ENT
24 0015      ;   JP   ?PRNT    ; 1 CHARACTER PRINT
25 0015 C39308   MSG:   ENT
26 0018      ;   JP   ?MSG     ; 1 LINE PRINT (END 'ODH')
27 0018 C3A108   MSGX:  ENT
28 001B      ;   JP   ?MSGX   ; RST 3
29 001B C3BD08   GETKY: ENT
30 001E      ;   JP   ?GET     ; GET KEY
31 001E C3320A   BRKEY: ENT
32 0021      ;   JP   ?BRK     ; GET BREAK
33 0021 C33604   WRINF: ENT
34 0024      ;   JP   ?WRI     ; WRITE INFORMATION
35 0024 C37504   WRDAT: ENT
36 0027      ;   JP   ?WRD     ; WRITE DATA
37 0027 C3D804   RDINF: ENT
38 002A      ;   JP   ?RDI     ; READ INFORMATION
39 002A C3F804   RDDAT: ENT
40 002D      ;   JP   ?RDD     ; READ DATA
41 002D C38805   VERFY: ENT
42 0030      ;   JP   ?VRFY   ; VERIFYING CMT
43 0030 C3C701   MELDY: ENT
44 0033      ;   JP   ?MLDY   ; RST 6
45 0033 C30803   TIMST: ENT
46 0036 00      ;   NOP             ; TIME SET
47 0037 00      ;   NOP             ;
48 0038 C33810   TIMRD: ENT
49 003B      ;   JP   1038H    ; INTERRUPT ROUTINE
50 003B C35803   BEL:   ENT
51 003E      ;   JP   ?TMRD   ; TIME READ
52 003E C37705   XTEMP: ENT
53 0041      ;   JP   ?BEL     ; BELL ON
54 0041 C3E502   NSTA:  ENT
55 0044      ;   JP   ?TEMP    ; TEMPO SET (1+7)
56 0044 C3AB02   MSTP:  ENT
57 0047      ;   JP   MLDST   ; MELODY START
58 0047 C3BE02   MSTP:  ENT
59 004A      ;   JP   MLDSP   ; MELODY STOP
60 004A      ;

```

```

01 004A      ;
02 004A      ;   START: ENT
03 004A 31F010   LD   SP,SP      ; STACK SET (10F0H)
04 004D ED56     IM   1          ; IM 1 SET
05 004F CD3E07   CALL ?MODE     ; 8255,8253 MODE SET
06 0052 CD320A   CALL ?BRK     ; CTRL ?
07 0055 3019    JR   NC,STO    ;
08 0057 FE20    CP   20H      ; KEY IS CTRL KEY
09 0059 2015    JR   NZ,STO    ;
10 005B      ;
11 005B D3E1    OUT  (E1H),A    ; D000H-FFFFH IS DRAM
12 005D 11F0FF  LD   DE,FFF0H  ; TRANS. ADR.
13 0060 216B00  LD   HL,$MCP   ; MEMORY CHANG PROGRAM
14 0063 010500  LD   BC,05     ; BYTE SIZE
15 0066 EDB0    LDIR          ;
16 0068 C3F0FF  JP   FFF0H     ; JUMP $FFFF
17 006B      ;
18 006B      ;   $MCP: ENT
19 006B D3E0    DEFW E0D3H    ; 0000H-OFFFH IS DRAM
20 006D C300    DEFW 00C3H    ; OUT (E0H),A
21 006F 00      DEFB 00H      ; JP 0000H
22 0070      ;
23 0070      ;   STO:  ENT
24 0070 06FF   LD   B,FFH    ; BUFFER CLEAR
25 0072 21F110 LD   HL,NAME   ; 10F1H-11F0H CLEAR
26 0075 CDD80F  CALL ?CLER    ;
27 0078 3E16   LD   A,16H    ; LASTER CLR.
28 007A CD1200 CALL PRNT     ;
29 007D 3E71   LD   A,71H    ; BACK:BLUE CHA.:WRITE
30 007F 2100D8 LD   HL,D800H ; COLOR ADDRESS
31 0082 CDD509  CALL #CLR8   ;
32 0085 218D03 LD   HL,TIMIN ; INTERRUPT JUMP ROUTINE
33 0088 3EC3   LD   A,C3H    ;
34 008A 323810 LD   (1038H),A
35 008D 223910 LD   (1039H),HL
36 0090 3E04   LD   A,04     ; NORMAL TEMPO
37 0092 329E11 LD   (TEMPW),A
38 0095 CDBE02 CALL MLDSP    ; MELODY STOP
39 0098 CD0900 CALL NL       ;
40 009B 11E706 LD   DE,MSG?3 ; ** MONITOR 1Z-013A **
41 009E DF      RST 3          ; CALL MGX
42 009F CD7705 CALL ?BEL    ;
43 00A2      ;
44 00A2 3E01   LD   A,01H    ;
45 00A4 329D11 LD   (SWRK),A ; KEY IN SILENT
46 00A7 2100E8 LD   HL,E800H ; USR ROM ?
47 00AA 77     LD   (HL),A   ; ROM CHECK
48 00AB 1855   JR   FD2     ;
49 00AD      ;
50 00AD CD0900 CALL NL       ;
51 00B0 3E2A   LD   A,2AH    ; '* ' PRINT
52 00B2 CD1200 CALL PRNT    ;
53 00B5 11A311 LD   DE,BUFER ; GET LINE WORK (11A3H)
54 00B8 CD0300 CALL GETL    ;
55 00BB 1A     LD   A,(DE)   ;
56 00BC 13     INC  DE       ;
57 00BD FE0D   CP   0DH     ;
58 00BF 28EC   JR   Z,ST1   ;
59 00C1 FE4A   CP   'J'     ;
60 00C3 282E   JR   Z,GOTO  ;

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 03

```

01 00C5 FE4C          CP      'L'          ; LOAD PROGRAM
02 00C7 2848          JR      Z,LOAD          ;
03 00C9 FE46          CP      'F'          ; FLOPPY ACCESS
04 00CB 2832          JR      Z,FD           ;
05 00CD FE42          CP      'B'          ; KEY IN BELL
06 00CF 2826          JR      Z,SG           ;
07 00D1 FE23          CP      '#'          ; CHANG MEMORY
08 00D3 2886          JR      Z,CMYO         ;
09 00D5 FE50          CP      'P'          ; PRINTER TEST
10 00D7 287C          JR      Z,PTEST        ;
11 00D9 FE4D          CP      'M'          ; MEMORY CORRECTION
12 00DB CAAB07        JF      Z,MCOR         ;
13 00DE FE53          CP      'S'          ; SAVED DATA
14 00E0 CA5E0F        JP      Z,SAVE         ;
15 00E3 FE56          CP      'V'          ; VERIFYING DATA
16 00E5 CACB0F        JP      Z,VRFY         ;
17 00EB FE44          CP      'D'          ; DUMP DATA
18 00EA CA290D        JP      Z,DUMP         ;
19 00ED                ;
20 00ED                ;
21 00ED                DEFS    +4          ;
22 00F1                ;
23 00F1 18C8          JR      ST2           ; NOT COMMAND
24 00F3                ;
25 00F3                ; JUMP COMMAND
26 00F3                ;
27 00F3 CD3D01        GOTO:   CALL   HEXIY   ;
28 00F6 E9           JP      (HL)          ;
29 00F7                ;
30 00F7                ; KEY SOUND ON OFF
31 00F7                ;
32 00F7 3A9D11        SG:     LD      A,(SWRK) ; DO = SOUND WORK
33 00FA 1F           RRA                    ;
34 00FB 3F           CCF                    ; CHENGE MODE
35 00FC 17           RLA                    ;
36 00FD 18A5          JR      SS+2          ;
37 00FF                ;
38 00FF                ; FLOPPY
39 00FF                ;
40 00FF 2100F0        FD:     LD      HL,F000H ; FLOPPY I/O CHECK
41 0102 7E           FD2:    LD      A,(HL)   ;
42 0103 B7           OR      A              ;
43 0104 20A7          JR      NZ,ST1        ;
44 0106 E9           FD1:    JP      (HL)    ;
45 0107                ;
46 0107                ;
47 0107                ; ERROR (LOADING)
48 0107                ;
49 0107                ?ER:   ENT     ;
50 0107 FE02          CP      02H          ; A=02H : BREAK IN
51 0109 28A2          JR      Z,ST1        ;
52 010B 114701        LD      DE,MSGE1     ; CHECK SUM ERROR
53 010E DF           RST     3            ; CALL MSGX
54 010F 189C          JR      ST1          ;
55 0111                ;
56 0111                ;
57 0111                ; LOAD COMMAND
58 0111                ;
59 0111 CDD804        LOAD:   CALL   ?RDI   ;
60 0114 3BF1          JR      C,?ER        ;

```

04.07.83

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 04

```

01 0116 CD0900        LOAO:   CALL   NL      ;
02 0119 11A009        LD      DE,MSG?2     ; LOADING
03 011C DF           RST     3            ; CALL MSGX
04 011D 11F110        LD      DE,NAME      ; FILE NAME
05 0120 DF           RST     3            ; CALL MSGX
06 0121 CDF804        CALL   ?RDD          ;
07 0124 3BE1          JR      C,?ER        ;
08 0126 2A0611        LD      HL,(EXADR)   ; EXECUTE ADDRESS
09 0129 7C           LD      A,H          ;
10 012A FE12          CP      12H         ; EXECUTE CHECK
11 012C 3BE1          JR      C,LOAD-2    ;
12 012E E9           JP      (HL)        ;
13 012F                ;
14 012F                ;
15 012F                ;
16 012F                ;
17 012F                ; GETLINE AND BREAK IN CHECK
18 012F                ;
19 012F                ; EXIT BREAK IN THEN JUMP (ST1)
20 012F                ; ACC=TOP OF LINE DATA
21 012F                ;
22 012F E3           BGETL:  ENT     (SP),HL ;
23 0130 C1           POP     BC           ; STACK LOAD
24 0131 11A311        LD      DE,BUFER     ; MONITOR GETLINE BUFF
25 0134 CD0300        CALL   GETL          ;
26 0137 1A           LD      A,(DE)       ;
27 0138 FE1B          CP      1BH          ; BREAK CODE
28 013A 2BD3          JR      Z,LOAD-2    ; JP Z,ST1
29 013C E9           JP      (HL)        ;
30 013D                ;
31 013D                ; ASCII TO HEX CONVERT
32 013D                ; INPUT (DE)=ASCII
33 013D                ; CY=1 THEN JUMP (ST1)
34 013D                ;
35 013D                ;
36 013D FDE3          HEXIY:  ENT     (SP),IY     ;
37 013F F1           POP     AF           ;
38 0140 CD1004        CALL   HLHEX         ;
39 0143 3BCA          JR      C,LOAD-2    ; JP C,ST1
40 0145 FDE9          JP      (IY)        ;
41 0147                ;
42 0147                ;
43 0147                ;
44 0147                ;
45 0147 43484543        MSGE1:  DEFM    'CHECK SUM ER.' ;
46 0148 4B205355        ;
47 014F 4D204552        ;
48 0153 2E           ;
49 0154 0D           DEFNB  ODH          ;
50 0155                ;
51 0155                ;
52 0155                ; PLOTTER PRINTER TEST COMMAND
53 0155                ; (DPG23)
54 0155                ;
55 0155                ; &=CONTROL COMMANDS GROUP
56 0155                ; C=PEN CHENGE
57 0155                ; G=GRAPH MODE
58 0155                ; S=80 CHA. IN 1 LINE
59 0155                ; L=40 CHA. IN 1 LINE
60 0155                ; T=PLOTTER TEST

```

04.07.83

```

01 0155 ;
02 0155 PTEST: ENT
03 0155 1A LD A,(DE)
04 0156 FE26 CP '3'
05 0158 2016 JR NZ,PTST1
06 015A 13 PTST0: INC DE
07 015B 1A LD A,(DE)
08 015C FE4C CP 'L' ; 80 IN 1 LINE
09 015E 2816 JR Z,.LPT
10 0160 FE53 CP 'S' ; 80 IN 1LINE
11 0162 2817 JR Z,.LPT
12 0164 FE43 CP 'C' ; PEN CHENGE
13 0166 2823 JR Z,PEN
14 0168 FE47 CP 'G' ; GRAPH MODE
15 016A 2818 JR Z,PLOT
16 016C FE54 CP 'T' ; TEST
17 016E 2810 JR Z,PTRN
18 0170 ;
19 0170 CDA501 PTST1: CALL PMSG ; PLOT MESSAGE
20 0173 C3AD00 JP ST1
21 0176 ;
22 0176 117004 .LPT: LD DE,LLPT ; 01-09-09-0B-0D
23 0179 18F5 JR PTST1
24 017B ;
25 017B 11D503 ..LPT: LD DE,SLPT ; 01-09-09-09-0D
26 017E 18F0 JR PTST1
27 0180 ;
28 0180 3E04 PTRN: LD A,04H ; TEST PATTERN
29 0182 1802 JR PLOT+2
30 0184 ;
31 0184 3E02 PLOT: LD A,02H ; GRAPH CODE
32 0186 CDBF01 CALL LPRNT
33 0189 18CF JR PTST0
34 018B ;
35 018B 3E1D PEN: LD A,1DH ; 1 CHENGE CODE (TEXT MO
DE)
36 018D 18F7 JR PLOT+2
37 018F ;
38 018F ;
39 018F ; ICHA. PRINT TO $LPT
40 018F ;
41 018F ; IN: ACC PRINT DATA
42 018F ;
43 018F ;
44 018F 0E00 LPRNT: LD C,0 ; RDA TEST
45 0191 47 LD B,A ; PRINT DATA STORE
46 0192 CDB601 CALL RDA
47 0195 78 LD A,B
48 0196 D3FF OUT (FFH),A ; DATA OUT
49 0198 3E80 LD A,80H ; RDP HIGH
50 019A D3FE OUT (FEH),A
51 019C 0E01 LD C,01H ; RDA TEST
52 019E CDB601 CALL RDA
53 01A1 AF XOR A ; RDP LOW
54 01A2 D3FE OUT (FEH),A
55 01A4 C9 RET
56 01A5 ;
57 01A5 ; $LPT MSG.
58 01A5 ; IN: DE DATA LOW ADR.
59 01A5 ; ODH MSG. END
60 01A5 ;

```

```

01 01A5 D5 PMSG: PUSH DE
02 01A6 C5 PUSH BC
03 01A7 F5 PUSH AF
04 01A8 1A PMSG1: LD A,(DE) ; ACC=DATA
05 01A9 CDBF01 CALL LPRNT
06 01AC 1A LD A,(DE)
07 01AD 13 INC DE
08 01AE FE0D CP ODH ; END ?
09 01B0 20F6 JR NZ,PMSG1
10 01B2 F1 POP AF
11 01B3 C1 POP BC
12 01B4 D1 POP DE
13 01B5 C9 RET
14 01B6 ;
15 01B6 ; RDA CHECK
16 01B6 ;
17 01B6 ; BRKEY IN TO MONITOR RETURN
18 01B6 ; IN: C RDA CODE
19 01B6 ;
20 01B6 DBFE RDA: IN A,(FE)
21 01B8 E60D AND ODH
22 01BA B9 CP C
23 01BB C8 RET Z
24 01BC CD1E00 CALL BRKEY
25 01BF 20F5 JR NZ,RDA
26 01C1 31F010 LD SP,SP
27 01C4 C3AD00 JP ST1
28 01C7 ;
29 01C7 ;
30 01C7 ; ORG 01C7H
31 01C7 ;
32 01C7 ; MELODY
33 01C7 ;
34 01C7 ; DE=DATA LOW ADR.
35 01C7 ; EXIT CF=1 BREAK
36 01C7 ; CF=0 OK
37 01C7 ;
38 01C7 ?MLDY: ENT
39 01C7 C5 PUSH BC
40 01C8 D5 PUSH DE
41 01C9 E5 PUSH HL
42 01CA 3E02 LD A,02H
43 01CC 32A011 LD (OCTV),A
44 01CF 0601 LD B,01
45 01D1 1A MLD1: LD A,(DE)
46 01D2 FE0D CP ODH ; CR
47 01D4 2838 JR Z,MLD4
48 01D6 FEC8 CP CBH ; END MARK
49 01D8 2837 JR Z,MLD4
50 01DA FECF CP CFH ; UNDER OCTAVE
51 01DC 2827 JR Z,MLD2
52 01DE FE2D CP 2DH ; '-'
53 01E0 2823 JR Z,MLD2
54 01E2 FE2B CP 2BH ; '+'
55 01E4 2827 JR Z,MLD3
56 01E6 FED7 CP D7H ; UPPER OCTAVE
57 01E8 2823 JR Z,MLD3
58 01EA FE23 CP 23H ; "#" HANON
59 01EC 216C02 LD HL,MTBL
60 01EF 2004 JR NZ,+6

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 07          04.07.83
01 01F1 21B402          LD      HL,M#TBL
02 01F4 13              INC     DE
03 01F5 CD1C02         CALL   ONPU          ; ONTYO SET
04 01F8 38D7          JR     C,MLD1
05 01FA CDC802         CALL   RYTHM        ; MELODY TOP
06 01FD 3815          JR     C,MLD5
07 01FF CDAB02         CALL   MLDST        ; MELODY START
08 0202 41              LD     B,C
09 0203 18CC          JR     MLD1
10 0205 3E03          MLD2: LD     A,+3
11 0207 32A011         LD     (OCTV),A
12 020A 13              INC     DE
13 020B 18C4          JR     MLD1
14 020D 3E01          MLD3: LD     A,1
15 020F 18F6          JR     MLD2+2
16 0211 CDC802         MLD4: CALL  RYTHM
17 0214 F5              MLD5: PUSH AF
18 0215 CDBE02         CALL   MLDSP
19 0218 F1              POP    AF
20 0219 C39B06         JP     RET3
21 021C                ;
22 021C                ; ONPU TO RATIO CONV
23 021C                ;
24 021C                ; EXIT (RATIO)=RATIO VALUE
25 021C                ; C=ONTYO*TEMPO
26 021C                ;
27 021C                ;
28 021C C5              ONPU: ENT     BC
29 021D 0608          PUSH   BC
30 021F 1A              LD     B,B
31 0220 BE              ONP1: LD     A,(DE)
32 0221 2809          CP     (HL)
33 0223 23              JR     Z,ONP2
34 0224 23              INC     HL
35 0225 23              INC     HL
36 0226 10FB          DJNZ  -6
37 0228 37              SCF
38 0229 13              INC     DE
39 022A C1              POP    BC
40 022B C9              RET
41 022C 23              ONP2: INC     HL
42 022D D5              PUSH   DE
43 022E 5E              LD     E,(HL)
44 022F 23              INC     HL
45 0230 56              LD     D,(HL)
46 0231 EB              EX     DE,HL
47 0232 7C              LD     A,H
48 0233 B7              OR     A
49 0234 2809          JR     Z,+11
50 0236 3AA011         LD     A,(OCTV)    ; 11A0H OCTAVE WORK
51 0239 3D              DEC     A
52 023A 2803          JR     Z,+5
53 023C 29              ADD    HL,HL
54 023D 18FA          JR     -4
55 023F 22A111         LD     (RATIO),HL ; 11A1H ONPU RATIO
56 0242 21A011         LD     HL,OCTV
57 0245 3602          LD     (HL),2
58 0247 2B              DEC     HL
59 0248 D1              POP    DE
60 0249 13              INC     DE

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 08          04.07.83
01 024A 1A              LD     A,(DE)
02 024B 47              LD     B,A
03 024C E6F0          AND    FOH          ; ONTYO ?
04 024E FE30          CP     30H
05 0250 2803          JR     Z,+5
06 0252 7E              LD     A,(HL)      ; HL=ONTYO
07 0253 1805          JR     +7
08 0255 13              INC     DE
09 0256 78              LD     A,B
10 0257 E60F          AND    OFH
11 0259 77              LD     (HL),A      ; HL=ONTYO
12 025A 219C02        LD     HL,OPTBL
13 025D 85              ADD    A,L
14 025E 6F              LD     L,A
15 025F 4E              LD     C,(HL)
16 0260 3A9E11        LD     A,(TEMPW)
17 0263 47              LD     B,A
18 0264 AF              XOR    A
19 0265 81              ONP3: ADD    A,C
20 0266 10FD          DJNZ  -1
21 0268 C1              POP    BC
22 0269 4F              LD     C,A
23 026A AF              XOR    A
24 026B C9              RET
25 026C                ;
26 026C                ;
27 026C                ;
28 026C 43              MTBL: DEFB  43H      ; C
29 026D 4608          DEFB  0846H
30 026F 44              DEFB  44H           ; D
31 0270 5F07          DEFW  075FH
32 0272 45              DEFB  45H           ; E
33 0273 9106          DEFW  0691H
34 0275 46              DEFB  46H           ; F
35 0276 3306          DEFW  0633H
36 0278 47              DEFB  47H           ; G
37 0279 8605          DEFW  0586H
38 027B 41              DEFB  41H           ; A
39 027C EC04          DEFW  04ECH
40 027E 42              DEFB  42H           ; B
41 027F 6404          DEFW  0464H
42 0281 52              DEFB  52H           ; R
43 0282 0000          DEFW  0
44 0284                ;
45 0284 43              M#TBL: DEFB  43H      ; #C
46 0285 CF07          DEFW  07CFH
47 0287 44              DEFB  44H           ; #D
48 0288 F506          DEFW  06F5H
49 028A 45              DEFB  45H           ; #E
50 028B 3306          DEFW  0633H
51 028D 46              DEFB  46H           ; #F
52 028E DA05          DEFW  05DAH
53 0290 47              DEFB  47H           ; #G
54 0291 3705          DEFW  0537H
55 0293 41              DEFB  41H           ; #A
56 0294 A504          DEFW  04A5H
57 0296 42              DEFB  42H           ; #B
58 0297 2304          DEFW  0423H
59 0299 52              DEFB  52H           ; #R
60 029A                ;

```

```

01 029A 0000          DEFW  0
02 029C          OPTBL: ENT
03 029C 01          DEFB  1
04 029D 02          DEFB  2
05 029E 03          DEFB  3
06 029F 04          DEFB  4
07 02A0 06          DEFB  6
08 02A1 08          DEFB  8
09 02A2 0C          DEFB  0CH
10 02A3 10          DEFB  10H
11 02A4 18          DEFB  18H
12 02A5 20          DEFB  20H
13 02A6          ;
14 02A6          ;
15 02A6          ;
16 02A6          ; INCREMENT DE REG.
17 02A6          ;
18 02A6          .4DE: ENT
19 02A6 13          INC  DE
20 02A7 13          INC  DE
21 02A8 13          INC  DE
22 02A9 13          INC  DE
23 02AA C9          RET
24 02AB          ;
25 02AB          ;
26 02AB          ;
27 02AB          ; ORG 02ABH ; MLDST
28 02AB          ;
29 02AB          ; MELODY START & STOP
30 02AB          ;
31 02AB          MLDST: ENT
32 02AB 2AA111      LD    HL,(RATIO)
33 02AE 7C          LD    A,H
34 02AF B7          OR    A
35 02B0 280C       JR    Z,MLDSP
36 02B2 D5         PUSH DE
37 02B3 EB         EX   DE,HL
38 02B4 2104E0     LD    HL,CONTO
39 02B7 73         LD    (HL),E
40 02B8 72         LD    (HL),D
41 02B9 3E01      LD    A,1
42 02BB D1         POP  DE
43 02BC 1806       JR    MLDS1
44 02BE          ;
45 02BE          MLDSP: ENT
46 02BE 3E36       LD    A,36H
47 02C0 3207E0     LD    (CONTF),A
48 02C3 AF        XOR  A
49 02C4 3208E0     MLDSP: LD (SUNDG),A
50 02C7 C9        RET
51 02C8          ;
52 02C8          ; RHYTHM
53 02C8          ;
54 02C8          ; B=COUNT DATA
55 02C8          ; IN
56 02C8          ; EXIT CF=1 BREAK
57 02C8          ; CF=0 DK
58 02C8          ;
59 02C8          RYTHM: ENT
60 02C8 2100E0     LD    HL,KEYPA

```

```

01 02CB 36FB       LD    (HL),FBH
02 02CD 23        INC  HL
03 02CE 7E        LD    A,(HL)
04 02CF E681      AND  B1H          ; BREAK IN CHECK
05 02D1 2002      JR    NZ,+4
06 02D3 37        SCF
07 02D4 C9        RET
08 02D5 3A08E0    LD    A,(TEMP)
09 02D8 0F        RRCA          ; E008H
10 02D9 38FA      JR    C,-4      ; TEMPO OUT
11 02DB 3A08E0    LD    A,(TEMP)
12 02DE 0F        RRCA
13 02DF 30FA      JR    NC,-4
14 02E1 10F2      DJNZ -12
15 02E3 AF        XOR  A
16 02E4 C9        RET
17 02E5          ;
18 02E5          ;
19 02E5          ; TEMPO SET
20 02E5          ;
21 02E5          ; ACC=VALUE (1-7)
22 02E5          ;
23 02E5          ; ?TEMP: ENT
24 02E5 F5        PUSH AF
25 02E6 C5        PUSH BC
26 02E7 E60F      AND  0FH
27 02E9 47        LD    B,A
28 02EA 3E08      LD    A,B
29 02EC 90        SUB  B
30 02ED 329E11    LD    (TEMPW),A
31 02F0 C1        POP  BC
32 02F1 F1        POP  AF
33 02F2 C9        RET
34 02F3          ;
35 02F3          ; DECC CRT MANAGEMENT
36 02F3          ;
37 02F3          ; EXIT HL:DSPXY H=Y,L=X
38 02F3          ; DE:MANG ADR. (ON DSPXY)
39 02F3          ; A :MANG DATA
40 02F3          ; CY:MANG=1
41 02F3          ;
42 02F3          ;
43 02F3          ; MANG: ENT
44 02F3 217311    LD    HL,MANG
45 02F6 3A7211    LD    A,(1172H)
46 02F9 85        ADD  A,L
47 02FB 7E        LD    L,A
48 02FC 23        LD    A,(HL)
49 02FD CB16      INC  HL
50 02FF B6        RL   (HL)
51 0300 CB1E      OR   (HL)
52 0302 0F        RR   (HL)
53 0303 EB        RRCA
54 0304 2A7111    EX  DE,HL
55 0307 C9        LD    HL,(DSPXY)
56 0308          RET
57 0308          ;
58 0308          ;
59 0308          ; ORG 0308H
60 0308          ;

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 11

04.07.83

```

01 030B ; TIME SET
02 030B ;
03 030B ; ACC=0 : AM
04 030B ; =1 : PM
05 030B ; DE=SEC: BINARY
06 030B ;
07 030B ?TMST: ENT
08 030B F3 DI
09 0309 C5 PUSH BC
10 030A D5 PUSH DE
11 030B E5 PUSH HL
12 030C 329B11 LD (AMPM),A ; AMPM DATA
13 030F 3EFO LD A,FOH
14 0311 329C11 LD (TIMFB),A ; TIME FLAG
15 0314 21COAB LD HL,ABCOH ; 12H
16 0317 AF XOR A
17 031B ED52 SBC HL,DE ; COUNT DATA = 12H-IN DA
TA
18 031A E5 PUSH HL
19 031B 00 NOP
20 031C EB EX DE,HL
21 031D 2107E0 LD HL,CONTF ; E007H
22 0320 3674 LD (HL),74H
23 0322 36B0 LD (HL),BOH
24 0324 2B DEC HL ; CONT2
25 0325 73 LD (HL),E
26 0326 72 LD (HL),D
27 0327 2B DEC HL ; CONT1
28 0328 360A LD (HL),0AH
29 032A 3600 LD (HL),0
30 032C 23 INC HL
31 032D 23 INC HL ; CONTF
32 032E 3680 LD (HL),80H ; CONT2
33 0330 2B DEC HL
34 0331 4E ?TMS1: LD C,(HL)
35 0332 7E LD A,(HL)
36 0333 BA CP D
37 0334 20FB JR NZ,?TMS1
38 0336 79 LD A,C
39 0337 BB CP E
40 0338 20F7 JR NZ,?TMS1
41 033A 2B DEC HL
42 033B 00 NOP
43 033C 00 NOP
44 033D 00 NOP
45 033E 36FB LD (HL),FBH ; 1SEC
46 0340 363C LD (HL),3CH
47 0342 23 INC HL
48 0343 D1 POP DE
49 0344 4E ?TMS2: LD C,(HL)
50 0345 7E LD A,(HL)
51 0346 BA CP D
52 0347 20FB JR NZ,?TMS2
53 0349 79 LD A,C
54 034A BB CP E
55 034B 20F7 JR NZ,?TMS2
56 034D E1 POP HL
57 034E D1 POP DE
58 034F C1 POP BC
59 0350 FB EI
60 0351 C9 RET

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 12

04.07.83

```

01 0352 ; BELL DATA
02 0352 ;
03 0352 ; BELL DATA
04 0352 ;
05 0352 ?BELD: ENT
06 0352 D7 DEFNB D7H
07 0353 4130 DEFM 'AO'
08 0355 0D DEFNB ODH
09 0356 ;
10 0356 ;
11 0356 ;
12 0356 DEFS +2
13 0358 ;ORG 0358H
14 0358 ;
15 0358 ; TIME READ
16 0358 ;
17 0358 ; EXIT ACC=0 :AM
18 0358 ; =1 :PM
19 0358 ; DE=SEC. BINARY
20 0358 ;
21 0358 ?TMRD: ENT
22 0358 E5 PUSH HL
23 0359 2107E0 LD HL,CONTF
24 035C 3680 LD (HL),BOH
25 035E 2B DEC HL ; CONT2
26 035F F3 DI
27 0360 5E LD E,(HL)
28 0361 56 LD D,(HL)
29 0362 FB EI
30 0363 7B LD A,E
31 0364 B2 OR D
32 0365 280E JR Z,?TMR1
33 0367 AF XOR A
34 0368 21COAB LD HL,ABCOH
35 0368 ED52 SBC HL,DE
36 036D 3810 JR C,?TMR2
37 036F EB EX DE,HL
38 0370 3A9B11 LD A,(AMPM)
39 0373 E1 POP HL
40 0374 C9 RET
41 0375 11COAB ?TMR1: LD DE,ABCOH ; 12H
42 0378 3A9B11 LD A,(AMPM)
43 037B EE01 XOR 1
44 037D E1 POP HL
45 037E C9 RET
46 037F F3 DI
47 0380 2106E0 ?TMR2: LD HL,CONTF
48 0383 7E LD A,(HL)
49 0384 2F CPL
50 0385 5F LD E,A
51 0386 7E LD A,(HL)
52 0387 2F CPL
53 0388 57 LD D,A
54 0389 FB EI
55 038A 13 INC DE
56 038B 18EB JR ?TMR1+3
57 038D ;
58 038D ; TIME INTERRUPT
59 038D ;
60 038D TIMIN: ENT

```



```

01 03BD F5      PUSH AF
02 03BE C5      PUSH BC
03 03BF D5      PUSH DE
04 0390 E5      PUSH HL
05 0391 219B11  LD HL,AMPM
06 0394 7E      LD A,(HL)
07 0395 EE01    XOR 1
08 0397 77      LD (HL),A
09 0398 2107E0  LD HL,CONTF
10 039B 3680    LD (HL),80H
11 039D 2B      DEC HL
12 039E E5      PUSH HL
13 039F 5E      LD E,(HL)
14 03A0 56      LD D,(HL)
15 03A1 21C0A8  LD HL,ABCOH
16 03A4 19      ADD HL,DE
17 03A5 2B      DEC HL
18 03A6 2B      DEC HL
19 03A7 EB      EX DE,HL
20 03A8 E1      POP HL
21 03A9 73      LD (HL),E
22 03AA 72      LD (HL),D
23 03AB E1      POP HL
24 03AC D1      POP DE
25 03AD C1      POP BC
26 03AE F1      POP AF
27 03AF FB      EI
28 03B0 C9      RET
29 03B1 ;
30 03B1 ; SPACE PRINT AND DISP ACC
31 03B1 ;
32 03B1 ; INPUT:HL=DISP. ADR.
33 03B1 ;
34 03B1 SPHEX: ENT
35 03B1 CD2009  CALL ?PRTS ; SP.PRINT
36 03B4 7E      LD A,(HL)
37 03B5 CDC303  CALL PRTHX ; DSP OF ACC (ASCII)
38 03B8 7E      LD A,(HL)
39 03B9 C9      RET
40 03BA ;
41 03BA ;
42 03BA ;
43 03BA ;ORG 03BAH
44 03BA ;
45 03BA ; (ASCII PRINT) FOR HL
46 03BA ;
47 03BA PRTHL: ENT
48 03BA 7C      LD A,H
49 03BB CDC303  CALL PRTHX
50 03BE 7D      LD A,L
51 03BF 1802    JR PRTHX
52 03C1 ;
53 03C1 DEFS +2
54 03C3 ;ORG 03C3H;PRTHX
55 03C3 ;
56 03C3 ; (ASCII PRINT) FOR ACC
57 03C3 ;
58 03C3 PRTHX: ENT
59 03C3 F5      PUSH AF
60 03C4 0F      RRCA

```

```

01 03C5 0F      RRCA
02 03C6 0F      RRCA
03 03C7 0F      RRCA
04 03C8 CDDA03  CALL ASC
05 03CB CD1200  CALL PRNT
06 03CE F1      POP AF
07 03CF CDDA03  CALL ASC
08 03D2 C31200  JP PRNT
09 03D5 ;
10 03D5 ;
11 03D5 ;
12 03D5 ;
13 03D5 ; 80 CHA. 1 LINE CODE (DATA)
14 03D5 ;
15 03D5 ;
16 03D5 01      DEFB 01H ; TEXT MODE
17 03D6 09      DEFB 09H
18 03D7 09      DEFB 09H
19 03D8 09      DEFB 09H
20 03D9 0D      DEFB 0DH
21 03DA ;
22 03DA ;ORG 03DAH;ASC
23 03DA ;
24 03DA ;
25 03DA ; HEXADECIMAL TO ASCII
26 03DA ; IN : ACC (D3-D0)=HEXADECIMAL
27 03DA ; EXIT: ACC = ASCII
28 03DA ;
29 03DA E60F    AND 0FH
30 03DC FE0A    CP 0AH
31 03DE 3802    JR C,NOADD
32 03E0 C607    ADD A,7
33 03E2 ;
34 03E2 C630    ADD A,30H
35 03E4 C9      RET
36 03E5 ;
37 03E5 ; ASCII TO HEXADECIMAL
38 03E5 ; IN : ACC = ASCII
39 03E5 ; EXIT : ACC = HEXADECIMAL
40 03E5 ; CY = 1 ERROR
41 03E5 ;
42 03E5 HEXJ: ENT
43 03E5 D630    SUB 30H
44 03E7 DB      RET C
45 03E8 FE0A    CP 0AH
46 03EA 3F      CCF
47 03EB D0      RET NC
48 03EC D607    SUB 7
49 03EE FE10    CP 10H
50 03F0 3F      CCF
51 03F1 D8      RET C
52 03F2 FE0A    CP 0AH
53 03F4 C9      RET
54 03F5 ;
55 03F5 ;
56 03F5 DEFS +4
57 03F9 ;ORG 03F9H;HEX
58 03F9 ;
59 03F9 18EA    JR HEXJ
60 03FB ;

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 15          04.07.83
01 03FB          ; PRASS PLAY MESSAGE
02 03FB          ;
03 03FB          MSG#1: ENT
04 03FB 7F20      DEFW  207FH
05 03FD          MSG#2: ENT
06 03FD 504C4159 DEFM  'PLAY'
07 0401 0D        DEFB  0DH
08 0402          MSG#3: ENT
09 0402 7F20      DEFW  207FH
10 0404 5245434F DEFM  'RECORD.' ; PRESS RECORD
11 0408 52442E          DEFB  0DH
12 040B 0D        DEFB  0DH
13 040C          ;
14 040C          ;
15 040C          DEFS  +4
16 0410          ;ORG 0410H:HLHEX
17 0410          ;
18 0410          ;
19 0410          ; 4 ASCII TO (HL)
20 0410          ;
21 0410          ; IN DE=DATA LOW ADR.
22 0410          ; EXIT CF=0 : OK
23 0410          ; =1 : OUT
24 0410          ;
25 0410          HLHEX: ENT
26 0410 D5        PUSH  DE
27 0411 CD1F04    CALL  2HEX
28 0414 3807      JR    C,+9
29 0416 67        LD    H,A
30 0417 CD1F04    CALL  2HEX
31 041A 3801      JR    C,+3
32 041C 6F        LD    L,A
33 041D D1        HL1: POP  DE
34 041E C9        RET
35 041F          ;
36 041F          ;ORG 041FH:2HEX
37 041F          ;
38 041F          ;
39 041F          ; 2 ASCII TO (ACC)
40 041F          ;
41 041F          ; IN DE=DATA LOW ADR.
42 041F          ;
43 041F          ; EXIT CF=0 : OK
44 041F          ; =1 : OUT
45 041F          ;
46 041F          2HEX: ENT
47 041F C5        PUSH  BC
48 0420 1A        LD    A,(DE)
49 0421 13        INC   DE
50 0422 CDF903    CALL  HEX
51 0425 380D      JR    C,+15
52 0427 0F        RRCA
53 0428 0F        RRCA
54 0429 0F        RRCA
55 042A 0F        RRCA
56 042B 4F        LD    C,A
57 042C 1A        LD    A,(DE)
58 042D 13        INC   DE
59 042E CDF903    CALL  HEX
60 0431 3801      JR    C,+3

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 16          04.07.83
01 0433 B1        OR    C
02 0434 C1        2HE1: POP  BC
03 0435 C9        RET
04 0436          ;
05 0436          ;
06 0436          ; WRITE INFORMATION
07 0436          ;
08 0436          ?WRI: ENT
09 0436 F3        DI
10 0437 D5        PUSH  DE
11 0438 C5        PUSH  BC
12 0439 E5        PUSH  HL
13 043A 16D7      LD    D,D7H ; 'W'
14 043C 1ECC      LD    E,CCH ; 'L'
15 043E 21F010    LD    HL,IBUFE ; 10FOH
16 0441 018000    LD    BC,80H ; WRITE BYTE SIZE
17 0444 CD1A07    CALL  CKSUM ; CHECK SUM
18 0447 CD9F06    CALL  MOTOR ; MOTOR ON
19 044A 3818      JR    C,WRI3
20 044C 7B        LD    A,E
21 044D FECC      CP    CCH ; 'L'
22 044F 200D      JR    NZ,WRI2
23 0451 CD0900    CALL  NL
24 0454 D5        PUSH  DE
25 0455 116704    LD    DE,MSG#7 ; WRITING
26 0458 DF        RST   3 ; CALL MSGX
27 0459 11F110    LD    DE,NAME ; FILE NAME
28 045C DF        RST   3 ; CALL MSGX
29 045D D1        POP   DE
30 045E CD7A07    CALL  GAP
31 0461 CDBA04    CALL  WTAPE
32 0464 C35405    WRI3: JP  RET2
33 0467          ;
34 0467          MSG#7: ENT
35 0467 57524954 DEFM  'WRITING'
36 046B 494E4720 DEFB  0DH
37 046F OD        DEFB  0DH
38 0470          ;
39 0470          ;
40 0470          ;
41 0470          ; 40 CHA. IN 1 LINE CODE (DATA)
42 0470          ;
43 0470          ;
44 0470 01        LLPT: ENT
45 0471 09        DEFB  01H ; TEXT MODE
46 0472 09        DEFB  09H
47 0473 0B        DEFB  0BH
48 0474 0D        DEFB  0DH
49 0475          ;
50 0475          ;ORG 0475H
51 0475          ;
52 0475          ;
53 0475          ; WRITE DATA
54 0475          ;
55 0475          ; EXIT CF=0 : OK
56 0475          ; =1 : BREAK
57 0475          ;
58 0475          ?WRD: ENT
59 0475 F3        DI
60 0476 D5        PUSH  DE

```

```

01 0477 C5          PUSH BC
02 0478 E5          PUSH HL
03 0479 16D7        LD D,D7H          ; 'W'
04 047B 1E53        LD E,53H          ; 'S'
05 047D ED4B0211    LD BC,(SIZE)      ; WRITE DATA BYTE SIZE
06 0481 2A0411      LD HL,(DTADR)     ; WRITE DATA ADDRESS
07 0484 78          LD A,B
08 0485 B1          OR C
09 0486 2B4A        JR Z,RET1
10 0488 18BA        JR WR11
11 048A             ;
12 048A             ;
13 048A             ; TAPE WRITE
14 048A             ;
15 048A             ; BC=BYTE SIZE
16 048A             ; HL=DATA LOW ADR.
17 048A             ;
18 048A             ; EXIT CF=0 : OK
19 048A             ; =1 : BREAK
20 048A             ;
21 048A D5          WTAP: PUSH DE
22 048B C5          PUSH BC
23 048C E5          PUSH HL
24 048D 1602        LD D,2
25 048F 3EF8        LD A,FBH
26 0491 3200E0      LD (KEYPA),A      ; E000H
27 0494 7E          WTAP1: LD A,(HL)
28 0495 CD6707      CALL WBYTE        ; 1 BYTE WRITE
29 0498 3A01E0      LD A,(KEYPB)     ; E001H
30 049B E681        AND B1H          ; SHIFT & BREAK
31 049D C2A504      JP NZ,WTAP2
32 04A0 3E02        LD A,02H         ; BREAK IN CODE
33 04A2 37          SCF
34 04A3 182D        JR WTAP3
35 04A5 23          WTAP2: INC HL
36 04A6 0B          DEC BC
37 04A7 78          LD A,B
38 04A8 B1          OR C
39 04A9 C29404      JP NZ,WTAP1
40 04AC 2A9711      LD HL,(SUMDT)   ; SUM DATA SET
41 04AF 7C          LD A,H
42 04B0 CD6707      CALL WBYTE
43 04B3 7D          LD A,L
44 04B4 CD6707      CALL WBYTE
45 04B7 CD1A0A      CALL LONG
46 04BA 15          DEC D
47 04BB C2C204      JP NZ,+7
48 04BE B7          OR A
49 04BF C3D204      JP WTAP3
50 04C2 0600        LD B,0
51 04C4 CD010A      CALL SHORT
52 04C7 05          DEC B
53 04CB C2C404      JP NZ,-4
54 04CB E1          POP HL
55 04CC C1          POP BC
56 04CD C5          PUSH BC
57 04CE E5          PUSH HL
58 04CF C39404      JP WTAP1
59 04D2             ;
60 04D2 E1          RET1: POP HL
    
```

```

01 04D3 C1          POP BC
02 04D4 D1          POP DE
03 04D5 C9          RET
04 04D6             ;
05 04D6             ;
06 04D6             ;
07 04D6             ;
08 04D6             ;
09 04DB             ; ORG 04DBH
10 04DB             ;
11 04DB             ;
12 04DB             ; READ INFORMATION (FROM #CMT)
13 04DB             ;
14 04DB             ; EXIT ACC=0 : OK CF=0
15 04DB             ; =1 : ER CF=1
16 04DB             ; =2 : BREAK CF=1
17 04DB             ;
18 04DB             ; ?RDI: ENT
19 04DB F3          DI
20 04D9 D5          PUSH DE
21 04DA C5          PUSH BC
22 04DB E5          PUSH HL
23 04DC 16D2        LD D,D2H          ; 'R'
24 04DE 1ECC        LD E,CCH          ; 'L'
25 04E0 018000      LD BC,80H
26 04E3 21F010      LD HL,IBUFE
27 04E6             ; RD1: ENT
28 04E6 CD9F06      CALL MOTOR
29 04E9 DA7205      JP C,RTP6
30 04EC CD5B06      CALL TMARK
31 04EF DA7205      JP C,RTP6
32 04F2 CD0E05      CALL RTAPE
33 04F5 C35405      JP RTP4
34 04F8             ;
35 04F8             ;
36 04F8             ;
37 04F8             ; ORG 04FBH
38 04F8             ;
39 04F8             ;
40 04F8             ; READ DATA (FROM #CMT)
41 04F8             ;
42 04F8             ; EXIT SAME UP
43 04F8             ;
44 04F8             ; ?RDD: ENT
45 04F8 F3          DI
46 04F9 D5          PUSH DE
47 04FA C5          PUSH BC
48 04FB E5          PUSH HL
49 04FC 16D2        LD D,D2H          ; 'R'
50 04FE 1E53        LD E,53H          ; 'S'
51 0500 ED4B0211    LD BC,(SIZE)
52 0504 2A0411      LD HL,(DTADR)
53 0507 78          LD A,B
54 0508 B1          OR C
55 0509 CA5405      JP Z,RTP4
56 050C 18DB        JR RD1
57 050E             ;
58 050E             ;
59 050E             ; READ TAPE
60 050E             ;
    
```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 19

04.07.83

```

01 050E      ; IN BC=SIZE
02 050E      ; DE=LOAD ADR.
03 050E      ;
04 050E      ; EXIT ACC=0 : OK CF=0
05 050E      ; =1 : ER =1
06 050E      ; =2 : BREAK=1
07 050E      ;
08 050E      RTAPE: ENT
09 050E D5   PUSH DE
10 050F C5   PUSH BC
11 0510 E5   PUSH HL
12 0511 2602 LD H,2 ; TWICE WRITE
13 0513      RTP1: ENT
14 0513 0101E0 LD BC,KEYPB
15 0516 1102E0 LD DE,CSTR
16 0519      RTP2: ENT
17 0519 CD0106 CALL EDGE ; 1->0 EDGE DETECT
18 051C 3854 JR C,RTP6
19 051E CD4A0A CALL DLY3 ; CALL DLY2*3
20 0521 1A   LD A,(DE) ; DATA (1BIT) READ
21 0522 E620 AND 20H
22 0524 CA1905 JP Z,RTP2
23 0527 54   LD D,H
24 052B 210000 LD HL,0
25 052B 229711 LD (SUMDT),HL
26 052E E1   POP HL
27 052F C1   POP BC
28 0530 C5   PUSH BC
29 0531 E5   PUSH HL
30 0532      RTP3: ENT
31 0532 CD2406 CALL RBYTE ; 1BYTE READ
32 0535 383B JR C,RTP6
33 0537 77   LD (HL),A
34 0538 23   INC HL
35 0539 0B   DEC BC
36 053A 7B   LD A,B
37 053B B1   OR C
38 053C 20F4 JR NZ,RTP3
39 053E 2A9711 LD HL,(SUMDT) ; CHECK SUM
40 0541 CD2406 CALL RBYTE ; CHECK SUM DATA
41 0544 382C JR C,RTP6
42 0546 5F   LD E,A
43 0547 CD2406 CALL RBYTE ; CHECK SUM DATA
44 054A 3826 JR C,RTP6
45 054C 8D   CP L
46 054D 2016 JR NZ,RTP5
47 054F 7B   LD A,E
48 0550 BC   CP H
49 0551 2012 JR NZ,RTP5
50 0553      RTPB: ENT
51 0553 AF   XOR A
52 0554      RTP4: ENT
53 0554      RET2: ENT
54 0554 E1   POP HL
55 0555 C1   POP BC
56 0556 D1   POP DE
57 0557 CD0007 CALL MSTOP
58 055A F5   PUSH AF
59 055B 3A9C11 LD A,(TIMFG) ; INT. CHECK
60 055E FEFO CP FOH

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 20

04.07.83

```

01 0560 2001 JR NZ,+3
02 0562 FB   EI
03 0563 F1   POP AF
04 0564 C9   RET
05 0565      ;
06 0565      RTP5: ENT
07 0565 15   DEC D
08 0566 2806 JR Z,RTP7
09 0568 62   LD H,D
10 0569 CDE20F CALL GAPCK
11 056C 18A5 JR RTP1
12 056E      RTP7: ENT
13 056E 3E01 LD A,1
14 0570 1802 JR RTP9
15 0572      RTP6: ENT
16 0572 3E02 LD A,2
17 0574      RTP9: ENT
18 0574 37   SCF
19 0575 18DD JR RTP4
20 0577      ;
21 0577      ;
22 0577      ; BELL
23 0577      ;
24 0577      ;
25 0577 D5   ENT
26 0578 115203 PUSH DE
27 057B F7   LD DE,?BELD
28 057C D1   RST 6 ; CALL MELDY
29 057D C9   POP DE
30 057E      RET
31 057E      ;
32 057E      ; FLASING AND KEYIN
33 057E      ; EXIT:ACC INPUT KEY DATA(DSP.CODE)
34 057E      ; H=FOH THEN NO KEYIN(Z FLG.)
35 057E      ;
36 057E CDF09 FLKEY: ENT
37 0581 CDCA08 CALL ?FLAS
38 0584 FEFO CALL ?KEY
39 0586 C9   CP FOH
40 0587      RET
41 0587      ;
42 0587      ;
43 0587      ;
44 0587      ;
45 0587      ;
46 0588      DEFS +1
47 0588      ;ORG 0588H
48 0588      ;
49 0588      ;
50 0588      ; VERIFY (FROM #CMT)-
51 0588      ;
52 0588      ; EXIT ACC =0 : OK CF=0
53 0588      ; =1 : ER CF=1
54 0588      ; =2 : BREAK CF=1
55 0588      ;
56 0588 F3   ?VRFY: ENT
57 0589 D5   DI
58 058A C5   PUSH DE
59 058B E5   PUSH BC
60 058C ED4B0211 PUSH HL

```

```

01 0590 2A0411      LD    HL,(DTADR)
02 0593 16D2        LD    D,D2H
03 0595 1E53        LD    E,53H
04 0597 78          LD    A,B
05 0598 B1          OR    C
06 0599 28B9        JR    Z,RTP4
07 059B CD1A07      CALL  CKSUM
08 059E CD9F06      CALL  MOTOR
09 05A1 38CF        JR    C,RTP6
10 05A3 CD5B06      CALL  TMARK
11 05A6 38CA        JR    C,RTP6
12 05A8 CDAD05      CALL  TVRFY
13 05AB 18A7        JR    RTP4
14 05AD              ;
15 05AD              ;
16 05AD              ; DATA VERIFY
17 05AD              ;
18 05AD              ; BC=SIZE
19 05AD              ; HL=DATA LOW ADR
20 05AD              ; CSMDT=CHECK SUM
21 05AD              ; EXIT ACC=0 : OK CF=0
22 05AD              ; =1 : ER =1
23 05AD              ; =2 : BREAK=1
24 05AD              ;
25 05AD              ;
26 05AD TVRFY: ENT
27 05AD D5          PUSH  DE
28 05AE C5          PUSH  BC
29 05AF E5          PUSH  HL
30 05B0 2602        LD    H,2
31 05B2 TVF1: ENT
32 05B2 0101E0      LD    BC,KEYPB
33 05B5 1102E0      LD    DE,CSTR
34 05B8 TVF2: ENT
35 05B8 CD0106      CALL  EDGE
36 05BB DA7205      JP    C,RTP6
37 05BE CD4A0A      CALL  DLY3
38 05C1 1A          LD    A,(DE)
39 05C2 E620        AND   20H
40 05C4 CABB05      JP    Z,TVF2
41 05C7 54          LD    ,D,H
42 05C8 E1          POP   HL
43 05C9 C1          POP   BC
44 05CA C5          PUSH  BC
45 05CB E5          PUSH  HL
46 05CC TVF3: ENT
47 05CC CD2406      CALL  RBYTE
48 05CF 38A1        JR    C,RTP6
49 05D1 BE          CP    (HL)
50 05D2 209A        JR    NZ,RTP7
51 05D4 23          INC   HL
52 05D5 0B          DEC   BC
53 05D6 78          LD    A,B
54 05D7 B1          OR    C
55 05D8 20F2        JR    NZ,TVF3
56 05DA 2A9911      LD    HL,(CSMDT)
57 05DD CD2406      CALL  RBYTE
58 05E0 BC          CP    H
59 05E1 20BB        JR    NZ,RTP7
60 05E3 CD2406      CALL  RBYTE
    
```

```

01 05E6 BD          CP    L
02 05E7 20B5        JR    NZ,RTP7
03 05E9 15          DEC   D
04 05EA CA5305      JP    Z,RTP8
05 05ED 62          LD    H,D
06 05EE 18C2        JR    TVF1
07 05F0              ;
08 05F0              ; FLASHING DATA LOAD
09 05F0              ;
10 05F0 ?LOAD: ENT
11 05F0 F5          PUSH  AF
12 05F1 3A8E11      LD    A,(FLASH)
13 05F4 CDB10F      CALL  ?PONT
14 05F7 77          LD    (HL),A
15 05FB F1          POP   AF
16 05F9 C9          RET
17 05FA              ;
18 05FA              ;
19 05FA              ; NEW LINE AND PRINT HL REG.(ASCII)
20 05FA              ;
21 05FA NLPHL: ENT
22 05FA CD0900      CALL  NL
23 05FD CDBA03      CALL  PRTHL
24 0600 C9          RET
25 0601              ;
26 0601              ;
27 0601 ;ORG 0601H;EDGE
28 0601              ;
29 0601              ;
30 0601 ; EDGE (TAPE DATA EDGE DETECT)
31 0601              ;
32 0601 ; BC=KEYPB ($E001)
33 0601 ; DE=CSTR ($E002)
34 0601 ; EXIT CF=0 OK : CF=1 BREAK
35 0601              ;
36 0601 EDGE: ENT
37 0601 3EFB        LD    A,FBH
38 0603 3200E0      LD    (KEYPA),A
39 0606 00          NOP
40 0607 EDG1: ENT
41 0607 0A          LD    A,(BC)
42 0608 E6B1        AND   B1H
43 060A 2002        JR    NZ,+4
44 060C 37          SCF
45 060D C9          RET
46 060E 1A          LD    A,(DE)
47 060F E620        AND   20H
48 0611 20F4        JR    NZ,EDG1
49 0613 EDG2: ENT
50 0613 0A          LD    A,(BC)
51 0614 E6B1        AND   B1H
52 0616 2002        JR    NZ,+4
53 0618 37          SCF
54 0619 C9          RET
55 061A 1A          LD    A,(DE)
56 061B E620        AND   20H
57 061D 2BF4        JR    Z,EDG2
58 061F C9          RET
59 0620              ;
60 0620              ;
    
```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 23

04.07.83

```

01 0620          DEFS  +4
02 0624          ;ORG 0624H;RBYTE
03 0624          ;
04 0624          ;
05 0624          ; 1 BYTE READ
06 0624          ;
07 0624          ; EXIT SUMDT=STORE
08 0624          ; CF=1 : BREAK
09 0624          ;
10 0624          ; CF=0 : DATA=ACC
11 0624          ;
12 0624          RBYTE: ENT
13 0624 C5       PUSH BC
14 0625 D5       PUSH DE
15 0626 E5       PUSH HL
16 0627 21000B   LD HL,0B00H
17 062A 0101E0   LD BC,KEYPB
18 062D 1102E0   LD DE,CSTR
19 0630          RBY1: ENT
20 0630 CD0106   CALL EDGE
21 0633 DA5406   JP C,RBY3
22 0636 CD4A0A   CALL DLY3
23 0639 1A       LD A,(DE)
24 063A E620     AND 20H
25 063C CA4906   JP Z,RBY2
26 063F E5       PUSH HL
27 0640 2A9711   LD HL,(SUMDT)
28 0643 23       INC HL
29 0644 229711   LD (SUMDT),HL
30 0647 E1       POP HL
31 0648 37       SCF
32 0649          RBY2: ENT
33 0649 7D       LD A,L
34 064A 17       RLA
35 064B 6F       LD L,A
36 064C 25       DEC H
37 064D C23006   JP NZ,RBY1
38 0650 CD0106   CALL EDGE
39 0653 7D       LD A,L
40 0654          RBY3: ENT
41 0654 E1       POP HL
42 0655 D1       POP DE
43 0656 C1       POP BC
44 0657 C9       RET
45 0658          ;
46 0658          ;
47 0658          ; TAPE MARK DETECT
48 0658          ;
49 0658          ; E=0L0 : INFORMATION
50 0658          ; =0S0 : DATA
51 0658          ; EXIT CF=0 :OK
52 0658          ; =1 :BREAK
53 0658          ;
54 0658          ; DEFS +3
55 065B          ;
56 065B          ; THARK: ENT
57 065B          ;
58 065B          ;ORG 065BH
59 065B          ;
60 065B CDE20F   CALL GAPCK

```

```

; KEY DATA $E001
; $TAPE DATA $E002
; 41 OR 101
; 13
; 20+18*63+33
; DATA READ :B

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 24

04.07.83

```

01 065E C5       PUSH BC
02 065F D5       PUSH DE
03 0660 E5       PUSH HL
04 0661 21282B   LD HL,2828H
05 0664 7B       LD A,E
06 0665 FECC     CP CCH
07 0667 2B03     JR Z,+5
08 0669 211414   LD HL,1414H
09 066C 229511   LD (TMCNT),HL
10 066F 0101E0   LD BC,KEYPB
11 0672 1102E0   LD DE,CSTR
12 0675          TM1: ENT
13 0675 2A9511   LD HL,(TMCNT)
14 0678          TM2: ENT
15 0678 CD0106   CALL EDGE
16 067B 3B1E     JR C,TM4
17 067D CD4A0A   CALL DLY3
18 0680 1A       LD A,(DE)
19 0681 E620     AND 20H
20 0683 2BF0     JR Z,TM1
21 0685 25       DEC H
22 0686 20F0     JR NZ,TM2
23 0688          TM3: ENT
24 0688 CD0106   CALL EDGE
25 068B 3B0E     JR C,TM4
26 068D CD4A0A   CALL DLY3
27 0690 1A       LD A,(DE)
28 0691 E620     AND 20H
29 0693 20E0     JR NZ,TM1
30 0695 2D       DEC L
31 0696 20F0     JR NZ,TM3
32 0698 CD0106   CALL EDGE
33 069B          RET3: ENT
34 069B          TM4: ENT
35 069B E1       POP HL
36 069C D1       POP DE
37 069D C1       POP BC
38 069E C9       RET
39 069F          ;
40 069F          ;
41 069F          ; MOTOR ON
42 069F          ;
43 069F          ; IN D=0W0 :WRITE
44 069F          ; =0R0 :READ
45 069F          ; EXIT CF=0 :OK
46 069F          ; =1 :BREAK
47 069F          ;
48 069F          ; MOTOR: ENT
49 06A0 D5       PUSH BC
50 06A1 E5       PUSH DE
51 06A2 060A     LD B,10
52 06A4          MOT1: ENT
53 06A4 3A02E0   LD A,(CSTR)
54 06A7 E610     AND 10H
55 06A9 2B0E     JR Z,MOT4
56 06AB          MOT2: ENT
57 06AB 06FF     LD B,FFH
58 06AD CD9609   CALL DLY12
59 06B0 1B02     JR +4
60 06B2 1BEB     JR MOTOR

```

```

; ORG 065EH
; 'L
; CALL DLY2*3
; CALL DLY2*3
; CALL DLY2*3
; 2 SEC DELAY
; 7 MSEC DELAY
; MOTOR ENTRY ADJUST
; ORG 06B2H

```

```

01 06B4 10F7          DJNZ  -7
02 06B6 AF           XOR   A
03 06B7              MOT7:  ENT
04 06B7 18E2         JR    RET3
05 06B9              MOT4:  ENT
06 06B9 3E06         LD    A,06H
07 06BB 2103E0       LD    HL,CSTPT
08 06BE 77           LD    (HL),A
09 06BF 3C           INC   A
10 06C0 77           LD    (HL),A
11 06C1 10E1         DJNZ  MOT1
12 06C3 CD0900       CALL NL
13 06C6 7A           LD    A,D
14 06C7 FED7         CP    D7H          ; 'W'
15 06C9 2805         JR    Z,MOT8
16 06CB 11FB03       LD    DE,MSG#1     ; PLAY MARK
17 06CE 1807         JR    MOT9
18 06D0              MOT8:  ENT
19 06D0 110204       LD    DE,MSG#3     ; "RECORD."
20 06D3 DF           RST   3            ; CALL MSGX
21 06D4 11FD03       LD    DE,MSG#2     ; "PLAY"
22 06D7              MOT9:  ENT
23 06D7 DF           RST   3            ; CALL MSGX
24 06DB              MOT5:  ENT
25 06DB 3A02E0       LD    A,(CSTR)
26 06DB E610         AND   10H
27 06DD 20CC         JR    NZ,MOT2
28 06DF CD320A       CALL ?BRK
29 06E2 20F4         JR    NZ,MOT5
30 06E4 37           SCF
31 06E5 18D0         JR    MOT7
32 06E7              ;
33 06E7              ; INITIAL MESSAGE
34 06E7              ;
35 06E7              ;
36 06E7 2A2A2020     MSG?3: ENT
37 06EB 4D4F4E49     DEFM  '*** MONITOR 1Z-013A ***'
38 06EF 544F5220
39 06F3 315A2D30
40 06F7 31334120
41 06FB 202A2A
42 06FE OD           DEFB  ODH
43 06FF              ;
44 06FF              ;
45 06FF              ; DEFS  +1
46 0700              ;
47 0700              ;
48 0700              ; ORG 0700H;MSTOP
49 0700              ;
50 0700              ;
51 0700              ; MOTDR STOP
52 0700              ;
53 0700              ;
54 0700 F5           MSTOP: ENT
55 0701 C5           PUSH  AF
56 0702 D5           PUSH  BC
57 0703 060A        LD    B,10
58 0705              MST1:  ENT
59 0705 3A02E0       LD    A,(CSTR)
60 0708 E610         AND   10H
    
```

```

01 070A 280B        JR    Z,MST3
02 070C              MST2:  ENT
03 070C 3E06        LD    A,06H
04 070E 3203E0     LD    (CSTPT),A
05 0711 3C         INC   A
06 0712 3203E0     LD    (CSTPT),A
07 0715 10EE       DJNZ  MST1
08 0717              MST3:  ENT
09 0717 C3E60E     JP    ?RSTR1
10 071A              ;
11 071A              ;
12 071A              ;
13 071A              ;
14 071A              ; CHECK SUM
15 071A              ;
16 071A              ; IN   BC=SIZE
17 071A              ; HL=DATA ADR.
18 071A              ; EXIT SUMDT=STORE
19 071A              ; CSMDT=STORE
20 071A              ;
21 071A              ;
22 071A C5         CKSUM:  ENT
23 071B D5         PUSH  BC
24 071C E5         PUSH  DE
25 071D 110000     PUSH  HL
26 0720              LD    DE,0
27 0720 78         CKS1:  ENT
28 0721 B1         LD    A,B
29 0722 200B       OR    C
30 0724 EB         JR    NZ,CKS2
31 0725 229711     EX   DE,HL
32 0728 229911     LD    (SUMDT),HL
33 072B E1         LD    (CSMDT),HL
34 072C D1         POP   HL
35 072D C1         POP   DE
36 072E C9         POP   BC
37 072F              RET
38 072F 7E         CKS2:  ENT
39 0730 C5         LD    A,(HL)
40 0731 060B       PUSH  BC
41 0733              LD    B,+8
42 0733 07         CKS3:  ENT
43 0734 3001       RLCA
44 0736 13         JR    NC,+3
45 0737 10FA       INC   DE
46 0739 C1         DJNZ  CKS3
47 073A 23         POP   BC
48 073B 0B         INC   HL
49 073C 18E2       DEC   BC
50 073E              JR    CKS1
51 073E              ;
52 073E              ; MODE SET OF KEYPORT
53 073E              ;
54 073E 2103E0     ?MODE: ENT
55 0741 368A       LD    HL,KEYPF
56 0743 3607       LD    (HL),BAH    ; 10001010
57 0745 3605       LD    (HL),07H   ; PC3=1
58 0747              LD    (HL),05H   ; PC2=1
59 0747              VGOFF: ENT
60 0747 C9         ;
    RET
    
```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 27          04.07.83
01 0748 ;
02 0748 ;
03 0748     DEFS    +17
04 0759 ;
05 0759 ;ORG 0759H;DLY1
06 0759 ;
07 0759 ; 107 MICRO SEC DELY
08 0759 ;
09 0759 DLY1:  ENT
10 0759     LD      A,15H      ; 18*21+20
11 075B     DEC     A
12 075C     JP      NZ,-1
13 075F     C9
14 0760 ;
15 0760 ;ORG 0760H;DLY2
16 0760 ;
17 0760 DLY2:  ENT
18 0760     LD      A,13H      ; 18*19+20
19 0762     DEC     A
20 0763     JP      NZ,-1
21 0766     C9
22 0767 ;
23 0767 ;
24 0767 ;
25 0767 ;
26 0767 ;
27 0767 ; 1 BYTE WRITE
28 0767 ;
29 0767 WBYTE: ENT
30 0767     PUSH   BC
31 0768     LD      B,+8
32 076A     CALL   LONG
33 076D     WBY1:  ENT
34 076D     RLCA
35 076E     CALL   C, LONG
36 0771     CALL   NC, SHORT
37 0774     DEC     B
38 0775     JP      NZ, WBY1
39 0778     C1
40 0779     POP    BC
41 077A ;
42 077A ;
43 077A ; GAP + TAPEMARK
44 077A ;
45 077A ; E=@L@ LONG GAP
46 077A ; =@S@ SHORT GAP
47 077A ;
48 077A GAP:  ENT
49 077A     PUSH   BC
50 077B     PUSH   DE
51 077C     LD      A,E
52 077D     LD      BC,55F0H
53 0780     LD      DE,2828H
54 0783     CP      CCH      ; L
55 0785     JP      Z, GAP1
56 0788     LD      BC,2AF8H
57 078B     LD      DE,1414H
58 078E     GAP1:  ENT
59 078E     CALL   SHORT
60 0791     DEC     BC

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 28          04.07.83
01 0792 '78     LD      A,B
02 0793 B1     OR      C
03 0794 20FB   JR      NZ,-6
04 0796     GAP2:  ENT
05 0796     CALL   LONG
06 0799     DEC     D
07 079A 20FA   JR      NZ,-4
08 079C     GAP3:  ENT
09 079C CD010A CALL   SHORT
10 079F 1D     DEC     E
11 07A0 20FA   JR      NZ,-4
12 07A2 CD1A0A CALL   LONG
13 07A5 D1     POP    DE
14 07A6 C1     POP    BC
15 07A7 C9     RET
16 07AB ;
17 07AB ; MEMORY CORRECTION
18 07AB ; COMMAND 'M'
19 07AB ;
20 07AB MCR0:  ENT
21 07AB CD3D01 CALL   HEXIY      ; CRRECTION ADR.
22 07AB     MCR1:  ENT
23 07AB     CALL   NLPHL      ; COR. ADR. PRINT
24 07AE CDB103 CALL   SPHEX      ; ACC ⇔ ASCII DISP.
25 07B1 CD2009 CALL   ?PRTS      ; SPACE PRINT
26 07B4 CD2F01 CALL   BGETL      ; GET DATA & CHECK DATA
27 07B7 CD1004 CALL   HLHEX      ; HL(ASCII)(DE)
28 07BA 3B1B   JR      C, MCR3
29 07BC CDA602 CALL   .4DE       ; (INC DE)*4
30 07BF 13     INC     DE
31 07C0 CD1F04 CALL   ZHEX       ; DATA CHECK
32 07C3 3B66   JR      C, MCR1
33 07C5 BE     CP      (HL)
34 07C6 20E3   JR      NZ, MCR1
35 07C8 13     INC     DE
36 07C9 1A     LD      A,(DE)
37 07CA FE0D   CP      0DH      ; NOT CORRECTION ?
38 07CC 2B06   JR      Z, MCR2
39 07CE CD1F04 CALL   ZHEX       ; ACC+HL(ASCII)
40 07D1 3BDB   JR      C, MCR1
41 07D3 77     LD      (HL),A   ; DATA CORRECT
42 07D4     MCR2:  ENT
43 07D4     INC     HL
44 07D5 1BD4   JR      MCR1
45 07D7 ;
46 07D7 60     MCR3:  LD      H,B   ; MEMORY ADR.
47 07D8 69     LD      L,C
48 07D9 1BD0   JR      MCR1
49 07DB ;
50 07DB ;
51 07DB ;
52 07DB ;
53 07DB ;
54 07E6     ORG    07E6H
55 07E6 ;
56 07E6 ;
57 07E6 ;
58 07E6 ; GET 1 LINE STATEMENT *
59 07E6 ;
60 07E6 ; DE = DATA STORE LOW ADR.

```



```

01 07E6          ;          (END =CR )
02 07E6          ;
03 07E6          ;
04 07E6          ?GETL: ENT
05 07E6 F5      PUSH  AF
06 07E7 C5      PUSH  BC
07 07E8 E5      PUSH  HL
08 07E9 D5      PUSH  DE
09 07EA          GETL1: ENT
10 07EA CDB309  CALL  ??KEY          ; ENTRY KEY
11 07ED          AUT03: ENT
12 07ED F5      PUSH  AF          ; IN KEY DATA SAVE
13 07EE 47      LD    B,A
14 07EF 3A9D11  LD    A,(SWRK)          ; BELL WORK
15 07F2 0F      RRCA
16 07F3 D47705  CALL  NC,?BEL          ; ENTRY BELL
17 07F6 78      LD    A,B
18 07F7 217011  LD    HL,KANAF          ; KANA & GRAPH FLAG
19 07FA E6F0    AND   FOH
20 07FC FEC0    CP    COH
21 07FE D1      POP   DE          ; Ereg=FLAGreg
22 07FF 78      LD    A,B
23 0800 2016    JR    NZ,GETL2
24 0802 FECD    CP    CDH          ; CR
25 0804 2855    JR    Z,GETL3
26 0806 FECB    CP    CBH          ; BREAK
27 0808 CA220B  JP    Z,GETLC
28 080B FECE    CP    CFH          ; NIKO MARK WH.
29 080D 2809    JR    Z,GETL2
30 080F FEC7    CP    C7H          ; CRT EDITION
31 0811 300A    JR    NC,GETL5
32 0813 CB1B    RR    E          ; CY ?
33 0815 78      LD    A,B
34 0816 3005    JR    NC,GETL5
35 0818          ;
36 0818 CDB50D  GETL2: ENT
37 081B 1BCD    CALL  ?DSP
38 081D          JR    GETL1
39 081D CDDC0D  GETL5: ENT
40 0820 18C8    CALL  ?DPCT          ; CRT CONTROL
41 0822          JR    GETL1
42 0822          ;          BREAK IN
43 0822          ;
44 0822 E1      GETLC: POP  HL
45 0823 E5      PUSH  HL
46 0824 361B    LD    (HL),1BH          ; BREAK CODE
47 0826 23      INC   HL
48 0827 360D    LD    (HL),0DH
49 0829 1853    JR    GETLR
50 082B          ;          GETLA
51 082B          ;
52 082B 0F      GETLA: RRCA          ; CY+D7
53 082C 3037    JR    NC,GETL6
54 082E 1833    JR    GETLB
55 0830          ;
56 0830          ;
57 0830          ;
58 0830          ;          DELAY 7M SEC AND SWEP
59 0830          ;
60 0830 CD9609  DSWEF: CALL  DLY12
    
```

```

01 0833 CD500A          CALL  ?SWEP
02 0836 C9              RET
03 0837          ;
04 0837          ;
05 0837          DEFS  36
06 085B          ;
07 085B          ;
08 085B          ;
09 085B          ;          ORG 085BH;GETL3
10 085B          ;
11 085B CDF302          GETL3: CALL  .MANG          ; CR
12 085E 062B          LD    B,40          ; 1LINE
13 0860 30C9          JR    NC,GETLA
14 0862 25          DEC   H          ; BEFORE LINE
15 0863 0650          GETLB: LD  B,80          ; 2 LINE
16 0865 2E00          GETL6: LD  L,0
17 0867 CDB40F          CALL  ?PNT1
18 086A D1              POP   DE          ; STORE TOP ADR.
19 086B D5              PUSH  DE
20 086C 7E              GETLZ: LD  A,(HL)
21 086D CDCE0B          CALL  ?DACN
22 0870 12              LD    (DE),A
23 0871 23              INC   HL
24 0872 13              INC   DE
25 0873 10F7           DJNZ  GETLZ
26 0875 EB              EX    DE,HL
27 0876 360D           GETLU: LD  (HL),0DH
28 0878 2B              DEC   HL
29 0879 7E              LD    A,(HL)
30 087A FE20           CP    20H          ; SPACE THEN CR
31 087C          ;
32 087C          ;
33 087C          ;          CR AND NEW LINE
34 087C          ;
35 087C 28F8          JR    Z,GETLU
36 087E          ;
37 087E          ;          NEW LINE RETURN
38 087E          ;
39 087E CD0E09          GETLR: CALL  ?LTNL
40 0881 D1              POP   DE
41 0882 E1              POP   HL
42 0883 C1              POP   BC
43 0884 F1              POP   AF
44 0885 C9              RET
45 0886          ;
46 0886          ;
47 0886          ;
48 0886          DEFS  +13
49 0893          ;          ORG 0893H
50 0893          ;
51 0893          ;          MESSAGE PRINT
52 0893          ;
53 0893          ;          DE PRINT DATA LOW ADR.
54 0893          ;          END=CR
55 0893          ;
56 0893          ;          ?MSG: ENT
57 0893 F5              PUSH  AF
58 0894 C5              PUSH  BC
59 0895 D5              PUSH  DE
60 0896 1A              MSG1: LD  A,(DE)
    
```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 31

04.07.83

```

01 0B97 FE0D          CP      0DH          ; CR
02 0B97 2B0C          JR      Z,MSGX2
03 0B9B CD3509        CALL   ?PRNT
04 0B9E 13           INC     DE
05 0B9F 1BF5          JR      MSG1
06 0BA1              ;
07 0BA1              ;
08 0BA1              ;ORG 0BA1H
09 0BA1              ;
10 0BA1              ; ALL PRINT MESSAGE
11 0BA1              ;
12 0BA1              ?MSGX: ENT
13 0BA1 F5           PUSH   AF
14 0BA2 C5           PUSH   BC
15 0BA3 D5           PUSH   DE
16 0BA4 1A           MSGX1: LD   A,(DE)
17 0BA5 FE0D          CP      0DH
18 0BA7 CAE60E        MSGX2: JP   Z,?RSTR1
19 0BAA CDB90B        CALL   ?ADCN
20 0BAD CD6C09        CALL   PRNT3
21 0BB0 13           INC     DE
22 0BB1 1BF1          JR      MSGX1
23 0BB3              ;
24 0BB3              ; TOP OF KEYTBLS
25 0BB3              ;
26 0BB3 112A0C        ?KYSM: LD   DE,KTBL5
27 0BB6 1B42          JR      ?KY5
28 0BB8              ;
29 0BB8              ; BREAK CODE IN
30 0BB8              ;
31 0BB8 3ECB          #BRK: LD   A,CBH          ; BREAK CODE
32 0BBA B7           OR     A
33 0BBB 1B19          JR      ?KY1
34 0BBD              ;
35 0BBD              ;
36 0BBD              ;ORG 0BBDH
37 0BBD              ;
38 0BBD              ; GETKEY
39 0BBD              ;
40 0BBD              ; NOT ECHO BACK
41 0BBD              ;
42 0BBD              ; EXIT:ACC=ASCII CODE
43 0BBD              ;
44 0BBD              ?GET: ENT
45 0BBD CDCA0B        CALL   ?KEY          ; KEY IN (DISPLAY CODE)
46 0BC0 D6F0          SUB    F0H          ; NOT KEYIN CODE
47 0BC2 C8           RET    Z
48 0BC3 C6F0          ADD    A,F0H
49 0BC5 C3CE0B        JP     ?DACN        ; DIAPLAY TO ASCII CODE
50 0BC8              ;
51 0BC8              ;
52 0BC8              ; DEFS +2
53 0BCA              ;
54 0BCA              ;
55 0BCA              ;
56 0BCA              ;
57 0BCA              ;ORG 0BCAH;?KEY
58 0BCA              ;
59 0BCA              ; 1KEY INPUT
60 0BCA              ; IN      B = KEY MODE(SHIFT,CTRL,BREAK)

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 32

04.07.83

```

01 0BCA              ; C = KEY DATA (COLUMN & ROW)
02 0BCA              ; EXIT ACC=DISPLAY CODE
03 0BCA              ; IF NO KEY ACC=FOH
04 0BCA              ; IF CY=1 THEN ATTRIBUTE ON
05 0BCA              ; (SMALL,HIRAKANA)
06 0BCA              ;
07 0BCA              ;?KEY: ENT
08 0BCA C5           PUSH   BC
09 0BCB D5           PUSH   DE
10 0BCC E5           PUSH   HL
11 0BCD CD300B        CALL   DSWEP        ; DELAY AND KEY SWEP
12 0BD0 7B           LD     A,B
13 0BD1 07           RLCA
14 0BD2 3B06          JR     C,?KY2
15 0BD4 3EFO          LD     A,FOH
16 0BD6              ;?KY1: ENT
17 0BD6 E1           POP    HL
18 0BD7 D1           POP    DE
19 0BD8 C1           POP    BC
20 0BD9 C9           RET
21 0BDA              ;
22 0BDA              ;?KY2: ENT
23 0BDA 11EA0B        LD     DE,KTBL      ; NORMAL KEY TABLE
24 0BDD 7B           LD     A,B
25 0BDE FE8B          CP     8BH          ; BREAK IN
26 0BE0 2BD6          JR     Z,#BRK
27 0BE2 2600          LD     H,0          ; HL=ROW & COLUMN
28 0BE4 69           LD     L,C
29 0BE5 CB6F          BIT   5,A          ; CTRL CHECK
30 0BE7 200E          JR     NZ,?KY5-3
31 0BE9 3A7011        LD     A,(KANAF)   ; 0=NR.,1=GRAPH
32 0BEC 0F           RRCA
33 0BED DAFE0B        JP     C,?KYGRP    ; GRAPH MODE
34 0BF0 7B           LD     A,B          ; CTRL KEY CHECK
35 0BF1 17           RLA
36 0BF2 17           RLA
37 0BF3 3B8E          JR     C,?KYSM
38 0BF5 1B03          JR     ?KYS
39 0BF7 11AA0C        LD     DE,KTBLC    ; CONTROL KEY TABLE
40 0BFA              ;?KY5: ENT
41 0BFA 19           ADD    HL,DE        ; TABLE
42 0BFB              ;?KY55: ENT
43 0BFB 7E           LD     A,(HL)
44 0BFC 1BDB          JR     ?KY1
45 0BFE              ;?KYGRP: ENT
46 0BFE CB70          BIT   6,B
47 0900 2B07          JR     Z,?KYGRS
48 0902 11E90C        LD     DE,KTBLG
49 0905 19           ADD    HL,DE
50 0906 37           SCF
51 0907 1BF2          JR     ?KY55
52 0909              ;
53 0909 116A0C        ;?KYGRS: LD   DE,KTBLGS
54 090C 1BEC          JR     ?KYS
55 090E              ;
56 090E              ;
57 090E              ;
58 090E              ;
59 090E              ;
60 090E              ;ORG 090EH

```

```

01 090E      ;
02 090E      ;   NEWLINE
03 090E      ;
04 090E      ;?LTNL: ENT
05 090E AF   XOR      A
06 090F 329411 LD      (DPRNT),A   ; ROW POINTER
07 0912 3ECD  LD      A,CDH   ; CR
08 0914 1843  JR      PRNT5
09 0916      DEFS    +2
10 0918      ;ORG 0918H
11 0918      ;
12 0918      ;?NL: ENT
13 0918 3A9411 LD      A,(DPRNT)
14 091B B7    OR      A
15 091C CB   RET      Z
16 091D 18EF  JR      ?LTNL
17 091F      DEFS    +1
18 0920      ;ORG 0920H
19 0920      ;
20 0920      ;   PRINT SPACE
21 0920      ;
22 0920      ;?PRTS: ENT
23 0920 3E20  LD      A,20H
24 0922 1811  JR      ?PRT
25 0924      ;
26 0924      ;   PRINT TAB
27 0924      ;
28 0924      ;?PRTT: ENT
29 0924 CD0C00 CALL   PRNTS
30 0927 3A9411 LD      A,(DPRNT)
31 092A B7    OR      A
32 092B CB   RET      Z
33 092C D60A  SUB    +10
34 092E 3BF4  JR      C,-10
35 0930 20FA  JR      NZ,-4
36 0932      DEFS    +3
37 0935      ;ORG 0935H
38 0935      ;
39 0935      ;   PRINT
40 0935      ;
41 0935      ;   IN ACC = PRINT DATA (ASCII)
42 0935      ;
43 0935      ;?PRNT: ENT
44 0935 FE0D  CP      ODH   ; CR
45 0937 2BD5  JR      Z,?LTNL
46 0939 C5    PUSH   BC
47 093A 4F   LD      C,A
48 093B 47   LD      B,A
49 093C CD4609 CALL   ?PRT
50 093F 78   LD      A,B
51 0940 C1   POP     BC
52 0941 C9   RET
53 0942      ;
54 0942      ;
55 0942      ;MSGOK: ENT
56 0942 4F4B21 DEFM  'OK!'
57 0945 OD   DEFB  ODH
58 0946      ;ORG 0946H
59 0946      ;
60 0946      ;   PRINT ROUTINE
    
```

```

01 0946      ;   I CHA.
02 0946      ;   INPUT:C=ASCII DATA (?DSP+?DPCT)
03 0946      ;
04 0946      ;?PRT: ENT
05 0946 79   LD      A,C
06 0947 CDB90B CALL   ?ADCN   ; ASCII TO DSPLAY
07 094A 4F   LD      C,A
08 094B FEFO  CP      FOH
09 094D CB   RET      Z   ; ZERO=ILLEGAL DATA
10 094E E6F0  AND    FOH   ; MSD CHECK
11 0950 FE00  CP      COH
12 0952 79   LD      A,C
13 0953 2017  JR      NZ,PRNT3
14 0955 FEC7  CP      C7H
15 0957 3013  JR      NC,PRNT3   ; CRT EDITOR
16 0959      ;PRNT5: ENT
17 0959 CDDC0D CALL   ?DPCT
18 095C FEC3  CP      C3H
19 095E 280F  JR      Z,PRNT4
20 0960 FE05  CP      C5H   ; HOME
21 0962 2803  JR      Z,PRNT2
22 0964 FEC6  CP      C6H   ; CLR
23 0966 C0   RET      NZ
24 0967 AF   XOR      A
25 0968 329411 LD      (DPRNT),A
26 096B C9   RET
27 096C      ;PRNT3: ENT
28 096C CDB50D CALL   ?DSP
29 096F 3A9411 LD      A,(DPRNT)   ; TAB POINT+1
30 0972 3C   INC     A
31 0973 FE50  CP      +B0
32 0975 3BF1  JR      C,PRNT2+1
33 0977 D650  SUB    +B0
34 0979 18ED  JR      PRNT2+1
35 097B      ;
36 097B      ;
37 097B      ;
38 097B      ;
39 097B      ;
40 097B      ;   FLASSING BYPASS 1
41 097B      ;
42 097B      ;
43 097B 3ABE11 FLAS1: ENT
44 097E 186F  LD      A,(FLASH)
45 0980      JR      FLAS2
46 0980      ;
47 0980      ;   BREAK SUBROUTINE BYPASS 1
48 0980      ;
49 0980      ;   CTRL OR NOT KEY
50 0980      ;
51 0980 CB6F  ?BRK2: ENT
52 0982 2B02  BIT    5,A   ; NOT OR CTRL
53 0984 B7   JR      Z,?BRK3   ; CTRL
54 0985 C9   OR     A     ; NOTKEY A=7FH
55 0986      RET
56 0986 3E20  ?BRK3: LD    A,20H   ; CTRL D5=1
57 0988 B7   OR     A     ; ZERO FLG. CLR
58 0989 C7   SCF
59 098A C9   RET
60 098B      ;
    
```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 35      04.07.83

01 09BB      MSGSV:  ENT
02 09BB 46494C45      DEFM  'FILENAME?'
03 09BF 4E414D45
04 0993 3F20
05 0995 0D           DEFB  0DH
06 0996           ;
07 0996           ;   DLY 7 MSEC
08 0996           ;
09 0996      DLY12:  ENT
10 0996 C5           PUSH  BC
11 0997 0615         LD    B,15H
12 0999 CD4A0A       CALL  DLY3
13 099C 10FB        DJNZ  -3
14 099E C1           POP   BC
15 099F C9           RET
16 09A0           ;
17 09A0           ;
18 09A0           ;
19 09A0           ;   LOADING MESSAGE
20 09A0           ;
21 09A0      MSG?2:  ENT
22 09A0 4C4F4144     DEFM  'LOADING'
23 09A4 494E4720
24 09AB 0D           DEFB  0DH
25 09A9           ;
26 09A9           ;
27 09A9           ;
28 09A9           ;   DELAY FOR LONG PULSE
29 09A9           ;
30 09A9      DLY4:   ENT
31 09A9 3E59         LD    A,59H      ; 1B*B9+20
32 09AB 3D           DEC   A
33 09AC C2AB09       JP    NZ,-1
34 09AF C9           RET
35 09B0           ;
36 09B0           ;
37 09B0           ;   DEFS  +3
38 09B3           ;
39 09B3           ;
40 09B3           ;   ORG 09B3H;??KEY
41 09B3           ;
42 09B3           ;   KEY BOAD SEARCH
43 09B3           ;   & DISPLAY CODE CONV.
44 09B3           ;
45 09B3           ;   EXIT A = DISPLAY CODE
46 09B3           ;   CY= GRAPH MODE
47 09B3           ;   WITH CURSOR DISPLAY
48 09B3           ;
49 09B3      ??KEY:  ENT
50 09B3 E5           PUSH  HL
51 09B4 CD920B       CALL  ?SAVE
52 09B7           ;
53 09B7 CD7E05       CALL  FLKEY      ; KEY
54 09BA 20FB        JR    NZ,KSL1      ; KEY IN THEN JUMP
55 09BC           ;
56 09BC CD7E05       CALL  FLKEY
57 09BF 28FB        JR    Z,KSL2      ; NOT KEY IN THEN JUMP
58 09C1 67           LD    H,A
59 09C2 CD9609       CALL  DLY12     ; DELAY CHATTER
60 09C5 CDCA0B       CALL  ?KEY

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 36      04.07.83

01 09C8 F5           PUSH  AF
02 09C9 BC           CP    H           ; CHATER CHECK
03 09CA E1           POP   HL
04 09CB 20EF        JR    NZ,KSL2
05 09CD E5           PUSH  HL
06 09CE F1           POP   AF           ; IN KEY DATA
07 09CF CDF005      CALL  ?LOAD        ; FLSHING DATA LOAD
08 09D2 E1           POP   HL
09 09D3 C9           RET
10 09D4           ;
11 09D4           ;
12 09D4           ;   CLEAR 2
13 09D4           ;
14 09D4      #CLR0B: ENT           ; CY FLG.
15 09D4 AF          XOR   A
16 09D5      #CLRB:  ENT
17 09D5 01000B      LD    BC,0B00H
18 09D8      CLEAR:  ENT
19 09D8 D5          PUSH  DE           ; BC = CLR BYTE SIZE
20 09D9 57          LD    D,A           ; A = CLR DATA
21 09DA      CLEAR1: ENT
22 09DA 72          LD    (HL),D
23 09DB 23          INC   HL
24 09DC 0B          DEC   BC
25 09DD 78          LD    A,B
26 09DE B1          OR    C
27 09DF 20F9       JR    NZ,CLEAR1
28 09E1 D1          POP   DE
29 09E2 C9         RET
30 09E3           ;
31 09E3           ;
32 09E3           ;
33 09E3           ;
34 09E3           ;   FLASHING 2
35 09E3           ;
36 09E3      ?FLS:  ENT
37 09E3 F5         PUSH  AF
38 09E4 E5         PUSH  HL
39 09E5 3A02E0     LD    A,(KEYPC)
40 09E8 07         RLCA
41 09E9 07         RLCA
42 09EA 388F       JR    C,FLAS1
43 09EC 3A9211     LD    A,(FLSDT)
44 09EF      FLAS2: ENT
45 09EF CDB10F     CALL  ?PONT      ; DISPLAY POSITION
46 09F2 77         LD    (HL),A
47 09F3      FLAS3: ENT
48 09F3 E1         POP   HL
49 09F4 F1         POP   AF
50 09F5 C9         RET
51 09F6           ;
52 09F6           ;
53 09F6           ;
54 09F6           ;   DEFS  +9
55 09FF           ;
56 09FF           ;
57 09FF           ;   ORG 09FF ; ?FLAS
58 09FF           ;
59 09FF      ?FLAS: ENT
60 09FF 1BE2       JR    ?FLS

```

```

01 0A01 ;
02 0A01 ;
03 0A01 ;
04 0A01 ; SHORT AND LONG PULSE FOR 1 BIT WRITE
05 0A01 ;
06 0A01 ;
07 0A01 F5 SHORT: ENT
08 0A02 3E03 PUSH AF ; 12
09 0A04 3203E0 LD A,03H ; 9
10 0A07 CD5907 LD (CSTPT),A ; $E003 PC3=1:16
11 0A0A CD5907 CALL DLY1 ; 20+18*21+20
12 0A0D 3E02 LD A,02H ; 9
13 0A0F 3203E0 LD (CSTPT),A ; $E003 PC3=0:16
14 0A12 CD5907 CALL DLY1 ; 20+18*21+20
15 0A15 CD5907 CALL DLY1 ; 20+18*21+20
16 0A18 F1 POP AF ; 11
17 0A19 C9 RET ; 11
18 0A1A ;
19 0A1A ;
20 0A1A LONG: ENT
21 0A1A F5 PUSH AF ; 11
22 0A1B 3E03 LD A,03H ; 9
23 0A1D 3203E0 LD (CSTPT),A ; 16
24 0A20 CDA909 CALL DLY4 ; 20+18*89+20
25 0A23 3E02 LD A,02H ; 9
26 0A25 3203E0 LD (CSTPT),A ; 16
27 0A28 CDA909 CALL DLY4 ; 20+18*89+20
28 0A2B F1 POP AF ; 11
29 0A2C C9 RET ; 11
30 0A2D ;
31 0A2D ;
32 0A2D DEFS +5
33 0A32 ;
34 0A32 ;
35 0A32 ; ORG 0A32H
36 0A32 ;
37 0A32 ; BREAK KEY CHECK
38 0A32 ; AND SHIFT,CTRL KEY CHECK
39 0A32 ;
40 0A32 ; EXIT BREAK ON : ZERO=1
41 0A32 ; OFF: ZERO=0
42 0A32 ; NO KEY : CY =0
43 0A32 ; KEY IN : CY =1
44 0A32 ; A D6=1 : SHIFT ON
45 0A32 ; =0 : OFF
46 0A32 ; D5=1 : CTRL ON
47 0A32 ; =0 : OFF
48 0A32 ; D4=1 : SFT+CNT ON
49 0A32 ; =0 : OFF
50 0A32 ;
51 0A32 ?BRK: ENT
52 0A32 3EF8 LD A,F8H ; LINE 8SWEEP
53 0A34 3200E0 LD (KEYPA),A
54 0A37 00 NOP
55 0A3B 3A01E0 LD A,(KEYPB)
56 0A3B B7 OR A
57 0A3C 1F RRA
58 0A3D DA8009 JP C,?BRK2 ; SHIFT ?
59 0A40 17 RLA
60 0A41 17 RLA
    
```

```

01 0A42 3004 JR NC,?BRK1 ; BREAK ?
02 0A44 3E40 LD A,40H ; SHIFT D6=1
03 0A46 37 SCF
04 0A47 C9 RET
05 0A48 ;
06 0A48 ;
07 0A48 AF ?BRK1: XOR A ; SHIFT ?
08 0A49 C9 RET
09 0A4A ;
10 0A4A ;
11 0A4A ; 320 U SEC DELAY
12 0A4A ;
13 0A4A DLY3: ENT
14 0A4A 3E3F LD A,3FH ; 18*63+33
15 0A4C C36207 JP 0762H ; JP DLY2+2
16 0A4F ;
17 0A4F ;
18 0A4F DEFS +1
19 0A50 ;
20 0A50 ;
21 0A50 ;
22 0A50 ; ORG 0A50H ; ?SWEP
23 0A50 ;
24 0A50 ;
25 0A50 ; KEY BOAD SWEEP
26 0A50 ;
27 0A50 ; EXIT B,D7=0 NO DATA
28 0A50 ; =1 DATA
29 0A50 ; D6=0 SHIFT OFF
30 0A50 ; =1 SHIFT ON
31 0A50 ; D5=0 CTRL OFF
32 0A50 ; =1 CTRL ON
33 0A50 ; D4=0 SHIFT+CTRL OFF
34 0A50 ; =1 SHIFT+CTRL ON
35 0A50 ; C = ROW & COLOUMN
36 0A50 ; 7 6 5 4 3 2 1 0
37 0A50 ; * * * * *
38 0A50 ;
39 0A50 ;
40 0A50 D5 ?SWEP: ENT
41 0A51 E5 PUSH DE
42 0A52 AF PUSH HL
43 0A53 06F8 XOR A
44 0A55 57 LD B,F8H
45 0A56 CD320A LD D,A
46 0A59 2004 CALL ?BRK
47 0A5B 1688 JR NZ,SWEP6
48 0A5D 1814 LD D,88H ; BREAK ON
49 0A5F JR SWEP9
50 0A5F 3005 SWEP6: ENT
51 0A61 57 JR NC,SWEP0
52 0A62 1802 LD D,A
53 0A64 JR SWEP0
54 0A64 CBFA SWEP01: ENT
55 0A66 SET 7,D
56 0A66 05 SWEP0: ENT
57 0A67 78 DEC B
58 0A68 3200E0 LD (KEYPA),A
59 0A6B FEEF CP EFH ; MAP SWEEP END ?
60 0A6D 2008 JR NZ,SWEP3
    
```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 39          04.07.83

01 0A6F FEFB          CP      FBH          ; BREAK KEY ROW
02 0A71 2BF3          JR      Z,SWEPO
03 0A73              SWEP9: ENT
04 0A73 42          LD      B,D
05 0A74 E1          POP     HL
06 0A75 D1          POP     DE
07 0A76 C9          RET
08 0A77
09 0A77              SWEP3: ENT
10 0A77 3A01E0       LD      A,(KEYPB)
11 0A7A 2F          CPL
12 0A7B B7          OR      A
13 0A7C 28EB       JR      Z,SWEPO
14 0A7E 5F          LD      E,A
15 0A7F              SWEP2: ENT
16 0A7F 260B       LD      H,B
17 0A81 78          LD      A,B
18 0A82 E60F       AND     OFH
19 0A84 07          RLCA
20 0A85 07          RLCA
21 0A86 07          RLCA
22 0A87 4F          LD      C,A
23 0A88 7B          LD      A,E
24 0A89 25          DEC     H
25 0A8A 0F          RRCA
26 0A8B 30FC       JR      NC,-2
27 0A8D 7C          LD      A,H
28 0A8E 81          ADD     A,C
29 0A8F 4F          LD      C,A
30 0A90 18D2       JR      SWEP01
31 0A92
32 0A92
33 0A92              ; ASCII TO DISPLAY CODE TABL ;
34 0A92
35 0A92              ATBL:
36 0A92              ; 00 - 0F ;
37 0A92 F0          DEFB   FOH          ; 10
38 0A93 F0          DEFB   FOH          ; 1A
39 0A94 F0          DEFB   FOH          ; 1B
40 0A95 F3          DEFB   F3H          ; 1C
41 0A96 F0          DEFB   FOH          ; 1D
42 0A97 F5          DEFB   F5H          ; 1E
43 0A98 F0          DEFB   FOH          ; 1F
44 0A99 F0          DEFB   FOH          ; 1G
45 0A9A F0          DEFB   FOH          ; 1H
46 0A9B F0          DEFB   FOH          ; 1I
47 0A9C F0          DEFB   FOH          ; 1J
48 0A9D F0          DEFB   FOH          ; 1K
49 0A9E F0          DEFB   FOH          ; 1L
50 0A9F F0          DEFB   FOH          ; 1M
51 0AA0 F0          DEFB   FOH          ; 1N
52 0AA1 F0          DEFB   FOH          ; 1O
53 0AA2              ; 10 - 1F
54 0AA2 F0          DEFB   FOH          ; 1P
55 0AA3 C1          DEFB   C1H          ; 1Q CUR. DOWN
56 0AA4 C2          DEFB   C2H          ; 1R CUR. UP
57 0AA5 C3          DEFB   C3H          ; 1S CUR. RIGHT
58 0AA6 C4          DEFB   C4H          ; 1T CUR. LEFT
59 0AA7 C5          DEFB   C5H          ; 1U HOME
60 0AAB C6          DEFB   C6H          ; 1V CLEAR

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 40          04.07.83

01 0AA9 F0          DEFB   FOH          ; 1W
02 0AAA F0          DEFB   FOH          ; 1X
03 0AAB F0          DEFB   FOH          ; 1Y
04 0AAC F0          DEFB   FOH          ; 1Z SEP.
05 0AAD F0          DEFB   FOH          ; 1[
06 0AAE F0          DEFB   FOH          ; 1\
07 0AAF F0          DEFB   FOH          ; 1]
08 0AB0 F0          DEFB   FOH          ; 1^
09 0AB1 F0          DEFB   FOH          ; 1_
10 0AB2              ; 20 - 2F ;
11 0AB2 00          DEFB   00H          ; SPACE
12 0AB3 61          DEFB   61H          ; !
13 0AB4 62          DEFB   62H          ; "
14 0AB5 63          DEFB   63H          ; #
15 0AB6 64          DEFB   64H          ; $
16 0AB7 65          DEFB   65H          ; %
17 0AB8 66          DEFB   66H          ; &
18 0AB9 67          DEFB   67H          ; '
19 0ABA 68          DEFB   68H          ; (
20 0ABB 69          DEFB   69H          ; )
21 0ABC 6B          DEFB   6BH          ; *
22 0ABD 6A          DEFB   6AH          ; +
23 0ABE 2F          DEFB   2FH          ; ,
24 0ABF 2A          DEFB   2AH          ; -
25 0AC0 2E          DEFB   2EH          ; .
26 0AC1 2D          DEFB   2DH          ; /
27 0AC2              ; 30 - 3F ;
28 0AC2 20          DEFB   20H          ; 0
29 0AC3 21          DEFB   21H          ; 1
30 0AC4 22          DEFB   22H          ; 2
31 0AC5 23          DEFB   23H          ; 3
32 0AC6 24          DEFB   24H          ; 4
33 0AC7 25          DEFB   25H          ; 5
34 0AC8 26          DEFB   26H          ; 6
35 0AC9 27          DEFB   27H          ; 7
36 0ACA 28          DEFB   28H          ; 8
37 0ACB 29          DEFB   29H          ; 9
38 0ACC 4F          DEFB   4FH          ; :
39 0ACD 2C          DEFB   2CH          ; ;
40 0ACE 51          DEFB   51H          ; <
41 0ACF 2B          DEFB   2BH          ; =
42 0AD0 57          DEFB   57H          ; >
43 0AD1 4F          DEFB   4FH          ; ?
44 0AD2              ; 40 - 4F ;
45 0AD2 55          DEFB   55H          ; @
46 0AD3 01          DEFB   01H          ; A
47 0AD4 02          DEFB   02H          ; B
48 0AD5 03          DEFB   03H          ; C
49 0AD6 04          DEFB   04H          ; D
50 0AD7 05          DEFB   05H          ; E
51 0ADB 06          DEFB   06H          ; F
52 0AD9 07          DEFB   07H          ; G
53 0ADA 08          DEFB   08H          ; H
54 0ADB 09          DEFB   09H          ; I
55 0ADC 0A          DEFB   0AH          ; J
56 0ADD 0B          DEFB   0BH          ; K
57 0ADE 0C          DEFB   0CH          ; L
58 0ADF 0D          DEFB   0DH          ; M
59 0AE0 0E          DEFB   0EH          ; U
60 0AE1 0F          DEFB   0FH          ; O

```

```

01 OAE2          ; 50 - 5F ;
02 OAE2 10      DEFB 10H      ; P
03 OAE3 11      DEFB 11H      ; Q
04 OAE4 12      DEFB 12H      ; R
05 OAE5 13      DEFB 13H      ; S
06 OAE6 14      DEFB 14H      ; T
07 OAE7 15      DEFB 15H      ; U
08 OAE8 16      DEFB 16H      ; V
09 OAE9 17      DEFB 17H      ; W
10 OAEA 18      DEFB 18H      ; X
11 OAEB 19      DEFB 19H      ; Y
12 OAEC 1A      DEFB 1AH      ; Z
13 OAED 52      DEFB 52H      ; [
14 OAEE 59      DEFB 59H      ; \
15 OAEF 54      DEFB 54H      ; ]
16 OAFO 50      DEFB 50H      ; ^
17 OAF1 45      DEFB 45H      ; _
18 OAF2          ; 60 - 6F ;
19 OAF2 C7      DEFB C7H      ; UFD
20 OAF3 C8      DEFB C8H
21 OAF4 C9      DEFB C9H
22 OAF5 CA      DEFB CAH
23 OAF6 CB      DEFB CBH
24 OAF7 CC      DEFB CCH
25 OAF8 CD      DEFB CDH
26 OAF9 CE      DEFB CEH
27 Oafa CF      DEFB CFH
28 OAFB DF      DEFB DFH
29 OAFc E7      DEFB E7H
30 OAFD E8      DEFB E8H
31 OAFE E5      DEFB E5H
32 OAFF E9      DEFB E9H
33 OB00 EC      DEFB ECH
34 OB01 ED      DEFB EDH
35 OB02          ; 70 - 7F ;
36 OB02 D0      DEFB D0H
37 OB03 D1      DEFB D1H
38 OB04 D2      DEFB D2H
39 OB05 D3      DEFB D3H
40 OB06 D4      DEFB D4H
41 OB07 D5      DEFB D5H
42 OB08 D6      DEFB D6H
43 OB09 D7      DEFB D7H
44 OB0A D8      DEFB D8H
45 OB0B D9      DEFB D9H
46 OB0C DA      DEFB DAH
47 OB0D DB      DEFB DBH
48 OB0E DC      DEFB DCH
49 OB0F DD      DEFB DDH
50 OB10 DE      DEFB DEH
51 OB11 CO      DEFB COH
52 OB12          ; 80 - 8F ;
53 OB12 80      DEFB 80H      ; }
54 OB13 8D      DEFB 8DH      ;
55 OB14 9D      DEFB 9DH      ;
56 OB15 B1      DEFB B1H      ;
57 OB16 B5      DEFB B5H      ;
58 OB17 B9      DEFB B9H      ;
59 OB18 B4      DEFB B4H      ;
60 OB19 9E      DEFB 9EH      ;
    
```

```

01 OB1A B2      DEFB B2H      ;
02 OB1B B6      DEFB B6H      ;
03 OB1C BA      DEFB BAH      ;
04 OB1D BE      DEFB BEH      ;
05 OB1E 9F      DEFB 9FH      ;
06 OB1F B3      DEFB B3H      ;
07 OB20 B7      DEFB B7H      ;
08 OB21 BB      DEFB BBH      ;
09 OB22          ; 90 - 9F ;
10 OB22 BF      DEFB BFH      ; -
11 OB23 A3      DEFB A3H      ;
12 OB24 85      DEFB 85H      ;
13 OB25 A4      DEFB A4H      ;
14 OB26 A5      DEFB A5H      ;
15 OB27 A6      DEFB A6H      ;
16 OB28 94      DEFB 94H      ;
17 OB29 87      DEFB 87H      ;
18 OB2A 88      DEFB 88H      ;
19 OB2B 9C      DEFB 9CH      ;
20 OB2C 82      DEFB 82H      ;
21 OB2D 98      DEFB 98H      ;
22 OB2E 84      DEFB 84H      ;
23 OB2F 92      DEFB 92H      ;
24 OB30 90      DEFB 90H      ;
25 OB31 83      DEFB 83H      ;
26 OB32          ; A0 - AF ;
27 OB32 91      DEFB 91H      ;
28 OB33 81      DEFB 81H      ;
29 OB34 9A      DEFB 9AH      ;
30 OB35 97      DEFB 97H      ;
31 OB36 93      DEFB 93H      ;
32 OB37 95      DEFB 95H      ;
33 OB38 89      DEFB 89H      ;
34 OB39 A1      DEFB A1H      ;
35 OB3A AF      DEFB AFH      ;
36 OB3B 8B      DEFB 8BH      ;
37 OB3C 86      DEFB 86H      ;
38 OB3D 96      DEFB 96H      ;
39 OB3E A2      DEFB A2H      ;
40 OB3F AB      DEFB ABH      ;
41 OB40 AA      DEFB AAH      ;
42 OB41 8A      DEFB 8AH      ;
43 OB42          ; B0 - BF ;
44 OB42 8E      DEFB 8EH      ;
45 OB43 B0      DEFB B0H      ;
46 OB44 AD      DEFB ADH      ;
47 OB45 8D      DEFB 8DH      ;
48 OB46 A7      DEFB A7H      ;
49 OB47 AB      DEFB ABH      ;
50 OB48 A9      DEFB A9H      ;
51 OB49 8F      DEFB 8FH      ;
52 OB4A 8C      DEFB 8CH      ;
53 OB4B AE      DEFB AEH      ;
54 OB4C AC      DEFB ACH      ;
55 OB4D 9B      DEFB 9BH      ;
56 OB4E A0      DEFB A0H      ;
57 OB4F 99      DEFB 99H      ;
58 OB50 BC      DEFB BCH      ;
59 OB51 BB      DEFB BBH      ;
60 OB52          ; C0 - CF ;
    
```

```

01 0B52 40          DEFB 40H      ; I
02 0B53 3B          DEFB 3BH
03 0B54 3A          DEFB 3AH
04 0B55 70          DEFB 70H
05 0B56 3C          DEFB 3CH
06 0B57 71          DEFB 71H
07 0B58 5A          DEFB 5AH
08 0B59 3D          DEFB 3DH
09 0B5A 43          DEFB 43H
10 0B5B 56          DEFB 56H
11 0B5C 3F          DEFB 3FH
12 0B5D 1E          DEFB 1EH
13 0B5E 4A          DEFB 4AH
14 0B5F 1C          DEFB 1CH
15 0B60 5D          DEFB 5DH
16 0B61 3E          DEFB 3EH
17 0B62             ; DO - DF ;
18 0B62 5C          DEFB 5CH
19 0B63 1F          DEFB 1FH
20 0B64 5F          DEFB 5FH
21 0B65 5E          DEFB 5EH
22 0B66 37          DEFB 37H
23 0B67 7B          DEFB 7BH
24 0B68 7F          DEFB 7FH
25 0B69 36          DEFB 36H
26 0B6A 7A          DEFB 7AH
27 0B6B 7E          DEFB 7EH
28 0B6C 33          DEFB 33H
29 0B6D 4B          DEFB 4BH
30 0B6E 4C          DEFB 4CH
31 0B6F 1D          DEFB 1DH
32 0B70 6C          DEFB 6CH
33 0B71 5B          DEFB 5BH
34 0B72             ; EO - EF ;
35 0B72 7B          DEFB 7BH
36 0B73 41          DEFB 41H
37 0B74 35          DEFB 35H
38 0B75 34          DEFB 34H
39 0B76 74          DEFB 74H
40 0B77 30          DEFB 30H
41 0B78 3B          DEFB 3BH
42 0B79 75          DEFB 75H
43 0B7A 39          DEFB 39H
44 0B7B 4D          DEFB 4DH
45 0B7C 6F          DEFB 6FH
46 0B7D 6E          DEFB 6EH
47 0B7E 32          DEFB 32H
48 0B7F 77          DEFB 77H
49 0B80 76          DEFB 76H
50 0B81 72          DEFB 72H
51 0B82             ; FO - FF ;
52 0B82 73          DEFB 73H
53 0B83 47          DEFB 47H
54 0B84 7C          DEFB 7CH
55 0B85 53          DEFB 53H
56 0B86 31          DEFB 31H
57 0B87 4E          DEFB 4EH
58 0B88 6D          DEFB 6DH
59 0B89 4B          DEFB 4BH
60 0B8A 46          DEFB 46H

```

```

01 0BBB 7D          DEFB 7DH
02 0BBC 44          DEFB 44H
03 0BBD 1B          DEFB 1BH
04 0BBE 58          DEFB 58H
05 0BBF 79          DEFB 79H
06 0B90 42          DEFB 42H
07 0B91 60          DEFB 60H
08 0B92             ;
09 0B92             ;
10 0B92             ; FLASHING DATA SAVE
11 0B92             ;
12 0B92             ; ?SAVE: ENT
13 0B92 219211     LD HL,FLSDT
14 0B95 36EF       LD (HL),EFH ; NOMAL CURSOR
15 0B97 3A7011     LD A,(KANAF)
16 0B9A 0F         RRCA
17 0B9B 3B03       JR C,SVO-2 ; GRAPH MODE
18 0B9D 0F         RRCA
19 0B9E 3002       JR NC,SVO ; NORMAL MODE
20 0BA0 36FF       LD (HL),FFH ; GRAPH CURSOR
SVO: ENT
LD A,(HL)
PUSH AF
CALL ?PONT ; FLASING POSITION
LD A,(HL)
LD (FLASH),A
POP AF
LD (HL),A
XOR A
LD HL,KEYPA
LD (HL),A
CPL
LD (HL),A
RET
SV1: ENT
LD (HL),43H ; KANA CURSOR
JR SVO
;
; ORG 0BB9H;?ADCN
;
;
; ASCII TO DISPLAY CODE CONVERTE
;
; IN ACC:ASCII
; EXIT ACC:DISPLAY CODE
;
?ADCN: ENT
PUSH BC
PUSH HL
LD HL,ATBL
LD C,A
LD B,0
ADD HL,BC
LD A,(HL)
JR DACN3
;
VRNG: DEFM "V1.0A" ; VERSION MANAGEMENT
DEFB 0DH
DEFS +3

```



```

01 OBCE ;
02 OBCE ;
03 OBCE ;ORG OBCEH;?DACN
04 OBCE ;
05 OBCE ; DISPLAY CODE TO ASCII CONV. ;
06 OBCE ;
07 OBCE ; IN ACC = DISPLAY CODE
08 OBCE ; EXIT ACC = ASCII
09 OBCE ;
10 OBCE ?DACN: ENT
11 OBCE C5 PUSH BC
12 OBCE E5 PUSH HL
13 OBCE D5 PUSH DE
14 OBCE 21920A LD HL,ATBL
15 OBCE 54 LD D,H
16 OBCE 5D LD E,L
17 OBCE 010001 LD BC,0100H
18 OBCE EDB1 CPIR
19 OBCE 2806 JR Z,DACN1
20 OBCE 3EF0 LD A,FOH
21 OBCE DACN2: ENT
22 OBCE D1 POP DE
23 OBCE DACN3: ENT
24 OBCE E1 POP HL
25 OBCE C1 POP BC
26 OBCE C9 RET
27 OBCE3 ;
28 OBCE3 DACN1: ENT
29 OBCE B7 OR A
30 OBCE 2B DEC HL
31 OBCE ED52 SBC HL,DE
32 OBCE 7D LD A,L
33 OBCE 18F5 JR DACN2
34 OBCEA ;
35 OBCEA ;
36 OBCEA ;
37 OBCEA ; KEY MATRIX TO DISPLAY CODE TABL
38 OBCEA ;
39 OBCEA ;
40 OBCEA ;S0 00 - 07 ;
41 OBCE BF DEFB BFH ; SPARE
42 OBCE CA DEFB CAH ; GRAPH
43 OBCE 58 DEFB 58H ; ↓
44 OBCE C9 DEFB C9H ; ALPHA
45 OBCE F0 DEFB FOH ; NO
46 OBCE 2C DEFB 2CH ; ;
47 OBCE 4F DEFB 4FH ; ;
48 OBCE CD DEFB CDH ; CR
49 OBCE2 ;S1 08 - 0F ;
50 OBCE 19 DEFB 19H ; Y
51 OBCE 1A DEFB 1AH ; Z
52 OBCE 55 DEFB 55H ; @
53 OBCE 52 DEFB 52H ; [
54 OBCE 54 DEFB 54H ; ]
55 OBCE F0 DEFB FOH ; NULL
56 OBCE F0 DEFB FOH ; NULL
57 OBCE F0 DEFB FOH ; NULL
58 OBCEA ;S2 0 - 17 ;
59 OBCE 11 DEFB 11H ; Q
60 OBCE 12 DEFB 12H ; R
    
```

```

01 OBCE 13 DEFB 13H ; S
02 OBCE 14 DEFB 14H ; T
03 OBCE 15 DEFB 15H ; U
04 OBCE 16 DEFB 16H ; V
05 OBCE 17 DEFB 17H ; W
06 OBCE 18 DEFB 18H ; X
07 OBCE2 ;S3 18 - 1F ;
08 OBCE 09 DEFB 09H ; I
09 OBCE 0A DEFB 0AH ; J
10 OBCE 0B DEFB 0BH ; K
11 OBCE 0C DEFB 0CH ; L
12 OBCE 0D DEFB 0DH ; M
13 OBCE 0E DEFB 0EH ; N
14 OBCE 0F DEFB 0FH ; O
15 OBCE 10 DEFB 10H ; P
16 OBCEA ;S4 20 - 27 ;
17 OBCE 01 DEFB 01H ; A
18 OBCE 02 DEFB 02H ; B
19 OBCE 03 DEFB 03H ; C
20 OBCE 04 DEFB 04H ; D
21 OBCE 05 DEFB 05H ; E
22 OBCE 06 DEFB 06H ; F
23 OBCE 07 DEFB 07H ; G
24 OBCE 08 DEFB 08H ; H
25 OBCE2 ;S5 28 - 2F ;
26 OBCE 21 DEFB 21H ; 1
27 OBCE 22 DEFB 22H ; 2
28 OBCE 23 DEFB 23H ; 3
29 OBCE 24 DEFB 24H ; 4
30 OBCE 25 DEFB 25H ; 5
31 OBCE 26 DEFB 26H ; 6
32 OBCE 27 DEFB 27H ; 7
33 OBCE 28 DEFB 28H ; 8
34 OBCEA ;S6 30 - 37 ;
35 OBCE 59 DEFB 59H ; \
36 OBCE 50 DEFB 50H ; ↑
37 OBCE 2A DEFB 2AH ; -
38 OBCE 00 DEFB 00H ; SPACE
39 OBCE 20 DEFB 20H ; 0
40 OBCE 29 DEFB 29H ; 9
41 OBCE 2F DEFB 2FH ; .
42 OBCE 2E DEFB 2EH ; ,
43 OBCE2 ;S7 38 - 3F ;
44 OBCE C8 DEFB C8H ; INST.
45 OBCE C7 DEFB C7H ; DEL.
46 OBCE C2 DEFB C2H ; CURSOR UP
47 OBCE C1 DEFB C1H ; CURSOR DOWN
48 OBCE C3 DEFB C3H ; CURSOR RIGHT
49 OBCE C4 DEFB C4H ; CURSOR LEFT
50 OBCE 49 DEFB 49H ; ?
51 OBCE 2D DEFB 2DH ; /
52 OBCE2A ;
53 OBCE2A ; KTBL SHIFT ON
54 OBCE2A ;
55 OBCE2A ;
56 OBCE2A ;
57 OBCE BF DEFB BFH ; SPARE
58 OBCE CA DEFB CAH ; GRAPH
59 OBCE 1B DEFB 1BH ; POND
60 OBCE C9 DEFB C9H ; ALPHA
    
```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 47          04.07.83
01 0C2E FO          DEFB  FOH          ; NO
02 0C2F 6A          DEFB  6AH          ; +
03 0C30 6B          DEFB  6BH          ; *
04 0C31 CD          DEFB  CDH          ; CR
05 0C32             ;S1  0B-0F
06 0C32 99          DEFB  99H          ; y
07 0C33 9A          DEFB  9AH          ; z
08 0C34 A4          DEFB  A4H          ; ^
09 0C35 BC          DEFB  BCH          ; (
10 0C36 40          DEFB  40H          ; }
11 0C37 F0          DEFB  F0H          ; NULL
12 0C38 F0          DEFB  F0H          ; NULL
13 0C39 F0          DEFB  F0H          ; NULL
14 0C3A             ;S2  10-17
15 0C3A 91          DEFB  91H          ; q
16 0C3B 92          DEFB  92H          ; r
17 0C3C 93          DEFB  93H          ; s
18 0C3D 94          DEFB  94H          ; t
19 0C3E 95          DEFB  95H          ; u
20 0C3F 96          DEFB  96H          ; v
21 0C40 97          DEFB  97H          ; w
22 0C41 98          DEFB  98H          ; x
23 0C42             ;S3  18-1F
24 0C42 89          DEFB  89H          ; i
25 0C43 8A          DEFB  8AH          ; j
26 0C44 8B          DEFB  8BH          ; k
27 0C45 8C          DEFB  8CH          ; l
28 0C46 8D          DEFB  8DH          ; m
29 0C47 8E          DEFB  8EH          ; n
30 0C48 8F          DEFB  8FH          ; o
31 0C49 90          DEFB  90H          ; p
32 0C4A             ;S4  20-27
33 0C4A 81          DEFB  81H          ; a
34 0C4B 82          DEFB  82H          ; b
35 0C4C 83          DEFB  83H          ; c
36 0C4D 84          DEFB  84H          ; d
37 0C4E 85          DEFB  85H          ; e
38 0C4F 86          DEFB  86H          ; f
39 0C50 87          DEFB  87H          ; g
40 0C51 88          DEFB  88H          ; h
41 0C52             ;S5  28-2F
42 0C52 61          DEFB  61H          ; !
43 0C53 62          DEFB  62H          ; "
44 0C54 63          DEFB  63H          ; #
45 0C55 64          DEFB  64H          ; $
46 0C56 65          DEFB  65H          ; %
47 0C57 66          DEFB  66H          ; &
48 0C58 67          DEFB  67H          ; '
49 0C59 68          DEFB  68H          ; (
50 0C5A             ;S6  30-37
51 0C5A 80          DEFB  80H          ; \
52 0C5B A5          DEFB  A5H          ; POND MARK
53 0C5C 2B          DEFB  2BH          ; YEN
54 0C5D 00          DEFB  00H          ; SPACE
55 0C5E 60          DEFB  60H          ; π
56 0C5F 69          DEFB  69H          ; )
57 0C60 51          DEFB  51H          ; <
58 0C61 57          DEFB  57H          ; >
59 0C62             ;S7  38-3F
60 0C62 C6          DEFB  C6H          ; CLR

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 48          04.07.83
01 0C63 C5          DEFB  C5H          ; HOME
02 0C64 C2          DEFB  C2H          ; CURSOR UP
03 0C65 C1          DEFB  C1H          ; CURSOR DOWN
04 0C66 C3          DEFB  C3H          ; CURSOR RIGHT
05 0C67 C4          DEFB  C4H          ; CURSOR LEFT
06 0C68 5A          DEFB  5AH          ; +
07 0C69 45          DEFB  45H          ; +
08 0C6A             ;
09 0C6A             ; GRAPHIC
10 0C6A             ;
11 0C6A             ;
12 0C6A             ;
13 0C6A BF          DEFB  BFH          ; SPARE
14 0C6B F0          DEFB  F0H          ; GRAPH BUT NULL
15 0C6C E5          DEFB  E5H          ; #↓
16 0C6D C9          DEFB  C9H          ; ALPHA
17 0C6E F0          DEFB  F0H          ; NO
18 0C6F 42          DEFB  42H          ; #;
19 0C70 B6          DEFB  B6H          ; #:
20 0C71 CD          DEFB  CDH          ; CR
21 0C72             ;S1  0B-0F
22 0C72 75          DEFB  75H          ; #Y
23 0C73 76          DEFB  76H          ; #Z
24 0C74 B2          DEFB  B2H          ; #0
25 0C75 D8          DEFB  D8H          ; #C
26 0C76 4E          DEFB  4EH          ; #J
27 0C77 F0          DEFB  F0H          ; #NULL-
28 0C78 F0          DEFB  F0H          ; #NULL
29 0C79 F0          DEFB  F0H          ; #NULL
30 0C7A             ;S2  10-17
31 0C7A 3C          DEFB  3CH          ; #Q
32 0C7B 30          DEFB  30H          ; #R
33 0C7C 44          DEFB  44H          ; #S
34 0C7D 71          DEFB  71H          ; #T
35 0C7E 79          DEFB  79H          ; #U
36 0C7F DA          DEFB  DAH          ; #V
37 0C80 38          DEFB  38H          ; #W
38 0C81 6D          DEFB  6DH          ; #X
39 0C82             ;S3  18-1F
40 0C82 7D          DEFB  7DH          ; #I
41 0C83 5C          DEFB  5CH          ; #J
42 0C84 5B          DEFB  5BH          ; #K
43 0C85 B4          DEFB  B4H          ; #L
44 0C86 1C          DEFB  1CH          ; #M
45 0C87 32          DEFB  32H          ; #N
46 0C88 B0          DEFB  B0H          ; #O
47 0C89 D6          DEFB  D6H          ; #P
48 0C8A             ;S4  20-27
49 0C8A 53          DEFB  53H          ; #A
50 0C8B 6F          DEFB  6FH          ; #B
51 0C8C DE          DEFB  DEH          ; #C
52 0C8D 47          DEFB  47H          ; #D
53 0C8E 34          DEFB  34H          ; #E
54 0C8F 4A          DEFB  4AH          ; #F
55 0C90 4B          DEFB  4BH          ; #G
56 0C91 72          DEFB  72H          ; #H
57 0C92             ;S5  28-2F
58 0C92 37          DEFB  37H          ; #1
59 0C93 3E          DEFB  3EH          ; #2
60 0C94 7F          DEFB  7FH          ; #3

```

```

01 0C95 7B      DEF 7BH      ; #4
02 0C96 3A      DEF 3AH      ; #5
03 0C97 5E      DEF 5EH      ; #6
04 0C98 1F      DEF 1FH      ; #7
05 0C99 BD      DEF BDH      ; #8
06 0C9A          ;S6 30-3F
07 0C9A D4      DEF D4H      ; #YEN
08 0C9B 9E      DEF 9EH      ; #+
09 0C9C D2      DEF D2H      ; #-
10 0C9D 00      DEF 00H      ; SPACE
11 0C9E 9C      DEF 9CH      ; #0
12 0C9F A1      DEF A1H      ; #9
13 0CA0 CA      DEF CAH      ; #,
14 0CA1 B8      DEF B8H      ; #.
15 0CA2          ;S7 38-3F
16 0CA2 C8      DEF C8H      ; INST
17 0CA3 C7      DEF C7H      ; DEL.
18 0CA4 C2      DEF C2H      ; CURSOR UP
19 0CA5 C1      DEF C1H      ; CURSOR DOWN
20 0CA6 C3      DEF C3H      ; CURSOR RIGHT
21 0CA7 C4      DEF C4H      ; CURSOR LEFT
22 0CA8 BA      DEF BAH      ; #?
23 0CA9 DB      DEF DBH      ; #/
24 0CAA          ;
25 0CAA          ; CONTROL CODE
26 0CAA          ;
27 0CAA          ; KTBLC: ENT
28 0CAA          ;S0 00-07N
29 0CAA F0      DEF FOH      ;
30 0CAB F0      DEF FOH      ;
31 0CAC F0      DEF FOH      ; ↑
32 0CAD F0      DEF FOH      ;
33 0CAE F0      DEF FOH      ;
34 0CAF F0      DEF FOH      ;
35 0CB0 F0      DEF FOH      ;
36 0CB1 F0      DEF FOH      ;
37 0CB2          ;S1 08-0F
38 0CB2 F0      DEF FOH      ; ↑Y E3
39 0CB3 5A      DEF 5AH      ; ↑Z E4 (CHECKER)
40 0CB4 F0      DEF FOH      ; ↑Q
41 0CB5 F0      DEF FOH      ; ↑C E5
42 0CB6 F0      DEF FOH      ; ↑J E7
43 0CB7 F0      DEF FOH      ;
44 0CB8 F0      DEF FOH      ;
45 0CB9 F0      DEF FOH      ;
46 0CBA          ;S2 10-17
47 0CBA C1      DEF C1H      ; ↑Q
48 0CBB C2      DEF C2H      ; ↑R
49 0CBC C3      DEF C3H      ; ↑S
50 0CBD C4      DEF C4H      ; ↑T
51 0CBE C5      DEF C5H      ; ↑U
52 0CBF C6      DEF C6H      ; ↑V
53 0CC0 F0      DEF FOH      ; ↑W E1
54 0CC1 F0      DEF FOH      ; ↑X E2
55 0CC2          ;S3 18-1F
56 0CC2 F0      DEF FOH      ; ↑I F9
57 0CC3 F0      DEF FOH      ; ↑J FA
58 0CC4 F0      DEF FOH      ; ↑K FB
59 0CC5 F0      DEF FOH      ; ↑L FC
60 0CC6 F0      DEF FOH      ; ↑M FD

```

```

01 0CC7 F0      DEF FOH      ; ↑N FE
02 0CC8 F0      DEF FOH      ; ↑O FF
03 0CC9 F0      DEF FOH      ; ↑P EO
04 0CCA          ;S4 20-27
05 0CCA F0      DEF FOH      ; ↑A F1
06 0CCB F0      DEF FOH      ; ↑B F2
07 0CCC F0      DEF FOH      ; ↑C F3
08 0CCD F0      DEF FOH      ; ↑D F4
09 0CCE F0      DEF FOH      ; ↑E F5
10 0CCF F0      DEF FOH      ; ↑F F6
11 0CD0 F0      DEF FOH      ; ↑G F7
12 0CD1 F0      DEF FOH      ; ↑H F8
13 0CD2          ;S5 28-2F
14 0CD2 F0      DEF FOH      ;
15 0CD3 F0      DEF FOH      ;
16 0CD4 F0      DEF FOH      ;
17 0CD5 F0      DEF FOH      ;
18 0CD6 F0      DEF FOH      ;
19 0CD7 F0      DEF FOH      ;
20 0CD8 F0      DEF FOH      ;
21 0CD9 F0      DEF FOH      ;
22 0CDA          ;S6 30-37
23 0CDA F0      DEF FOH      ; ↑YEN E6
24 0CDB F0      DEF FOH      ;
25 0CDC F0      DEF FOH      ;
26 0CDD F0      DEF FOH      ;
27 0CDE F0      DEF FOH      ;
28 0CDF F0      DEF FOH      ; ↑, EF
29 0CEE F0      DEF FOH      ;
30 0CE1          ;S7 38-3F
31 0CE1 F0      DEF FOH      ;
32 0CE2 F0      DEF FOH      ;
33 0CE3 F0      DEF FOH      ;
34 0CE4 F0      DEF FOH      ;
35 0CE5 F0      DEF FOH      ;
36 0CE6 F0      DEF FOH      ;
37 0CE7 F0      DEF FOH      ;
38 0CE8 F0      DEF FOH      ; ↑/ EE
39 0CE9          ;
40 0CE9          ; KANA
41 0CE9          ;
42 0CE9          ; KTBLC: ENT
43 0CE9          ;S0 00-07
44 0CE9 BF      DEF BFH      ; SPARE
45 0CEA F0      DEF FOH      ; GRAPH BUT NULL
46 0CEB CF      DEF CFH      ; NIKO WH.
47 0CEC C9      DEF C9H      ; ALPHA
48 0CED F0      DEF FOH      ; NO
49 0CEE B5      DEF B5H      ; MD
50 0CEF 4D      DEF 4DH      ; DAKU TEN
51 0CF0 CD      DEF CDH      ; CR
52 0CF1          ;S1 08-0F
53 0CF1 35      DEF 35H      ; HA
54 0CF2 77      DEF 77H      ; TA
55 0CF3 D7      DEF D7H      ; WA
56 0CF4 B3      DEF B3H      ; YO
57 0CF5 B7      DEF B7H      ; HANDAKU
58 0CF6 F0      DEF FOH      ;
59 0CF7 F0      DEF FOH      ;
60 0CF8 F0      DEF FOH      ;

```

```

01 0CF9          ;S2      10-17
02 0CF9 7C      DEFB 7CH      ; KA
03 0CFA 70      DEFB 70H      ; KE
04 0CFB 41      DEFB 41H      ; SHI
05 0CFC 31      DEFB 31H      ; KO
06 0CFD 39      DEFB 39H      ; HI
07 0CFE A6      DEFB A6H      ; TE
08 0CFF 78      DEFB 78H      ; KI
09 0D00 DD      DEFB DDH      ; CHI
10 0D01          ;S3      18-1F
11 0D01 3D      DEFB 3DH      ; FU
12 0D02 5D      DEFB 5DH      ; MI
13 0D03 6C      DEFB 6CH      ; MU
14 0D04 56      DEFB 56H      ; ME
15 0D05 1D      DEFB 1DH      ; RHI
16 0D06 33      DEFB 33H      ; RA
17 0D07 D5      DEFB D5H      ; HE
18 0D08 B1      DEFB B1H      ; HO
19 0D09          ;S4      20-27
20 0D09 46      DEFB 46H      ; SA
21 0D0A 6E      DEFB 6EH      ; TO
22 0D0B D9      DEFB D9H      ; THU
23 0D0C 48      DEFB 48H      ; SU
24 0D0D 74      DEFB 74H      ; KU
25 0D0E 43      DEFB 43H      ; SE
26 0D0F 4C      DEFB 4CH      ; SO
27 0D10 73      DEFB 73H      ; MA
28 0D11          ;S5      28-2F
29 0D11 3F      DEFB 3FH      ; A
30 0D12 36      DEFB 36H      ; I
31 0D13 7E      DEFB 7EH      ; U
32 0D14 3B      DEFB 3BH      ; E
33 0D15 7A      DEFB 7AH      ; O
34 0D16 1E      DEFB 1EH      ; NA
35 0D17 5F      DEFB 5FH      ; NI
36 0D18 A2      DEFB A2H      ; NU
37 0D19          ;S6      30-37
38 0D19 D3      DEFB D3H      ; YO
39 0D1A 9F      DEFB 9FH      ; YU
40 0D1B D1      DEFB D1H      ; YA
41 0D1C 00      DEFB 00H      ; SPACE
42 0D1D 9D      DEFB 9DH      ; NO
43 0D1E A3      DEFB A3H      ; NE
44 0D1F D0      DEFB D0H      ; RU
45 0D20 B9      DEFB B9H      ; RE
46 0D21          ;S7      38-3F
47 0D21 C6      DEFB C6H      ; ?CLR @
48 0D22 C5      DEFB C5H      ; ?HOME @
49 0D23 C2      DEFB C2H      ; ?CURSOR UP
50 0D24 C1      DEFB C1H      ; ?CURSOR DOWN
51 0D25 C3      DEFB C3H      ; ?CURSOR RIGHT
52 0D26 C4      DEFB C4H      ; ?CURSOR LEFT
53 0D27 BB      DEFB BBH      ; DASH
54 0D28 BE      DEFB BEH      ; RO
55 0D29          ;
56 0D29          ; MEMORY DUMP
57 0D29          ; COMMAND 'D'
58 0D29          ;
59 0D29          ;
60 0D29 CD3D01  DUMP:  ENT      ;
                    CALL    HEXIY ; START ADR.

```

```

01 0D2C CDA602  CALL  .4DE
02 0D2F E5      PUSH  HL
03 0D30 CD1004  CALL  HLHEX      ; END ADR.
04 0D33 D1      POP   DE
05 0D34 3B52    JR    C,DUM1     ; DATA ER. THEN
06 0D36 EB      EX    DE,HL
07 0D37 0608    LD    B,08H     ; DISP BBYTES
08 0D39 0E17    LD    C,23     ; CHA. PRINT BIAS
09 0D3B CDF A05  CALL  NLPHL     ; NEWLINE PRINT
10 0D3E CDB103  CALL  SPHEX     ; SP. PRT.+ACC PRT.
11 0D41 23      INC   HL
12 0D42 F5      PUSH  AF
13 0D43 3A7111  LD    A,(DSPXY) ; DISPLAY POINT
14 0D46 B1      ADD   A,C
15 0D47 327111  LD    (DSPXY),A ; X AXIS.=X+Creg
16 0D4A F1      POP   AF
17 0D4B FE20    CP    20H
18 0D4D 3002    JR    NC,+4
19 0D4F 3E2E    LD    A,2EH     ;
20 0D51 CDB90B  CALL  ?ADCN     ; ASCII TO DISPLAY CODE
21 0D54 CD6C09  CALL  PRNT3
22 0D57 3A7111  LD    A,(DSPXY)
23 0D5A 0C      INC   C
24 0D5B 91      SUB   C         ; ASCII DSP POSITION
25 0D5C 327111  LD    (DSPXY),A
26 0D5F 0D      DEC   C
27 0D60 0D      DEC   C
28 0D61 0D      DEC   C
29 0D62 E5      PUSH  HL
30 0D63 ED52    SBC  HL,DE
31 0D65 E1      POP   HL
32 0D66 2B1D    JR    Z,DUM1-3
33 0D68 3EFB    LD    A,FBH
34 0D6A 3200E0  LD    (KEYPA),A
35 0D6D 00      NOP
36 0D6E 3A01E0  LD    A,(KEYPB)
37 0D71 FEFE    CP    FEH     ; SHIFT KEY ?
38 0D73 2003    JR    NZ,+5
39 0D75 CDA60D  CALL  ?BLNK     ; 64MSEC DELAY
40 0D78 10C4    DJNZ  DUM2
41 0D7A CDCA0B  CALL  ?KEY      ; STOP DISP
42 0D7D B7      OR    A
43 0D7E 2BFA    JR    Z,-4     ; SPACE KEY THEN STOP
44 0D80 CD320A  CALL  ?BRK     ; BREAK IN ?
45 0D83 20B2    JR    NZ,DUM3
46 0D85 C3AD00  JP    ST1     ; COMMAND IN !
47 0D88 21A000  DUM1: LD    HL,160 ; 20*8 BYTE
48 0D8B 19      ADD   HL,DE
49 0D8C 18AB    JR    DUM3-1
50 0DBE          ;
51 0DBE          ;
52 0DBE          ;
53 0DBE          ;
54 0DBE          ; DEFS +24
55 0DA6          ;
56 0DA6          ;
57 0DA6          ;
58 0DA6          ; ORG 0DA6H; ?BLNK
59 0DA6          ;
60 0DA6          ;

```

```

01 ODA6 ; V-BLANK CHECK ;
02 ODA6 ;
03 ODA6 ?BLNK: ENT
04 ODA6 F5 PUSH AF
05 ODA7 3A02E0 LD A,(KEYPC) ; V-BLNK
06 ODA8 07 RLCA
07 ODA8 30FA JR NC,-4
08 ODA9 3A02E0 LD A,(KEYPC)
09 ODB0 07 RLCA
10 ODB1 38FA JR C,-4
11 ODB3 F1 POP AF
12 ODB4 C9 RET
13 ODB5 ;
14 ODB5 ;ORG ODB5H;?DSP
15 ODB5 ;
16 ODB5 ;
17 ODB5 ;
18 ODB5 ; DISPLAY ON POINTER ;
19 ODB5 ;
20 ODB5 ; ACC = DISPLAY CODE
21 ODB5 ; EXCEPT FOH
22 ODB5 ;
23 ODB5 ?DSP: ENT
24 ODB5 F5 PUSH AF
25 ODB6 C5 PUSH BC
26 ODB7 D5 PUSH DE
27 ODB8 E5 PUSH HL
28 ODB9 DSP01: ENT
29 ODB9 CDB10F CALL ?PONT
30 ODBC 77 LD (HL),A
31 ODBD 2A7111 LD HL,(DSPXY)
32 ODC0 7D LD A,L
33 ODC1 FE27 CP +39
34 ODC3 200B JR NZ,DSP04
35 ODC5 CDF302 CALL .MANG
36 ODC8 3806 JR C,DSP04
37 ODCA EB EX DE,HL
38 ODCB 3601 LD (HL),+1 ; LOGICAL 1ST COLUMN
39 ODCC 23 INC HL
40 ODCE 3600 LD (HL),0 ; LOGICAL 2ND COLUMN
41 ODD0 DSP04: ENT
42 ODD0 3EC3 LD A,CSH ; CURSL
43 ODD2 180C JR ?DPCT+4
44 ODD4 ;
45 ODD4 ;
46 ODD4 ;
47 ODD4 ;
48 ODD4 ; GRAPHIC STATUS CHECK
49 ODD4 ;
50 ODD4 3A7011 GRSTAS: LD A,(KANAF)
51 ODD7 FE01 CP 01H
52 ODD9 3ECA LD A,CAH
53 ODDB C9 RET
54 ODDC ;
55 ODDC ;
56 ODDC ;
57 ODDC ;
58 ODDC ;
59 ODDC ;
60 ODDC ;ORG ODDCH;?DPCT

```

```

01 ODDC ;
02 ODDC ;
03 ODDC ; DISPLAY CONTROL ;
04 ODDC ;
05 ODDC ; ACC = CONTROL CODE
06 ODDC ;
07 ODDC ?DPCT: ENT
08 ODDC F5 PUSH AF
09 ODDD C5 PUSH BC
10 ODDE D5 PUSH DE
11 ODDF E5 PUSH HL
12 ODE0 47 LD B,A
13 ODE1 E6F0 AND FOH
14 ODE3 FEC0 CP COH
15 ODE5 201B JR NZ,CURS5
16 ODE7 A8 XOR B
17 ODE8 07 RLCA
18 ODE9 4F LD C,A
19 ODEA 0600 LD B,+0
20 ODEC 21AA0E LD HL,CTBL ; PAGE MODE1
21 ODEF 09 ADD HL,BC
22 ODF0 5E LD E,(HL)
23 ODF1 23 INC HL
24 ODF2 56 LD D,(HL)
25 ODF3 2A7111 LD HL,(DSPXY)
26 ODF6 EB EX DE,HL
27 ODF7 E9 JP (HL)
28 ODF8 ;
29 ODF8 ;
30 ODF8 ;
31 ODF8 CURSD: ENT
32 ODF8 EB EX DE,HL ; LD HL,(DSPXY)
33 ODF9 7C LD A,H
34 ODFA FE18 CP +24
35 ODFC 2825 JR Z,CURS4
36 ODFF 24 INC H
37 ODFE ;
38 ODFE ;
39 ODFE ;
40 ODFE ;
41 ODFE ;
42 ODFE ;
43 ODFE ;
44 ODFE ;
45 ODFE ;
46 ODFE ;
47 ODFE ;
48 ODFE ;
49 ODFE ;
50 ODFE ;
51 ODFE ;
52 ODFE ;
53 ODFE ;
54 ODFE ;
55 ODFE ;
56 ODFE ;
57 ODFE ;
58 ODFE ;
59 ODFE ;
60 ODFE ;

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 55      04.07.83

01 0E16 2E00          LD    L,+0
02 0E18 24           INC    H
03 0E19 7C           LD    A,H
04 0E1A FE19         CP    +25
05 0E1C 38E1         JR    C,CURS1
06 0E1E 2618         LD    H,+24
07 0E20 227111       LD    (DSPXY),HL
08 0E23              CURS4: ENT
09 0E23 1848         JR    SCROL
10 0E25              ;
11 0E25              CURSL: ENT
12 0E25 EB           EX    DE,HL          ; LD HL,(DSPXY)
13 0E26 7D           LD    A,L
14 0E27 B7           OR    A
15 0E28 2803         JR    Z,+5
16 0E2A 2D           DEC    L
17 0E2B 18D2         JR    CURS3
18 0E2D 2E27         LD    L,+39
19 0E2F 25           DEC    H
20 0E30 F20B0E       JP    P,CURSU1
21 0E33 2600         LD    H,0
22 0E35 227111       LD    (DSPXY),HL
23 0E38 18CB         JR    CURS5
24 0E3A              ;
25 0E3A              CLRS: ENT
26 0E3A 217311       LD    HL,MANG
27 0E3D 061B         LD    B,27
28 0E3F CDD80F       CALL ?CLER
29 0E42 2100D0       LD    HL,D000H      ; SCRN TOP
30 0E45 CDD409       CALL #CLR08
31 0E48 3E71         LD    A,71H         ; COLOR DATA
32 0E4A CDD509       CALL #CLR8          ; D800H-DFFFH CLR.
33 0E4D              HOME: ENT
34 0E4D 210000       LD    HL,0          ; DSPXY:0 X=0,Y=0
35 0E50 18AD         JR    CURS3
36 0E52              ;
37 0E52              DEFS  +8
38 0E5A              ;
39 0E5A              ; CR
40 0E5A              ;
41 0E5A              CR: ENT
42 0E5A CDF302       CALL .MANG
43 0E5D 0F           RRCA
44 0E5E 30B6         JR    NC,CURS2
45 0E60 2E00         LD    L,0
46 0E62 24           INC    H
47 0E63 FE18         CP    +24
48 0E65 2803         JR    Z,CR1
49 0E67 24           INC    H
50 0E68 1895         JR    CURS1
51 0E6A              CR1: ENT
52 0E6A 227111       LD    (DSPXY),HL
53 0E6D              ;
54 0E6D              ; SCROL
55 0E6D              ;
56 0E6D              SCROL: ENT
57 0E6D 01C003       LD    BC,03C0H
58 0E70 1100D0       LD    DE,SCRN      ; TOP OF #CRT ADR.
59 0E73 2128D0       LD    HL,SCRN+40   ; 1 COLUMN
60 0E76 C5           PUSH  BC           ; 1000 STORE

```

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 56      04.07.83

01 0E77 ED80          LDIR
02 0E79 C1           POP   BC
03 0E7A D5           PUSH  DE
04 0E7B 1100DB       LD    DE,SCRN+800H ; COLOR RAM SCROLL
05 0E7E 2128DB       LD    HL,SCRN+828H ; SCROLL TOP + 40
06 0E81 ED80          LDIR
07 0E83 0628         LD    B,40          ; ONE LINE
08 0E85 EB           EX    DE,HL
09 0E86 3E71         LD    A,71H        ; COLOR RAM INITIAL DATA
10 0E88 CDDDOF       CALL ?DINT
11 0E8B E1           POP   HL
12 0E8C 0628         LD    B,40
13 0E8E CDD80F       CALL ?CLER          ; LAST LINE CLEAR
14 0E91 011A00       LD    BC,26         ; ROW NUMBER +1
15 0E94 117311       LD    DE,MANG      ; LOGICAL MANAGEMENT
16 0E97 217411       LD    HL,MANG+1
17 0E9A ED80          LDIR
18 0E9C 3600         LD    (HL),0
19 0E9E 3A7311       LD    A,(MANG)
20 0EA1 B7           OR    A
21 0EA2 2841         JR    Z,?RSTR
22 0EA4 217211       LD    HL,DSPXY+1
23 0EA7 35           DEC   (HL)
24 0EAB 18C3         JR    SCROL
25 0EAA              ;
26 0EAA              ; CONTROL CODE TABLE
27 0EAA              ;
28 0EAA              ;
29 0EAA 6D0E         CTBL: ENT
30 0EAC F80D         DEFW  SCROL        ; SCROLLING
31 0EAE 050E         DEFW  CURSD        ; CURSOR
32 0EB0 0D0E         DEFW  CURSR
33 0EB2 250E         DEFW  CURSL
34 0EB4 4D0E         DEFW  HOME
35 0EB6 3A0E         DEFW  CLRS
36 0EB8 F80E         DEFW  DEL
37 0EBA 380F         DEFW  INST
38 0EBC E10E         DEFW  ALPHA
39 0EBE EE0E         DEFW  KANA
40 0EC0 E50E         DEFW  ?RSTR
41 0EC2 E50E         DEFW  ?RSTR
42 0EC4 5A0E         DEFW  CR
43 0EC6 E50E         DEFW  ?RSTR
44 0EC8 E50E         DEFW  ?RSTR
45 0ECA              ;
46 0ECA              ;
47 0ECA              ;
48 0ECA              ; INST BYPASS
49 0ECA              ;
50 0ECA CBDC         INST2: SET 3,H
51 0ECC 7E           LD    A,(HL)
52 0ECD 23           INC   HL
53 0ECE 77           LD    (HL),A
54 0ECF 2B           DEC   HL
55 0ED0 CB9C         RES 3,H
56 0ED2 EDAB         LDD  A,C
57 0ED4 79           LD    A,C
58 0ED5 B0           OR    B
59 0ED6 20F2         JR    NZ,INST2
60 0ED8 EB           EX    DE,HL

```

```

01 0ED9 3600 LD (HL),0
02 0EDB CBDC SET 3,H ; COLOR RAM
03 0EDD 3671 LD (HL),71H
04 0EDF 1804 JR ?RSTR
;
05 0EE1 ;
06 0EE1 ;
07 0EE1 ;
08 0EE1 ;
09 0EE1 ;ORG 0EE1H;ALPHA
10 0EE1 ;
11 0EE1 ALPHA: ENT
12 0EE1 AF XOR A
13 0EE2 ALPH1: ENT
14 0EE2 327011 LD (KANAF),A
;
15 0EE5 ;
16 0EE5 ;
17 0EE5 ; RESTORE ;
18 0EE5 ;
19 0EE5 ?RSTR: ENT
20 0EE5 E1 POP HL
21 0EE6 ?RSTR1: ENT
22 0EE6 D1 POP DE
23 0EE7 C1 POP BC
24 0EE8 F1 POP AF
25 0EE9 C9 RET
;
26 0EEA ;
27 0EEA ; MONITOR WORK AREA ;
28 0EEA ;
29 D000 P SCRN: EQU D000H
30 E003 P KANST: EQU E003H ; KANA STATUS PORT
;
31 0EEA ;
32 0EEA ;
33 0EEA ;
34 0EEA DEFS +4
35 0EEE ;ORG 0EEEH;KANA
;
36 0EEE ;
37 0EEE KANA: ENT
38 0EEE CDD40D CALL GRSTAS
39 0EF1 CAB90D JP Z,DSP01 ; NOT GRAPH KEY THEN JUM
;
40 0EF4 3E01 LD A,+1
41 0EF6 18EA JR ALPH1
;
42 0EF8 ;
43 0EF8 ;
44 0EF8 DEL: ENT
45 0EF8 EB EX DE,HL ; LD HL,(DSPXY)
46 0EF9 7C LD A,H ; HOME ?
47 0EFA B5 OR L
48 0EFB 28E8 JR Z,?RSTR
49 0EFD 7D LD A,L
50 0EFE B7 OR A
51 0EFF 200D JR NZ,DEL1 ; LEFT SIDE ?
52 0F01 CDF302 CALL .MANG
53 0F04 3808 JR C,DEL1
54 0F06 CDB10F CALL ?PONT
55 0F09 2B DEC HL
56 0F0A 3600 LD (HL),+0
57 0F0C 1825 JR INST-5 ; JP CURSL
58 0F0E DEL1: ENT
59 0F0E CDF302 CALL .MANG
60 0F11 0F RRCA

```

```

01 0F12 5E2B LD A,40
02 0F14 3001 JR NC,+3
03 0F16 07 RLCA ; ACC=80
04 0F17 95 SUB L
05 0F18 47 LD B,A ; TRNS. BYTE
06 0F19 CDB10F CALL ?PONT ; CHA. FROM ADR
DEL2: 07 0F1C 7E LD A,(HL)
08 0F1D 2B DEC HL
09 0F1E 77 LD (HL),A ; TO
10 0F1F 23 INC HL
11 0F20 CBDC SET 3,H ; COLOR RAM
12 0F22 7E LD A,(HL)
13 0F23 2B DEC HL
14 0F24 77 LD (HL),A
15 0F25 CB9C RES 3,H ; CHA.
16 0F27 23 INC HL
17 0F28 23 INC HL ; NEXT
18 0F29 10F1 DJNZ DEL2
19 0F2B 2B DEC HL ; ADR.ADJUST
20 0F2C 3600 LD (HL),0
21 0F2E CBDC SET 3,H
22 0F30 217100 LD HL,71H ; BLUE + WHITE
23 0F33 3EC4 LD A,C4H ; JP CURSL
24 0F35 C3E00D JP ?DPCT+4
;
INST: 26 0F38 ENT
27 0F38 CDF302 CALL .MANG
28 0F3B 0F RRCA
29 0F3C 2E27 LD L,+39
30 0F3E 7D LD A,L
31 0F3F 3001 JR NC,+3
32 0F41 24 INC H
33 0F42 CDB40F CALL ?PNT1
34 0F45 E5 PUSH HL
35 0F46 2A7111 LD HL,(DSPXY)
36 0F49 3002 JR NC,+4
37 0F4B 3E4F LD A,+79
38 0F4D 95 SUB L
39 0F4E 0600 LD B,0
40 0F50 4F LD C,A
41 0F51 D1 POP DE
42 0F52 2891 JR Z,?RSTR
43 0F54 1A LD A,(DE)
44 0F55 B7 OR A
45 0F56 20BD JR NZ,?RSTR
46 0F58 62 LD H,D ; HL<DE
47 0F59 6B LD L,E
48 0F5A 2B DEC HL
49 0F5B C3CA0E JP INST2 ; JUMP NEXT (BYPASS)
;
;
; PROGRAM SAVE
;
; CMD. 'S'
;
SAVE: 52 0F5E ENT
53 0F5E CALL HEXIY ; START ADR.
54 0F5E LD (DTADR),HL ; DATA ADR. BUFFER
55 0F5E LD B,H
56 0F5E LD C,L
57 0F5E CD3D01
58 0F61 220411
59 0F64 44
60 0F65 4D

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 59

04.07.83

```

01 0F66 CDA602      CALL  .4DE
02 0F69 CD3D01     CALL  HEXIY      ; END ADR.
03 0F6C ED42       SBC   HL,BC      ; BYTE SIZE
04 0F6E 23         INC   HL
05 0F6F 220211     LD    (SIZE),HL ; BYTE SIZE BUFFER
06 0F72 CDA602     CALL  .4DE
07 0F75 CD3D01     CALL  HEXIY      ; EXECUTE ADR.
08 0F78 220611     LD    (EXADR),HL ; BUFFER
09 0F7B CD0900     CALL  NL
10 0F7E 118B09     LD    DE,MSGSV  ; SAVED FILENAME
11 0F81 DF         RST   3          ; CALL MSGX
12 0F82 CD2F01     CALL  BGETL     ; FILENAME INPUT
13 0F85 CDA602     CALL  .4DE
14 0F88 CDA602     CALL  .4DE
15 0F8B 21F110     LD    HL,NAME   ; NAME BUFFER
16 0F8E            SAV1: ENT
17 0F8E 13         INC   DE
18 0F8F 1A         LD    A,(DE)
19 0F90 77         LD    (HL),A   ; FILENAME TRANS.
20 0F91 23         INC   HL
21 0F92 FE0D       CP    0DH       ; END CODE
22 0F94 20F8       JR    NZ,SAV1
23 0F96 3E01       LD    A,01H    ; ATTRIBUTE:OBJ.
24 0F98 32F010     LD    (ATRB),A
25 0F9B CD3604     CALL  ?WRI
26 0F9E DA0701     JP    C,?ER    ; WRITE ERROR
27 0FA1 CD7504     CALL  ?WRD     ; DATA
28 0FA4 DA0701     JP    C,?ER
29 0FA7 CD0900     CALL  NL
30 0FAA 114209     LD    DE,MSGOK ; OK MESSAGE
31 0FAD DF         RST   3          ; CALL MSGX
32 0FAE C3AD00     JP    ST1
33 0FB1            ;
34 0FB1            ;
35 0FB1            ; ORG 0FB1H;?PONT
36 0FB1            ;
37 0FB1            ;
38 0FB1            ; COMPUTE POINT ADR . ;
39 0FB1            ;
40 0FB1            ; HL = SCREEN COORDINATE
41 0FB1            ; EXIT
42 0FB1            ; HL = POINT ADR. ON SCREEN
43 0FB1            ;
44 0FB1            ; ?PONT: ENT
45 0FB1 2A7111     LD    HL,(DSPXY)
46 0FB4            ;
47 0FB4            ; ORG 0FB4H;?PNT1
48 0FB4            ;
49 0FB4            ; ?PNT1: ENT
50 0FB4 F5         PUSH  AF
51 0FB5 C5         PUSH  BC
52 0FB6 D5         PUSH  DE
53 0FB7 E5         PUSH  HL
54 0FB8 C1         POP   BC
55 0FB9 112800     LD    DE,0028H ; 40
56 0FBC 21D8CF     LD    HL,SCRN-40
57 0FBF            ; ?PNT2: ENT
58 0FBF 19         ADD   HL,DE
59 0FC0 05         DEC   B
60 0FC1 F2BF0F     JP    P,-2

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 60

04.07.83

```

01 0FC4 0600      LD    B,+0
02 0FC6 09        ADD   HL,BC
03 0FC7 D1        POP   DE
04 0FC8 C1        POP   BC
05 0FC9 F1        POP   AF
06 0FCA C9        RET
07 0FCB            ;
08 0FCB            ; VERIFYING
09 0FCB            ;
10 0FCB            ; COMMAND 'V'
11 0FCB            ;
12 0FCB            ; VRFY: ENT
13 0FCB CD8805     CALL  ?VRFY
14 0FCE DA0701     JP    C,?ER
15 0FD1 114209     LD    DE,MSGOK
16 0FD4 DF         RST   3
17 0FD5 C3AD00     JP    ST1
18 0FDB            ;
19 0FDB            ;
20 0FDB            ; ORG 0FDBH;?CLER
21 0FDB            ;
22 0FDB            ;
23 0FDB            ;
24 0FDB            ; CLER ;
25 0FDB            ; B=SIZE
26 0FDB            ; HL=LOW ADR.
27 0FDB            ;
28 0FDB            ; ?CLER: ENT
29 0FDB AF        XOR   A
30 0FD9 1802      JR    +4
31 0FDB            ; ?CLRFF: ENT
32 0FDB 3EFF      LD    A,FFH
33 0FDD            ; ?DINT: ENT
34 0FDD 77        LD    (HL),A
35 0FDE 23        INC   HL
36 0FDF 10FC      DJNZ -2
37 0FE1 C9        RET
38 0FE2            ;
39 0FE2            ;
40 0FE2            ; GAP CHECK
41 0FE2            ;
42 0FE2            ; GAPCK: ENT
43 0FE2 C5        PUSH  BC
44 0FE3 D5        PUSH  DE
45 0FE4 E5        PUSH  HL
46 0FE5 0101E0    LD    BC,KEYPB
47 0FE8 1102E0    LD    DE,CSTR
48 0FEB            ; GAPCK1: ENT
49 0FEB 2664      LD    H,100
50 0FED            ; GAPCK2: ENT
51 0FED CD0106     CALL  EDGE
52 0FF0 380B      JR    C,GAPCK3
53 0FF2 CD4A0A    CALL  DLY3      ; CALL DLY2*3
54 0FF5 1A        LD    A,(DE)
55 0FF6 E620      AND   20H
56 0FF8 20F1      JR    NZ,GAPCK1
57 0FFA 25        DEC   H
58 0FFB 20F0      JR    NZ,GAPCK2
59 0FFD            ; GAPCK3: ENT
60 0FFD C39B06     JP    RETS

```


01 1000 SKP H

```

37 11E4      END
38 11E4      ;
39 1000      ;
40 1000      ;
41 1000      ;
42 1000      ;
43 1000      ;
44 1000      ;
45 1000      ;
46 1000      ;
47 1000      ;
48 1000      ;
49 1000      ;
50 1000      ;
51 1000      ;
52 1000      ;
53 1000      ;
54 1000      ;
55 1000      ;
56 1000      ;
57 1000      ;
58 1000      ;
59 1000      ;
60 1000      ;

```

```

01 1000      ;
02 1000      ;
03 1000      ; MONITOR WORK AREA ;
04 1000      ; (MZ-700) ;
05 1000      ;
06 1000      ;
07 1000      ;
08 10F0      ; ORG -10F0H
09 10F0      ; SP: ENT
10 10F0      ; Ibuf: ENT ; TAPE BUFFER(128B)
11 10F0      ; ATRB: ENT ; ATTRIBUTE
12 10F0      ; DEFS +1 ;
13 10F1      ; NAME: ENT ; FILE NAME
14 10F1      ; DEFS +17 ;
15 1102      ; SIZE: ENT ; BYTE SIZE
16 1102      ; DEFS +2 ;
17 1104      ; DTADR: ENT ; DATA ADR
18 1104      ; DEFS +2 ;
19 1106      ; EXADR: ENT ; EXECUTION ADR
20 1106      ; DEFS +2 ;
21 1108      ; COMNT: ENT ; COMMENT
22 1108      ; DEFS +104 ;
23 1170      ; KANAF: ENT ; KANA FLAG
24 1170      ; DEFS +1 ;
25 1171      ; DSPXY: ENT ; DISPLAY CO-ORDINATES
26 1171      ; DEFS +2 ;
27 1173      ; MANG: ENT ; COLOUMN MANAGEMENT
28 1173      ; DEFS +27 ;
29 118E      ; FLASH: ENT ; FLASHING DATA
30 118E      ; DEFS +1 ;
31 118F      ; FLPST: ENT ; FLASSING POSITION
32 118F      ; DEFS +2 ;
33 1191      ; FLSST: ENT ; FLASING STATUS
34 1191      ; DEFS +1 ;
35 1192      ; FLSDT: ENT ; CURSOR DATA
36 1192      ; DEFS +1 ;
37 1193      ; STRGF: ENT ; STRING FLAG
38 1193      ; DEFS +1 ;
39 1194      ; DPRNT: ENT ; TAB COUNTER
40 1194      ; DEFS +1 ;
41 1195      ; TMCNT: ENT ; TAPE MARK COUNTER
42 1195      ; DEFS +2 ;
43 1197      ; SUMDT: ENT ; CHECK SUM DATA
44 1197      ; DEFS +2 ;
45 1199      ; CSMDT: ENT ; FOR COMPARE SUM DATA
46 1199      ; DEFS +2 ;
47 119B      ; AMPM: ENT ; AMPM DATA
48 119B      ; DEFS +1 ;
49 119C      ; TIMFG: ENT ; TIME FLAG
50 119C      ; DEFS +1 ;
51 119D      ; SWRK: ENT ; KEY SOUND FLAG
52 119D      ; DEFS +1 ;
53 119E      ; TEMPW: ENT ; TEMPO WORK
54 119E      ; DEFS +1 ;
55 119F      ; ONTYO: ENT ; ONTYO WORK
56 119F      ; DEFS +1 ;
57 11A0      ; OCTV: ENT ; OCTAVE WORK
58 11A0      ; DEFS +1 ;
59 11A1      ; RATIO: ENT ; ONPU RATIO
60 11A1      ; DEFS +2 ;

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 63

04.07.83

```

01 11A3          BUFER:  ENT          ; GET LINE BUFFER
02 11A3          DEFS    +81
03 11F4          ;
04 11F4          ;
05 11F4          ;          EQU TABLE I/O PORT
06 11F4          ;
07 11F4          ;
08 E000 P       KEYPA:  EQU    E000H
09 E001 P       KEYPB:  EQU    E001H
10 E002 P       KEYPC:  EQU    E002H
11 E003 P       KEYPF:  EQU    E003H
12 E002 P       CSTR:   EQU    E002H
13 E003 P       CSTPT:  EQU    E003H
14 E004 P       CONTO:  EQU    E004H
15 E005 P       CONT1:  EQU    E005H
16 E006 P       CONT2:  EQU    E006H
17 E007 P       CONTF:  EQU    E007H
18 E008 P       SUNDG:  EQU    E008H
19 E008 P       TEMP:   EQU    E008H
20 11F4          ;
21 11F4          END

```

** Z80 ASSEMBLER SB-7201 <1Z-013A> PAGE 64

04.07.83

```

#BRK 08BB #CLR08 09D4 #CLR8 09D5 #MCP 006B ..LPT 017B
.L4DE 02A6 .LPT 0176 .MANG 02F3 2HE1 0434 2HEX 041F
??KEY 09B3 ?ADCN 08B9 ?BEL 0577 ?BELD 0352 ?BLNK 0DA6
?BRK 0A32 ?BRK1 0A48 ?BRK2 0980 ?BRK3 0986 ?CLER 0FDB
?CLRFF 0FDB ?DACN 0BCE ?DINT 0FDD ?DPCT 0DDC ?DSP 0DB5
?ER 0107 ?FLAS 09FF ?FLS 09E3 ?GET 08BD ?GETL 07E6
?KEY 08CA ?KY1 0BD6 ?KY2 08DA ?KY5 0BFA ?KY55 0BFB
?KYGRP 08FE ?KYGRS 0909 ?KYSM 08B3 ?LOAD 05F0 ?LTNL 090E
?MLDY 01C7 ?MODE 073E ?MSG 0893 ?MSGX 08A1 ?NL 0918
?PNT1 0FB4 ?PNT2 0FBF ?PONT 0FB1 ?PRNT 0935 ?PRT 0946
?PRTS 0920 ?PRTT 0924 ?RDD 04F8 ?RDI 04DB ?RSTR 0EE5
?RSTR1 0EE6 ?SAVE 0B92 ?SWEP 0A50 ?TEMP 02E5 ?TMR1 0375
?TMR2 037F ?TMRD 035B ?TMS1 0331 ?TMS2 0344 ?TMST 0308
?VRFY 0588 ?WRD 0475 ?WRI 0436 ALPH1 0EE2 ALPHA 0EE1
AMPM 119B ASC 03DA ATBL 0A92 ATRB 10F0 AUTO3 07ED
BELL 003E BGETL 012F BRKEY 001E BUFFER 11A3 CKS1 0720
CKS2 072F CKS3 0733 CKSUM 071A CLEAR 09DB CLEAR1 09DA
CLRS 0E3A CMY0 005B COMNT 1108 CONTO E004 CONT1 E005
CONT2 E006 CONTF E007 CR 0E5A CR1 0E6A CSMdT 1199
CSTPT E003 CSTR E002 CTBL 0EAA CURS1 0DDF CURS2 0E16
CURS3 0DFF CURS4 0E23 CURS5 0E02 CURSD 0DF8 CURSL 0E25
CURSR 0E0D CURSU 0E05 CURSU1 0E0B DACN1 0BE3 DACN2 0BDF
DACN3 0BE0 DEL 0EF8 DEL1 0F0E DEL2 0F1C DLY1 0759
DLY12 0996 DLY2 0760 DLY3 0A4A DLY4 09A9 DPRT 0194
DSP01 0DB9 DSP04 0DD0 DSPXY 1171 DSWEP 0830 DTADR 1104
DUM1 0DB8 DUM2 0D3E DUM3 0D37 DUMP 0D29 EDG1 0607
EDG2 0613 EDGE 0601 EXADR 1106 FD 00FF FD1 0106
FD2 0102 FLAS1 097B FLAS2 09EF FLAS3 09F3 FLASH 11BE
FLKEY 057E FLPST 11BF FLSDT 1192 FLSST 1191 GAP 077A
GAP1 078E GAP2 0796 GAP3 079C GAPCK 0FE2 GAPCK1 0FEB
GAPCK2 0FED GAPCK3 0FFD GETKY 001B GETL 0003 GETL1 07EA
GETL2 0818 GETL3 085B GETL5 081D GETL6 0865 GETLA 082B
GETLB 0863 GETLC 0822 GETLR 087E GETLU 0876 GETLZ 086C
GOTO 00F3 GRSTAS 0DD4 HEX 03F9 HEXIY 013D HEXJ 03E5
HL1 041D HLHEX 0410 HOME 0E4D IbufE 10F0 INST 0F38
INST2 0ECA KANA 0EEE KANAF 1170 KANST E003 KEYFA E000
KEYPB E001 KEYPC E002 KEYPF E003 KSL1 09B7 KSL2 09BC
KTBL 0BEA KTBLC 0CAA KTBLG 0CE9 KTBLGS 0C6A KTBL5 0C2A
LETNL 0006 LLPT 0470 LOAO 0116 LOAD 0111 LONG 0A1A
LPRNT 018F M#TBL 0284 MANG 1173 MCR 07A8 MCR1 07AB
MCR2 07D4 MCR3 07D7 MELDY 0030 MLD1 01D1 MLD2 0205
MLD3 020D MLD4 0211 MLD5 0214 MLD51 02C4 MLDSP 02BE
MLDST 02AB MNIT 0000 MOT1 06A4 MOT2 06AB MOT4 06B9
MOT5 06D8 MOT7 06B7 MOT8 06D0 MOT9 06D7 MOTOR 069F
MSG 0015 MSG#1 03FB MSG#2 03FD MSG#3 0402 MSG#7 0467
MSG1 0896 MSG?2 09A0 MSG?3 06E7 MSGE1 0147 MSGOK 0942
MSGSV 09BB MSGX 0018 MSGX1 08A4 MSGX2 08A7 MST1 0705
MST2 070C MST3 0717 MSTA 0044 MSTOP 0700 MSTP 0047
MTBL 026C NAME 10F1 NL 0009 NLPHL 05FA NOADD 03E2
OCTV 11A0 ONP1 021F ONP2 022C ONP3 0265 ONPU 021C
QNTYD 119F OPTBL 029C PEN 018B PLOT 0184 PMSG 01A5
PMSG1 01AB PRNT 0012 PRNT2 0967 PRNT3 096C PRNT4 096F
PRNT5 0959 PRNTS 000C PRNTT 000F PRTHL 03BA PRTHX 03C3
PTEST 0155 PTRN 0180 PTST0 015A PTST1 0170 RATID 11A1
RBY1 0630 RBY2 0649 RBY3 0654 RBYTE 0624 RD1 04E6
RDA 01B6 RDDAT 002A RDINF 0027 RET1 04D2 RET2 0554
RET3 069B RTAPE 050E RTP1 0513 RTP2 0519 RTP3 0532
RTP4 0554 RTP5 0565 RTP6 0572 RTP7 056E RTP8 0553
RTP9 0574 RYTHM 02C8 SAV1 0F8E SAVE 0F5E SCRN 0000
SCRQL 0E6D SG 00F7 SHORT 0A01 SIZE 1102 SLPT 03D5

```

SP	10F0	SPHEX	03B1	SS	00A2	ST0	0070	ST1	00AD
ST2	00BB	START	004A	STRGF	1193	SUMDT	1197	SUNDG	E008
SVO	0BA2	SV1	0BB5	SWEP0	0A66	SWEP01	0A64	SWEP2	0A7F
SWEP3	0A77	SWEP6	0A5F	SWEP9	0A73	SWRK	119D	TEMP	E008
TEMPW	119E	TIMFG	119C	TIMIN	03BD	TIMRD	003B	TIMST	0033
TM1	0675	TM2	0678	TM3	0688	TM4	069B	TMARK	065B
TMCNT	1195	TVF1	05B2	TVF2	05B8	TVF3	05CC	TVERFY	05AD
VERFY	002D	VGOFF	0747	VERFY	0FCB	VRNS	0BC5	WBY1	076D
WBYTE	0767	WRDAT	0024	WR11	0444	WR12	045E	WR13	0464
WRINF	0021	WTAP1	0494	WTAP2	04A5	WTAP3	04D2	WTAPE	048A
XTEMP	0041								

- The pen nib mode is switched from graphics to text.
- The graphics mode can be changed in the range from 0 to 03.
- The pen nib mode can be changed by the following control codes and commands.

A.8.1 Control codes

Changes the next color.

- Next color (201D)

Moves the carriage left or right by the number of the line counter to 0.

- Form feed (202)

Moves the carriage one column to the left. This code is ignored when the carriage

- Back space (202)

Moves the carriage to the left side of the print area.

- Carriage return (202)

Reverses the pen nib mode.

- Message (202)

Engages the pen nib mode.

- Message (202)

Engages the pen nib mode.

- Line feed (202)

Moves the paper one line in the forward direction. The line counter is incremented by 1

- Line feed (202)

lines per page is 255. Set to 0 when the power is turned on or the system is reset.

Specifies the number of lines per page as indicated by 3 bytes of ASCII code. The maximum number of

lines per page is 255. Set to 0 when the power is turned on or the system is reset.

- Line counter (202) + (202) + (202) + (ASCII) + (ASCII) + (20D)

Engages the pen nib mode from 0 to 1 (40 characters).

- Pen nib mode (202) + (202) + (20B)

Reverses the pen nib mode from 1 to 0 (80 characters).

- Pen nib mode (202) + (202) + (20A)



color = 0

Specifies the following printing patterns to start ink flowing from the pen nib. When the pen nib mode is set to 0 (80 characters).

- Pen nib mode (202) + (204)

Moves the carriage in the reverse direction. The line counter is decremented by 1.

- Line counter (202) + (202) + (203)

Engages the pen nib mode.

- Pen nib mode (202) + (202) + (20A)

Reverses the pen nib mode.

- Pen nib mode (202) + (202) + (20B)

Engages the pen nib mode.


A.8.2 Control codes used in the text mode

A.9 Color Printer Control Codes

A. 6 Color Plotter-Printer Control Codes

A.6.1 Control codes used in the text mode

- Text code (\$01)
Sets the printer in the text mode.
- Graphic code (\$02) Same as the BASIC MODE GR statement.
Sets the printer in the graphic mode.
- Line up (\$03) Same as the BASIC SKIP-1 statement.
Moves the paper one line in the reverse direction. The line counter is decremented by 1.
- Pen test (\$04) Same as the BASIC TEST statement.
Writes the following patterns to start ink flowing from the pens, then sets scale = 1 (40 chr/line), color = 0.



- Reduction scale (\$09) + (\$09) + (\$09)
Reduces the scale from 1 to 0 (80 chr/line).
- Reduction cancel (\$09) + (\$09) + (\$0B)
Enlarges the scale from 0 to 1. (40 chr/line).
- Line counter set (\$09) + (\$09) + (ASCII)₂ + (ASCII)₁ + (ASCII)₀ + (\$0D)
..... Same as the BASIC PAGE statement.
Specifies the number of lines per page as indicated by 3 bytes of ASCII code. The maximum number of lines per page is 255. Set to 66 when the power is turned on or the system is reset.
- Line feed (\$0A) Same as the BASIC SKIP 1 statement.
Moves the paper one line in the forward direction. The line counter is incremented by 1.
- Magnify scale (\$0B)
Enlarges the scale from 1 to 2 (26 chr/line).
- Magnify cancel (\$0C)
Reduces the scale from 2 to 1.
- Carriage return (\$0D)
Moves the carriage to the left side of the print area.
- Back space (\$0E)
Moves the carriage one column to the left. This code is ignored when the carriage is at the left side of the print area.
- Form feed (\$0F)
Moves the paper to the beginning of the next page and resets the line counter to 0.
- Next color (\$1D)
Changes the pen to the next color.


A.6.2 Character scale

- The character scale is automatically set to 1 (40 chr/line) when the power is turned on. Afterwards, it can be changed by the control codes and commands.
- In the graphic mode, the scale can be changed in the range from 0 to 63.
- The scale is set to 1 when the mode is switched from graphic to text.

A.6.3 Graphic mode commands

A. 6. 3. 1 Command type

In the graphic mode, the printer can be controlled by outputting the following commands to the printer. Words in parentheses are BASIC statements which have the same functions as the graphic mode commands.

Command name	Format	Function
LINE TYPE	Lp (p = 0 to 15)	Specifies the type of line (solid or dotted) and the dot pitch. p = 0 : solid line, p = 1 ~ 15 : dotted line 
ALL INITIALIZE	A	Sets the printer in the text mode.
HOME (PHOME)	H	Lifts the pen and returns it to the origin (home position).
INITIALIZE (HSET)	I	Sets the current pen location as the origin (x = 0, y = 0).
DRAW (LINE)	Dx, y, . . . xn, yn (-999 ≤ x, y ≤ 999)	Draws lines from the current pen location to coordinates (x ₁ , y ₁), then to coordinates (x ₂ , y ₂), and so forth.
RELATIVE DRAW (RLINE)	JΔx, Δy . . . Δxn, Δyn (-999 ≤ Δx, Δy ≤ 999)	Draws lines from the current pen location to relative coordinates (Δx ₁ , Δy ₁), then to relative coordinates (Δx ₂ , Δy ₂) and so forth.
MOVE (MOVE)	Mx, y (-999 ≤ x, y ≤ 999)	Lifts the pen and moves it to coordinates (x, y).
RELATIVE MOVE (RMOVE)	RΔx, Δy (-999 ≤ Δx, Δy ≤ 999)	Lifts the pen and moves it to relative coordinates (Δx, Δy).
COLOR CHANGE (PCOLOR)	Cn (n = 0 to 3)	Changes the pen color to n.
SCALE SET	Sn (n = 0 to 63)	Specifies the character scale.
ALPHA ROTATE	Qn (n = 0 to 3)	Specifies the direction in which characters are printed.
PRINT	Pc ₁ c ₂ c ₃ . . . cn (n = ∞)	Prints characters.
AXIS (AXIS)	Xp, q, r (p = 0 or 1) (q = -999 to 999) (r = 1 to 255)	Draws an X axis when p = 1 and a Y axis when p = 0. q specifies the scale pitch and r specifies the number of scale marks to be drawn.

A. 6. 3. 2 Command format

There are 5 types of command formats as shown below.

- Command character only (without parameters)
"A", "H", "I"
- Command character plus one parameter
"L", "C", "S", "Q"
- Command character plus pairs of parameters
"D", "J", "M", "R"
", " is used to separate parameters, and a CR code is used to end the parameter list.
- Command plus character string
"P"
The character string is terminated with a CR code.
- Command plus three parameters
"X"
", " is used to separate parameters.

A. 6. 3. 3 Parameter specification

1. Leading blanks are ignored.
2. Any number preceded by "--" is treated as a negative number.
3. If the number of digits of a number exceeds 3, only the lower 3 digits are effective.
4. Each parameter is ended with ",", " or a CR code. If other than numbers are included in a parameter, subsequent characters are ignored until a comma or CR code is detected.

Example) D <u> </u> -135.21,	Format	Command name
	Lp (p = 0 to 12)	LINE TYPE

A. 6. 3. 4 Abbreviated formats

1. Any command can be followed by a one-character command without entering a CR code.
Ex) "HD100, 200" CR is effective and is the same as "H" CR "D100, 200" CR.
2. Any command can be followed by a command with one parameter by separating them with a comma ",".
Ex) "L0, S1, Q0, C1, D100, 200" CR is effective.
3. A command with pairs of parameters must be terminated with a CR code.

4. 6. 3. 5 Data change due to mode switching

The following data changes when the printer is switched from the graphic mode to the text mode.

- X and Y coordinates
- Y is set to 0 and the origin is placed at the left side of the printable area.
- Direction of characters
- Q is set to 0.
- Character scale
- Character scale is set to 1.
- The line type setting is not affected.

Prints characters	Pc (c = ~) (n = ~)	PRINT
Draws an X axis when p = 1 and a Y axis when p = 0. p specifies the scale pitch and r specifies the number of scale marks to be drawn.	Xp, p, r (p = 0 or 1) (r = 1 to 125)	AXIS
Specifies the characters to be printed.	Qn (n = 0 to 3)	ALPHA ROTATE
Changes the pen color to n.	Sn (n = 0 to 63)	SCALE SET
	Cr (n = 0 to 3)	COLOR CHANGE (BT COLOR)
	(-999 ≤ Δx, Δy ≤ 999)	RELATIVE MOVE (TRMOVE)
	(-999 ≤ x, y ≤ 999)	MOVE (TRMOVE)

A. 7 Notes Concerning Operation

■ Data recorder

- Although the data recorder of the MZ-700 is highly reliable, the read/write head will wear out after prolonged use. Further, magnetic particles and dust will accumulate on the head, degrading read/write performance. Therefore, the head must be cleaned periodically or replaced when it becomes worn.
 1. To clean the head, open the cassette compartment, press the **PLAY** key, and wipe the head and pinch roller using a cotton swab. If they are very dirty, soak the cotton swab in alcohol.
 2. When the head becomes worn, contact your dealer. Do not attempt to replace it by yourself.

■ Cassette tape


- Any commercially available cassette tape can be used with the MZ-700. However, it is recommended that you use quality cassette tape produced by a reliable manufacturer.

- Use normal type tapes.
- Avoid using C-120 type cassette tapes.
- Use of C-60 or shorter cassette tapes is recommended.
- Be sure to take up any the slack in the tape with a pencil or the like as shown at right before loading the cassette tape: otherwise, the tape may break or become wound round the pinch roller.


● Protecting programs/data from accidental erasure

The data recorder of the MZ-700 is equipped with a write protect function which operates in the same manner as with ordinary audio cassette tape decks.

To prevent data from being accidentally erased, remove the record lock-out tab from the cassette with a screwdriver or the like. This makes it impossible to press the **RECORD** key, preventing erasure of, valuable data.



Remove record lock-out tab with a screwdriver.



■ Other

- See page 109 for commercially available cassette tape decks.

■ Display unit

When using a display unit other than one specified for the MZ-700, the screen size must be adjusted. See page 106.

■ Color plotter-printer

- Do not rotate the pen drum in the reverse direction when replacing pens.
- Be sure to remove the pens from the pen drum, replace their caps to them, and store them in the case to prevent them from drying out when the printer is not to be used for an extended period of time.
- It takes a certain amount of time for ink on the paper to dry. (The ink is water-soluble.)
- Do not rip off the paper when the printer cover is removed. Hold down the paper holder when ripping off the paper.
- Do not touch the internal mechanism when replacing the pens. Failure to observe this warning may result in damage to the printer.
- The color plotter printer generates sound for a moment when the power is turned on. This is not a problem.
- Letters printed in the 80 character line mode may be difficult to read. In this case, use the 40 character/line mode.
- In the graphic mode, lines printed repeatedly may become blurred. This is particularly liable to occur when a dotted line is printed repeatedly. Due to the characteristics of the ball pen, this is unavoidable.

■ Notes concerning software

- It takes about 3 minutes to load the BASIC interpreter.
- The reset switch on the rear panel is to be used in the following cases. (See 3. 1. 1.)
To stop execution of a BASIC program during normal execution or when the program enters an infinite loop. To return to the program, use the # command. However, the program or hardware should be checked if the program loops.

■ BASIC calculation error

- BASIC converts decimal values to floating point binary values before performing calculations, then converts the binary calculation results into decimal numbers for display. This can result in a certain amount of error.

(Example:)

```
PRINT 817.3-810.4  
6.899999
```

..... Correct result is 6.9.

- Approximations are made during calculation of functions and exponentiation.
- The above must be considered when using IF statements.

(Example:)

```
10 A=1/100*100  
20 IF A=1 THEN PRINT "TRUE" : GOTO 40  
30 PRINT "FALSE"  
40 PRINT "A=" ; A  
50 END  
RUN  
FALSE  
A=1
```

Although the practical result of the equation in line 10 is 1, this program prints FALSE because of error due to conversion.

- **Notes concerning handling**

- **Power switch**

The power switch should be left untouched for at least 10 seconds after being turned on or off. This is necessary to ensure correct operation of the computer. Do not unplug the power cable when the power switch is on: otherwise, trouble may result.

- **Power cable**

Avoid placing heavy objects such as desks on top of the power cable. This may damage the power cable, possibly resulting in a serious accident. Be sure to grasp the cable by the plug when unplugging it.

- **Power supply voltage**

The power supply voltage is 240/220 VAC. The computer may not operate properly if the voltage is too high or too low. Contact your dealer for assistance if you experience this problem.

- **Ventilation**

Many vents are provided in the cabinet to prevent overheating. Place the computer in a well ventilated place, and do not cover it with a cloth. Do not place any objects on the left side of the computer, since this is where the vents for the power supply unit are located.

- **Humidity and dust**

Do not use the computer in a damp or dusty places.

- **Temperature**

Do not place the computer near heaters or in places where it may be exposed to direct sunlight; failure to observe this precaution may result in damage to the computer's components.

- **Water and foreign substances**

Water and other foreign substances (such as pins) entering the computer will damage it. Unplug the power cable immediately and contact your dealer for assistance if such an accident occurs.

- **Shock**

Avoid subjecting the computer to shock; strong shocks will damage the computer permanently.

- **Trouble**

Stop immediately operation and contact your dealer if you note any abnormality.

- **Prolonged disuse**

Be sure to unplug the power cable if the computer is not to be used for a prolonged period of time.

- **Connection of peripheral devices**

Use only parts and components designated by Sharp when connecting any peripheral devices, otherwise, the computer may be damaged.

- **Dirt**

Wipe the cabinet with a soft cloth soaked in water or detergent when it becomes dirty. To avoid discoloration of the cabinet, do not use volatile fluids such as benzene.

- **Noise**

It is recommended that a line filter be used when the computer is used in a place where high level noise signals may be present in the AC power. (A line filter can be obtained from your Sharp dealer). Move the signal cables as far as possible from the power cable and other electrical appliances.

- **RF interference**

Interference with TV or radio reception may occur due to the RF signal generated by the computer if it is used near a TV or radio set. TV sets generate a strong magnetic field which may result in incorrect operation of the computer. If this occurs, move the TV set at least 2 to 3 meters away from the computer.

This apparatus complies with requirements of EEC directive 76/889/EEC.

Copying/Debugging of MZ-700 Basic Interpreter

A. Please follow the procedure below mentioned to copy the BASIC tape.

- 1) Power on MZ-700 (→ monitor state)
- 2) Partial memory should be modified by the use of monitor command M (memory correction) as follows:

*MCF00

CF00	FF → CD
CF01	00 → 27
CF02	FF → 00
CF03	00 → 38
CF04	FF → 03
CF05	00 → CD
CF06	FF → 2A
CF07	00 → 00
CF08	FF → DA
CF09	00 → FE
CF0A	FF → 00
CF0B	00 → C3
CF0C	FF → AD
CF0D	00 → 00
CF0E	FF → CD
CF0F	00 → 27
CF10	FF → 00
CF11	00 → 38
CF12	FF → F5
CF13	00 → C3
CF14	FF → CB
CF15	00 → 0F

SHIFT + BREAK to be keyed in.

NOTE: The content of memory from CF00 to CF15 may not always be as above mentioned.

- 3) The cassette to be read (copied from) should be set to the tape recorder.
- 4) Key in the monitor command J (Jump) as follows:

* JCF00 CR
 PLAY

NOTE: If a button of the tape recorder is still pushed no play indication will appear.

- 5) Confirming the “ PLAY” indication above mentioned, push PLAY button and load the content of BASIC tape. On this occasion, no indication like FILE NAME, etc. will be shown. When ERROR occurred, please restart from the item 1) again.
- 6) Set a new cassette to which the BASIC should be written into the recorder and execute REWIND .

7) Key in as follows:

* J1108

8) The monitor will be cleared and the following indication will appear:

S-BASICEX SAVER xx xx
HIT ANY KEY?

9) Push any key.

Record Play

button should be pushed beforehand.

10) Push button. The copy will start and the following indication will appear:

WRITING S-BASIC

On the occasion of MZ-711, item 9) should be effectuated after setting the external tape recorder in recording state.

11) After the sound "Pit Pit", the copy will be terminated.

12) The monitor state will be recovered by pushing the rear RESET SW.

13) Rewind the tape and push button.

14) Key in as follows:

* JCF0E

PLAY

15) Push button of the recorder and the "VERIFY" function will be executed. When successful verified, the indication of "OK!" will appear though no other indication like FILE NAME etc. will appear. When error occurred, please restart from the item 4).

16) Please make sure to enable the write protection of the cassette by removing the nail.

B. The following procedure is requested to modify the content of BASIC interpreter.

a) Operate just as the case for copying mentioned in item 1) to 5).

b) Call up the address to be modified by using the monitor command M.

Ex. 8A in 1234H should be changed to 7A.

		Key in
*M		1234
1234	8A	7A <input type="text" value="CR"/>
1235	8A	<input type="text" value="SHIFT"/> + <input type="text" value="BREAK"/>
*		

C. The operation from the item 6) onwards should be continued hereafter.

SHARP CORPORATION
OSAKA, JAPAN

Printed in Japan
Gedruckt in Japan
Imprimé au Japon

3H 5.305-1
TINSE1066ACZZ